

Machine Automation Controller

NJ-series

CPU Unit Motion Control

User's Manual

NJ501-1300

NJ501-1400

NJ501-1500

CPU Unit



© **OMRON, 2011**

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.

No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

Introduction

Thank you for purchasing an NJ-series CPU Unit.

This manual contains information that is necessary to use the Motion Control Function Module of an NJ-series CPU Unit. Please read this manual and make sure you understand the functionality and performance of the NJ-series CPU Unit before you attempt to use it in a control system.

Keep this manual in a safe place where it will be available for reference during operation.

Intended Audience

This manual is intended for the following personnel, who must also have knowledge of electrical systems (an electrical engineer or the equivalent).

- Personnel in charge of introducing FA systems.
- Personnel in charge of designing FA systems.
- Personnel in charge of installing and maintaining FA systems.
- Personnel in charge of managing FA systems and facilities.

For programming, this manual is intended for personnel who understand the programming language specifications in international standard IEC 61131-3 or Japanese standard JIS B3503.

Applicable Products

This manual covers the following products.

- NJ-series CPU Units
 - NJ501-1300
 - NJ501-1400
 - NJ501-1500

Relevant Manuals

There are three manuals that provide basic information on the NJ-series CPU Units: the *NJ-series CPU Unit Hardware User's Manual*, the *NJ-series CPU Unit Software User's Manual* (this manual), and the *NJ-series Instructions Reference Manual*.

Most operations are performed from the Sysmac Studio Automation Software. Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for information on the Sysmac Studio.

Other manuals are necessary for specific system configurations and applications.

Read all of the manuals that are relevant to your system configuration and application to make the most of the NJ-series CPU Unit.

	NJ-series User's Manuals								
	Basic information								CJ-series Special Unit Operation Manuals for NJ-series CPU Unit
	NJ-series CPU Unit Hardware User's Manual	NJ-series CPU Unit Software User's Manual	NJ-series Instructions Reference Manual	NJ-series CPU Unit Motion Control User's Manual	NJ-series CPU Unit Built-in EtherCAT Port User's Manual	NJ-series Motion Control Instructions Reference Manual	NJ-series CPU Unit Built-in EtherNet/IP Port User's Manual	NJ-series Troubleshooting Manual	
Introduction to NJ-series Controllers	●								
Setting devices and hardware									
Using motion control				●					
Using EtherCAT	●				●				
Using EtherNet/IP							●		
Using CJ-series Units								●	
Software settings									
Using motion control		●		●					
Using EtherCAT					●				
Using EtherNet/IP							●		
Programming		●	●						
Using motion control				●		●			
Using EtherCAT					●				
Using CJ-series Units								●	
Programming error processing								●	
Testing operation and debugging									
Using motion control		●		●					
Using EtherCAT					●				
Using EtherNet/IP							●		
Troubleshooting and managing errors in an NJ-series Controller	△	△		△			△	△	
	Use the relevant manuals for references according to any error that occurs.								
Maintenance									
Using EtherCAT	●				●				
Using EtherNet/IP							●		
Using CJ-series Units								●	

Manual Configuration

NJ-series CPU Unit Hardware User's Manual (Cat. No. W500)

Section	Description
Section 1 Introduction	This section provides an introduction to the NJ-series Controllers and their features, and gives the NJ-series Controller specifications.
Section 2 System Configuration	This section describes the system configuration used for NJ-series Controllers.
Section 3 Configuration Units	This section describes the parts and functions of the configuration devices in the NJ-series Controller configuration, including the CPU Unit and Configuration Units.
Section 4 Installation and Wiring	This section describes where and how to install the CPU Unit and Configuration Units and how to wire them.
Section 5 Troubleshooting	This section describes the event codes, error confirmation methods, and corrections for errors that can occur.
Section 6 Inspection and Maintenance	This section describes the contents of periodic inspections, the service life of the Battery and Power Supply Units, and replacement methods for the Battery and Power Supply Units.
Appendices	The appendices provide the specifications of the Basic I/O Units, Unit dimensions, load short-circuit protection detection, line disconnection detection, and measures for EMC Directives.

NJ-series CPU Unit Software User's Manual (Cat. No. W501)

Section	Description
Section 1 Introduction	This section provides an introduction to the NJ-series Controllers and their features, and gives the NJ-series Controller specifications.
Section 2 CPU Unit Operation	This section describes the variables and control systems of the CPU Unit and CPU Unit status.
Section 3 I/O Ports, Slave Configuration, and Unit Configuration	This section describes how to use I/O ports, how to create the slave configuration and unit configuration and how to assign functions.
Section 4 Controller Setup	This section describes the initial settings of the function modules.
Section 5 Designing Tasks	This section describes the task system and types of tasks.
Section 6 Programming	This section describes programming, including the programming languages and the variables and instructions that are used in programming.
Section 7 Simulation, Transferring Projects to the Physical CPU Unit, and Operation	This section describes simulation of Controller operation and how to use the results of simulation.
Section 8 CPU Unit Status	This section describes CPU Unit status.
Section 9 CPU Unit Functions	This section describes the functionality provided by the CPU Unit.
Section 10 Communications Setup	This section describes how to go online with the CPU Unit and how to connect to other devices.
Section 11 Example of Actual Application Procedures	This section describes the procedures that are used to actually operate an NJ-series Controller.
Section 12 Troubleshooting	This section describes the event codes, error confirmation methods, and corrections for errors that can occur.
Appendices	The appendices provide the CPU Unit specifications, task execution times, system-defined variable lists, data attribute lists, CJ-series Unit memory information, CJ-series Unit memory allocation methods, and data type conversion information.

NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507) (This Manual)

Section	Description
Section 1 Introduction to the Motion Control Function Module	This section describes the features, system configuration, and application flow for the Motion Control Function Module.
Section 2 Motion Control Configuration and Principles	This section outlines the internal structure of the CPU Unit and describes the configuration and principles of the MC Function Module.
Section 3 Configuring Axes and Axes Groups	This section describes the concept of axes and axes groups, the settings for axes that are required for the MC Test Run operations to function on the Sysmac Studio, and the instructions for creating and configuring axes and axes groups using the Sysmac Studio.
Section 4 Checking Wiring from the Sysmac Studio	This section describes the MC Test Run operations of the Sysmac Studio. You can use the MC Test Run operations to monitor sensor signals, check Servomotor wiring, and more, all without any programming.
Section 5 Motion Control Parameters	This section provides information on the axis parameters and axes group parameters that are used for motion control.
Section 6 Motion Control Programming	This section provides the specifications of a motion control program and the operating procedures that are required up through actual program development.
Section 7 Manual Operation	This section describes manual operation when the MC Function Module is used together with an OMRON G5-series Servo Drive.
Section 8 Homing	This section describes homing.
Section 9 Motion Control Functions	This section describes the motion control functions that are used when connected to OMRON G5-series Servo Drives with built-in EtherCAT communications.
Section 10 Sample Programming	This section describes basic application methods for homing, error monitoring, and other functions, and provides programming samples for absolute positioning, cam operation, and other axis operations.
Section 11 Troubleshooting	This section describes the items to check when problems occur in the MC Function Module. It includes error diagnosis and countermeasures for error indications, and error diagnosis and countermeasures for operating conditions.
Appendices	The appendices describe settings and connection methods for OMRON G5-series Servo Drive objects.

NJ-series Instructions Reference Manual (Cat. No. W502)

Section	Description
Section 1 Instruction Set	This section provides a table of the instructions that are described in this manual.
Section 2 Instruction Descriptions	This section describes instruction specifications in detail.
Appendices	The appendices provide a table of error codes and other supplemental information to use instructions.

NJ-series CPU Unit Built-in EtherCAT Port User's Manual (Cat. No. W505)

Section	Description
Section 1 Introduction	This section provides an overview of EtherCAT communications, describes the system configuration and specifications, and provides operating procedures.
Section 2 Part Names and Slave Settings	This section provides the part names and describes the slave settings and Sysmac device functions.
Section 3 EtherCAT Communications	This section describes the different types of EtherCAT communications, EtherCAT settings, and state transitions.
Section 4 EtherCAT Network Wiring	This section describes how to connect and wire an EtherCAT network.
Section 5 Setting Up EtherCAT Communications with the Sysmac Studio	This section describes how to set the network configuration information and how to check EtherCAT communications from the Sysmac Studio.
Section 6 Process Data Communications and SDO Communications	This section describes the timing of communications, response times, and special instructions for process data communications and SDO communications. It also provides sample programming.
Section 7 System-defined Variables That Are Related to the Built-in EtherCAT Port	This section describes the system-defined variables that are related to the built-in EtherCAT port.
Section 8 Example of Operations for EtherCAT Communications	This section provides a series of example operations for when an NJ-series CPU Unit is connected to slaves.
Section 9 Troubleshooting	This section describes the event codes, error confirmation methods, and corrections for errors that can occur for EtherCAT communications. It also describes how to replace slaves.
Appendices	The appendices describe the relation of EtherCAT communications to overall CPU Unit status, packet monitoring functions, and multi-vendor application.

NJ-series Motion Control Instructions Reference Manual (Cat. No. W508)

Section	Description
Section 1 Introduction to Motion Control Instructions	This section gives an introduction to motion control instructions supported by NJ-series CPU Units.
Section 2 Variables and Instructions	This section describes the variables and instructions for the Motion Control Function Module.
Section 3 Axis Command Instructions	This section describes the instructions that are used to perform single-axis control for the MC Function Module.
Section 4 Axes Group Instructions	This section describes the instructions to perform multi-axes coordinated control for the MC Function Module.
Section 5 Common Command Instructions	This section describes the instructions that are used for both axes and axes groups.
Appendices	The appendices describe the error codes that are generated by the instructions.

NJ-series Troubleshooting Manual (Cat. No. W503)

Section	Description
Section 1 Overview of Errors	This section describes the errors that can occur on an NJ-series Controller, the operation that occurs for errors, and methods to confirm errors.
Section 2 Error Troubleshooting Methods	This section describes how to handle errors.
Section 3 Error Tables	This section lists all of the error events that can occur on NJ-series Controllers.


Sysmac Studio Version 1 Operation Manual (Cat. No. W504)

Section	Description
Section 1 Introduction	This section provides an overview and lists the specifications of the Sysmac Studio and describes its features and components.
Section 2 Installation and Uninstallation	This section describes how to install and uninstall the Sysmac Studio.
Section 3 System Design	This section describes the basic concepts for designing an NJ-series System with the Sysmac Studio and the basic operating procedures.
Section 4 Programming	This section describes how to create programs with the Sysmac Studio.
Section 5 Online Connections to a Controller	This section describes how to go online with a Controller.
Section 6 Debugging	This section describes how to debug the programs online on the Controller or debug it offline with the Simulator.
Section 7 Other Functions	This section describes Sysmac Studio functions other than system design functions.
Section 8 Reusing Programming	This section describes how to reuse the programs that you create with the Sysmac Studio.
Section 9 Support Software Provided with the Sysmac Studio	This section describes the Support Software that is provided with the Sysmac Studio.
Section 10 Troubleshooting	This section describes the error messages that are displayed when you check a program on the Sysmac Studio and how to correct those errors.
Appendices	The appendices describe the following: Driver Installation for Direct USB Cable Connection Specifying One of Multiple Ethernet Interface Cards Online Help Simulation Instructions

Manual Structure

Page Structure

The following page structure is used in this manual.



This illustration is provided only as a sample. It may not literally appear in this manual.

Special Information

Special information in this manual is classified as follows:



Precautions for Safe Use

Precautions on what to do and what not to do to ensure safe usage of the product.



Precautions for Correct Use

Precautions on what to do and what not to do to ensure proper operation and performance.



Additional Information

Additional information to read as required.

This information is provided to increase understanding or make operation easier.

Note References are provided to more detailed or related information.

Precaution on Terminology

In this manual, “download” refers to transferring data from the Sysmac Studio to the physical Controller and “upload” refers to transferring data from the physical Controller to the Sysmac Studio.

For the Sysmac Studio, synchronization is used to both upload and download data. Here, “synchronize” means to automatically compare the data for the Sysmac Studio on the computer with the data in the physical Controller and transfer the data in the direction that is specified by the user.

Sections in this Manual

1	Introduction to the Motion Control Function Module	10	Sample Programming	1	10
2	Motion Control Configuration and Principles	11	Troubleshooting	2	11
3	Configuring Axes and Axes Groups	A	Appendices	3	A
4	Checking Wiring from the Sysmac Studio	I	Index	4	I
5	Motion Control Parameters			5	
6	Motion Control Programming			6	
7	Manual Operation			7	
8	Homing			8	
9	Motion Control Functions			9	

CONTENTS

Introduction	1
Relevant Manuals.....	2
Manual Configuration	3
Manual Structure	7
Sections in this Manual.....	9
Read and Understand this Manual	17
Safety Precautions	21
Precautions for Safe Use	22
Precautions for Correct Use	23
Regulations and Standards	24
Unit Versions.....	26
Related Manuals	29
Revision History	31

Section 1 Introduction to the Motion Control Function Module

1-1 Features.....	1-2
1-2 System Configuration	1-3
1-3 Application Procedure	1-4
1-4 Specifications	1-6
1-4-1 General Specifications.....	1-6
1-4-2 Performance Specifications	1-6
1-4-3 Function Specifications.....	1-7

Section 2 Motion Control Configuration and Principles

2-1 Internal Configuration of the CPU Unit.....	2-2
2-2 Motion Control Configuration.....	2-3
2-3 Motion Control Principles	2-4
2-3-1 CPU Unit Tasks.....	2-4
2-3-2 Example of Task Operations for Motion Control	2-7
2-4 EtherCAT Communications and Motion Control	2-11
2-4-1 CAN Application Protocol over EtherCAT (CoE).....	2-11
2-4-2 Relationship between EtherCAT Master Function Module and MC Function Module	2-12
2-4-3 Relationship between Process Data Communications Cycle and Motion Control Period	2-13

Section 3 Configuring Axes and Axes Groups

3-1	Axes	3-2
3-1-1	Introduction to Axes	3-2
3-1-2	Introduction to Axis Parameters	3-3
3-1-3	Introduction to Axis Variables	3-5
3-1-4	Specifying an Axis in the User Program	3-7
3-2	Axis Setting Procedure	3-8
3-2-1	Axis Configuration Procedure	3-8
3-2-2	Setting Procedure	3-8
3-3	Axes Groups	3-17
3-3-1	Introduction to Axes Groups	3-17
3-3-2	Introduction to Axes Group Parameters	3-18
3-3-3	Introduction to Axes Group Variables	3-19
3-3-4	Specifying an Axes Group in the User Program	3-21
3-4	Setting Procedures for Axes Groups	3-22
3-4-1	Setting Procedure for an Axes Group	3-22
3-4-2	Setting Procedure	3-22

Section 4 Checking Wiring from the Sysmac Studio

4-1	Functions of the Sysmac Studio	4-2
4-1-1	MC Test Run Function	4-2
4-1-2	Application Procedure	4-4
4-1-3	Axis Parameter Setting Example	4-5
4-1-4	Starting the MC Test Run Function	4-6
4-2	Monitoring Sensor Signals	4-7
4-3	Checking Motor Operation	4-8
4-3-1	Turning ON the Servo	4-8
4-3-2	Jogging	4-8
4-3-3	Homing	4-9
4-3-4	Absolute Positioning	4-10
4-3-5	Relative Positioning	4-11

Section 5 Motion Control Parameters

5-1	Introduction	5-2
5-2	Axis Parameters	5-4
5-2-1	Axis Parameters	5-4
5-2-2	Axis Basic Settings	5-5
5-2-3	Unit Conversion Settings	5-8
5-2-4	Operation Settings	5-11
5-2-5	Other Operation Settings	5-12
5-2-6	Limit Settings	5-13
5-2-7	Position Count Settings	5-13
5-2-8	Servo Drive Settings	5-15
5-2-9	Homing Settings	5-16
5-2-10	Axis Parameter Setting Example	5-17
5-3	Axes Group Parameters	5-20
5-3-1	Axes Group Parameters	5-20
5-3-2	Axes Group Basic Settings	5-21
5-3-3	Axes Group Operation Settings	5-22
5-3-4	Enabling an Axes Group	5-23

Section 6 Motion Control Programming

6-1	Introduction	6-2
6-2	Motion Control Instructions	6-3
6-2-1	Function Blocks for PLCopen Motion Control.....	6-3
6-2-2	Motion Control Instructions of the MC Function Module.....	6-3
6-3	State Transitions	6-4
6-3-1	Status of the Motion Control Function Module.....	6-4
6-3-2	Axis States.....	6-4
6-3-3	Axes Group States.....	6-6
6-4	Execution and Status of Motion Control Instructions	6-8
6-4-1	Basic Rules for Execution of Instructions	6-8
6-4-2	Execution Timing Charts	6-10
6-4-3	Timing Chart for Re-execution of Motion Control Instructions	6-12
6-4-4	Timing Chart for Multi-execution of Motion Control Instructions	6-13
6-5	Positions	6-14
6-5-1	Types of Positions	6-14
6-5-2	Valid Positions for Each Axis Type	6-14
6-6	System-defined Variables for Motion Control	6-15
6-6-1	Overview of System-defined Variables for Motion Control.....	6-15
6-6-2	System for System-defined Variables for Motion Control	6-17
6-6-3	Tables of System-defined Variables for Motion Control	6-18
6-7	Cam Tables and Cam Data Variables	6-28
6-8	Programming Motion Controls	6-32
6-9	Creating Cam Tables	6-34

Section 7 Manual Operation

7-1	Outline	7-2
7-2	Turning ON the Servo	7-3
7-2-1	Turning ON the Servo	7-3
7-2-2	Setting Axis Parameters	7-4
7-2-3	Programming Example	7-4
7-3	Jogging	7-5
7-3-1	Jogging Procedure.....	7-5
7-3-2	Setting Axis Parameters	7-6
7-3-3	Setting Example for Input Variables.....	7-6
7-3-4	Programming Example	7-7

Section 8 Homing

8-1	Outline	8-2
8-2	Homing Procedure	8-5
8-2-1	Setting Homing Parameters.....	8-5
8-2-2	Monitoring the Homing Operation.....	8-10
8-3	Homing Operation	8-11
8-4	Homing with an Absolute Encoder	8-12
8-4-1	Outline of Function.....	8-13
8-4-2	Setting Procedure	8-13
8-5	High-speed Homing	8-15

Section 9 Motion Control Functions

9-1	Single-axis Position Control	9-3
9-1-1	Outline of Operation	9-3
9-1-2	Absolute Positioning	9-4
9-1-3	Relative Positioning	9-4
9-1-4	Interrupt Feeding	9-5
9-1-5	Stopping	9-6
9-1-6	Override Factors	9-9
9-2	Single-axis Synchronized Control	9-11
9-2-1	Overview of Synchronized Control	9-11
9-2-2	Gear Operation	9-11
9-2-3	Positioning Gear Operation	9-12
9-2-4	Cam Operation	9-13
9-2-5	Cam Tables	9-14
9-2-6	Synchronous Positioning	9-19
9-2-7	Combining Axes	9-21
9-2-8	Master Axis Phase Shift	9-22
9-3	Single-axis Velocity Control	9-23
9-3-1	Velocity Control	9-23
9-3-2	Cyclic Synchronous Velocity Control	9-24
9-4	Single-axis Torque Control	9-25
9-5	Common Functions for Single-axis Control	9-26
9-5-1	Positions	9-26
9-5-2	Velocity	9-28
9-5-3	Acceleration and Deceleration	9-29
9-5-4	Jerk	9-31
9-5-5	Specifying the Operation Direction	9-32
9-5-6	Re-executing Motion Control Instructions	9-35
9-5-7	Multi-execution of Motion Control Instructions (Buffer Mode)	9-41
9-6	Multi-axes Coordinated Control	9-46
9-6-1	Outline of Operation	9-46
9-6-2	Linear Interpolation	9-48
9-6-3	Circular Interpolation	9-49
9-6-4	Stopping Under Multi-axes Coordinated Control	9-50
9-6-5	Overrides for Multi-axes Coordinated Control	9-51
9-7	Common Functions for Multi-axes Coordinated Control	9-53
9-7-1	Velocity Under Multi-axes Coordinated Control	9-53
9-7-2	Acceleration and Deceleration Under Multi-axes Coordinated Control	9-54
9-7-3	Jerk for Multi-axes Coordinated Control	9-55
9-7-4	Re-executing Motion Control Instructions for Multi-axes Coordinated Control	9-56
9-7-5	Multi-execution (Buffer Mode) of Motion Control Instructions for Multi-axes Coordinated Control	9-56
9-8	Other Functions	9-65
9-8-1	Changing the Current Position	9-65
9-8-2	Torque Limit	9-66
9-8-3	Latching	9-66
9-8-4	Zone Monitoring	9-67
9-8-5	Software Limits	9-68
9-8-6	Following Error Monitoring	9-69
9-8-7	Following Error Counter Reset	9-70
9-8-8	Axis Following Error Monitoring	9-70
9-8-9	In-position Check	9-71

Section 10 Sample Programming

10-1	Overview of Sample Programming	10-2
10-1-1	Devices	10-2

10-1-2	Installation and Wiring	10-2
10-1-3	Setup	10-3
10-2	Basic Programming Samples	10-4
10-2-1	Monitoring EtherCAT Communications and Turning ON Servos	10-4
10-2-2	Interlocking Axis Operation with Master Control Instructions	10-6
10-2-3	Error Monitoring and Error Resetting for Single-axis Operation and Synchronized Operation	10-8
10-2-4	Error Monitoring and Error Resetting for Multi-axes Coordinated Operation	10-10
10-2-5	Monitoring for Instruction Errors	10-16
10-2-6	Checking to See If Errors Are Reset.....	10-18
10-2-7	Stopping Axes during Single-axis Operation	10-20
10-2-8	Stopping an Axes Group in Coordinated Motion	10-24
10-2-9	Homing and Absolute Positioning.....	10-30
10-2-10	Changing the Target Position by Re-execution of an Instruction	10-35
10-2-11	Interrupt Feeding	10-41
10-2-12	Changing the Cam Table by Re-execution of an Instruction.....	10-45
10-2-13	Using a Cam Profile Curve to Correct the Sync Start Position	10-54
10-2-14	Shifting the Phase of a Master Axis in Cam Motion.....	10-64
10-2-15	Changing the Actual Position during Velocity Control.....	10-72
10-2-16	Changing a Cam Data Variable and Saving the Cam Table	10-78
10-2-17	Temporarily Changing Axis Parameters.....	10-87
10-2-18	Updating the Cam Table End Point Index	10-90

Section 11 Troubleshooting

11-1	Overview of Errors.....	11-2
11-1-1	How to Check for Errors.....	11-3
11-1-2	Errors Related to the Motion Control Function Module.....	11-5
11-2	Troubleshooting.....	11-10
11-2-1	Error Table	11-10
11-2-2	Error Descriptions.....	11-19
11-2-3	Error Causes and Remedies	11-53

Appendices

A-1	Connecting the Servo Drive.....	A-2
A-1-1	Wiring the Servo Drive.....	A-2
A-1-2	Servo Drive Settings.....	A-2
A-2	Connecting to Encoder Input Terminals	A-11
A-2-1	Wiring to Encoder Input Terminals.....	A-11
A-2-2	Settings for Encoder Input Terminals.....	A-11
A-3	Terminology	A-15
A-3-1	NJ-series Controller.....	A-15
A-3-2	Motion Control	A-16
A-3-3	EtherCAT Communications.....	A-17

Index

Read and Understand this Manual

Please read and understand this manual before using the product. Please consult your OMRON representative if you have any questions or comments.

Warranty and Limitations of Liability

WARRANTY

OMRON's exclusive warranty is that the products are free from defects in materials and workmanship for a period of one year (or other period if specified) from date of sale by OMRON.

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, REGARDING NON-INFRINGEMENT, MERCHANTABILITY, OR FITNESS FOR PARTICULAR PURPOSE OF THE PRODUCTS. ANY BUYER OR USER ACKNOWLEDGES THAT THE BUYER OR USER ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. OMRON DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED.

LIMITATIONS OF LIABILITY

OMRON SHALL NOT BE RESPONSIBLE FOR SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE, OR STRICT LIABILITY.

In no event shall the responsibility of OMRON for any act exceed the individual price of the product on which liability is asserted.

IN NO EVENT SHALL OMRON BE RESPONSIBLE FOR WARRANTY, REPAIR, OR OTHER CLAIMS REGARDING THE PRODUCTS UNLESS OMRON'S ANALYSIS CONFIRMS THAT THE PRODUCTS WERE PROPERLY HANDLED, STORED, INSTALLED, AND MAINTAINED AND NOT SUBJECT TO CONTAMINATION, ABUSE, MISUSE, OR INAPPROPRIATE MODIFICATION OR REPAIR.

Application Considerations

SUITABILITY FOR USE

OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of products in the customer's application or use of the products.

At the customer's request, OMRON will provide applicable third party certification documents identifying ratings and limitations of use that apply to the products. This information by itself is not sufficient for a complete determination of the suitability of the products in combination with the end product, machine, system, or other application or use.

The following are some examples of applications for which particular attention must be given. This is not intended to be an exhaustive list of all possible uses of the products, nor is it intended to imply that the uses listed may be suitable for the products:

- Outdoor use, uses involving potential chemical contamination or electrical interference, or conditions or uses not described in this manual.
- Nuclear energy control systems, combustion systems, railroad systems, aviation systems, medical equipment, amusement machines, vehicles, safety equipment, and installations subject to separate industry or government regulations.
- Systems, machines, and equipment that could present a risk to life or property.

Please know and observe all prohibitions of use applicable to the products.

NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCTS ARE PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

PROGRAMMABLE PRODUCTS

OMRON shall not be responsible for the user's programming of a programmable product, or any consequence thereof.

Disclaimers

CHANGE IN SPECIFICATIONS

Product specifications and accessories may be changed at any time based on improvements and other reasons.

It is our practice to change model numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the products may be changed without any notice. When in doubt, special model numbers may be assigned to fix or establish key specifications for your application on your request. Please consult with your OMRON representative at any time to confirm actual specifications of purchased products.

DIMENSIONS AND WEIGHTS

Dimensions and weights are nominal and are not to be used for manufacturing purposes, even when tolerances are shown.

PERFORMANCE DATA

Performance data given in this manual is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of OMRON's test conditions, and the users must correlate it to actual application requirements. Actual performance is subject to the OMRON Warranty and Limitations of Liability.

ERRORS AND OMISSIONS

The information in this manual has been carefully checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical, or proofreading errors, or omissions.

Safety Precautions

Definition of Precautionary Information

Refer to the following manuals for safety precautions.

- NJ-series CPU Unit Hardware User's Manual (Cat. No. W500)
- NJ-series CPU Unit Software User's Manual (Cat. No. W501)

Precautions for Safe Use

Refer to the following manuals for precautions for safe use.

- NJ-series CPU Unit Hardware User's Manual (Cat. No. W500)
- NJ-series CPU Unit Software User's Manual (Cat. No. W501)

Precautions for Correct Use

Refer to the following manuals for precautions for correct use.

- NJ-series CPU Unit Hardware User's Manual (Cat. No. W500)
- NJ-series CPU Unit Software User's Manual (Cat. No. W501)

Regulations and Standards

Conformance to EC Directives

Applicable Directives

- EMC Directives
- Low Voltage Directive

Concepts

● EMC Directive

OMRON devices that comply with EC Directives also conform to the related EMC standards so that they can be more easily built into other devices or the overall machine. The actual products have been checked for conformity to EMC standards.*

Whether the products conform to the standards in the system used by the customer, however, must be checked by the customer. EMC-related performance of the OMRON devices that comply with EC Directives will vary depending on the configuration, wiring, and other conditions of the equipment or control panel on which the OMRON devices are installed. The customer must, therefore, perform the final check to confirm that devices and the overall machine conform to EMC standards.

* Applicable EMC (Electromagnetic Compatibility) standards are as follows:

EMS (Electromagnetic Susceptibility): EN 61131-2 and EN 61000-6-2

EMI (Electromagnetic Interference): EN 61131-2 and EN 61000-6-4 (Radiated emission: 10-m regulations)

● Low Voltage Directive

Always ensure that devices operating at voltages of 50 to 1,000 VAC and 75 to 1,500 VDC meet the required safety standards. The applicable directive is EN 61131-2.

● Conformance to EC Directives

The NJ-series Controllers comply with EC Directives. To ensure that the machine or device in which the NJ-series Controller is used complies with EC Directives, the Controller must be installed as follows:

- The NJ-series Controller must be installed within a control panel.
- You must use reinforced insulation or double insulation for the DC power supplies connected to DC Power Supply Units and I/O Units.
- NJ-series Controllers that comply with EC Directives also conform to the Common Emission Standard (EN 61000-6-4). Radiated emission characteristics (10-m regulations) may vary depending on the configuration of the control panel used, other devices connected to the control panel, wiring, and other conditions.

You must therefore confirm that the overall machine or equipment complies with EC Directives.

Conformance to Shipbuilding Standards

The NJ-series Controllers comply with the following shipbuilding standards. Applicability to the shipbuilding standards is based on certain usage conditions. It may not be possible to use the product in some locations. Contact your OMRON representative before attempting to use a Controller on a ship.

Usage Conditions for NK and LR Shipbuilding Standards

- The NJ-series Controller must be installed within a control panel.
- Gaps in the door to the control panel must be completely filled or covered with gaskets or other material.
- The following noise filter must be connected to the power supply line.

Noise Filter

Manufacturer	Model
Cosel Co., Ltd.	TAH-06-683

Trademarks

- Sysmac and SYSMAC are trademarks or registered trademarks of OMRON Corporation in Japan and other countries for OMRON factory automation products.
- Windows, Windows 98, Windows XP, Windows Vista, and Windows 7 are registered trademarks of Microsoft Corporation in the USA and other countries.
- EtherCAT® is a registered trademark of Beckhoff Automation GmbH for their patented technology.
- The SD logo is a trademark of SD-3C, LLC. 

Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.

Software Licenses and Copyrights

This product incorporates certain third party software. The license and copyright information associated with this software is available at http://www.fa.omron.co.jp/nj_info_e/.

Unit Versions


Unit Versions

A “unit version” has been introduced to manage CPU Units in the NJ Series according to differences in functionality accompanying Unit upgrades.

Notation of Unit Versions on Products

The unit version is given on the ID information label of the products for which unit versions are managed, as shown below.

Example for NJ-series NJ501-□□□□ CPU Unit:



The following information is provided on the ID information label.

Item	Description
Unit model	Gives the model of the Unit.
Unit version	Gives the unit version of the Unit.
Lot number and serial number	Gives the lot number and serial number of the Unit. DDMY: Lot number, □: For use by OMRON, xxxx: Serial number “M” gives the month (1 to 9: January to September, X: October, Y: November, Z: December)
MAC address	Gives the MAC address of the built-in port on the Unit.

Confirming Unit Versions with Sysmac Studio


You can use the Unit Production Information on the Sysmac Studio to check the unit version of the CPU Unit, CJ-series Special I/O Units, CJ-series CPU Bus Units, and EtherCAT slaves. The unit versions of CJ-series Basic I/O Units cannot be checked from the Sysmac Studio.

● CPU Unit and CJ-series Units

- 1 Double-click **CPU/Expansion Racks** under **Configurations and Setup** in the Multiview Explorer. Or, right-click **CPU/Expansion Racks** under **Configurations and Setup** and select **Edit** from the menu.

The Unit Editor is displayed for the Controller Configurations and Setup layer.

- Right-click any open space in the Unit Editor and select **Production Information**.
The Production Information Dialog Box is displayed.



Simple Display

Detailed Display


In this example, “Ver.1.0” is displayed next to the unit model.

The following items are displayed.

CPU Unit	CJ-series Units
Unit model	Unit model
Unit version	Unit version
Lot number	Lot number
	Rack number, slot number, and unit number

● EtherCAT Slaves

- Double-click **EtherCAT** under **Configurations and Setup** in the Multiview Explorer. Or, right-click **EtherCAT** under **Configurations and Setup** and select **Edit** from the menu.
The EtherCAT Configuration Tab Page is displayed for the Controller Configurations and Setup layer.
- Right-click the master in the EtherCAT Configurations Editing Pane and select **Display Production Information**.
The Production Information Dialog Box is displayed.



The following items are displayed.

- Node address
- Type information*
- Serial number

* If the model number cannot be determined (such as when there is no ESI file), the vendor ID, product code, and revision number are displayed.

Unit Version Notation

In this manual, unit versions are specified as shown in the following table.

Product nameplate	Notation in this manual	Remarks
"Ver.1.0" or later to the right of the lot number	Unit version 1.0 or later	Unless unit versions are specified, the information in this manual applies to all unit versions.

Related Manuals

The following manuals are related to the NJ-series Controllers. Use these manuals for reference.

Manual name	Cat. No.	Model numbers	Application	Description
NJ-series CPU Unit Hardware User's Manual	W500	NJ501-□□□□	Learning the basic specifications of the NJ-series CPU Units, including introductory information, designing, installation, and maintenance. Mainly hardware information is provided.	An introduction to the entire NJ-series system is provided along with the following information on a Controller built with an NJ501 CPU Unit. <ul style="list-style-type: none"> • Features and system configuration • Introduction • Part names and functions • General specifications • Installation and wiring • Maintenance and inspection Use this manual together with the <i>NJ-series CPU Unit Software User's Manual</i> (Cat. No. W501).
NJ-series CPU Unit Software User's Manual	W501	NJ501-□□□□	Learning how to program and set up an NJ-series CPU Unit. Mainly software information is provided.	The following information is provided on a Controller built with an NJ501 CPU Unit. <ul style="list-style-type: none"> • CPU Unit operation • CPU Unit features • Initial settings • Programming based on IEC 61131-3 language specifications Use this manual together with the <i>NJ-series CPU Unit Hardware User's Manual</i> (Cat. No. W500).
NJ-series CPU Unit Motion Control User's Manual	W507	NJ501-□□□□	Learning about motion control settings and programming concepts.	The settings and operation of the CPU Unit and programming concepts for motion control are described. Use this manual together with the <i>NJ-series CPU Unit Hardware User's Manual</i> (Cat. No. W500) and <i>NJ-series CPU Unit Software User's Manual</i> (Cat. No. W501).
NJ-series Instructions Reference Manual	W502	NJ501-□□□□	Learning about the specifications of the instruction set that is provided by OMRON.	The instructions in the instruction set (IEC 61131-3 specifications) are described. When programming, use this manual together with the <i>NJ-series CPU Unit Hardware User's Manual</i> (Cat. No. W500) and <i>NJ-series CPU Unit Software User's Manual</i> (Cat. No. W501).
NJ-series Motion Control Instructions Reference Manual	W508	NJ501-□□□□	Learning about the specifications of the motion control instructions that are provided by OMRON.	The motion control instructions are described. When programming, use this manual together with the <i>NJ-series CPU Unit Hardware User's Manual</i> (Cat. No. W500), <i>NJ-series CPU Unit Software User's Manual</i> (Cat. No. W501) and <i>NJ-series CPU Unit Motion Control User's Manual</i> (Cat. No. W507).
CJ-series Special Unit Manuals for NJ-series CPU Unit	W490 W498 W499 W491 Z310 W492 W494 W497	CJ1W-□□□□	Learning how to use CJ-series Units with an NJ-series CPU Unit.	The methods and precautions for using CJ-series Units with an NJ501 CPU Unit are described, including access methods and programming interfaces. Manuals are available for the following Units. <ul style="list-style-type: none"> Analog I/O Units, Insulated-type Analog I/O Units, Temperature Control Units, ID Sensor Units, High-speed Counter Units, Serial Communications Units, and DeviceNet Units. Use these manuals together with the <i>NJ-series CPU Unit Hardware User's Manual</i> (Cat. No. W500) and <i>NJ-series CPU Unit Software User's Manual</i> (Cat. No. W501).

Manual name	Cat. No.	Model numbers	Application	Description
NJ-series CPU Unit Built-in EtherCAT Port User's Manual	W505	NJ501-□□□□	Using the built-in EtherCAT port on an NJ-series CPU Unit.	Information on the built-in EtherCAT port is provided. This manual provides an introduction and provides information on the configuration, features, and setup. Use this manual together with the <i>NJ-series CPU Unit Hardware User's Manual</i> (Cat. No. W500) and <i>NJ-series CPU Unit Software User's Manual</i> (Cat. No. W501).
NJ-series CPU Unit Built-in EtherNet/IP Port User's Manual	W506	NJ501-□□□□	Using the built-in EtherNet/IP port on an NJ-series CPU Unit.	Information on the built-in EtherNet/IP port is provided. Information is provided on the basic setup, tag data links, and other features. Use this manual together with the <i>NJ-series CPU Unit Hardware User's Manual</i> (Cat. No. W500) and <i>NJ-series CPU Unit Software User's Manual</i> (Cat. No. W501).
NJ-series Troubleshooting Manual	W503	NJ501-□□□□	Learning about the errors that may be detected in an NJ-series Controller.	Concepts on managing errors that may be detected in an NJ-series Controller and information on individual errors are described. Use this manual together with the <i>NJ-series CPU Unit Hardware User's Manual</i> (Cat. No. W500) and <i>NJ-series CPU Unit Software User's Manual</i> (Cat. No. W501).
Sysmac Studio Version 1 Operation Manual	W504	SYSMAC-SE2□□□	Learning about the operating procedures and functions of the Sysmac Studio.	Describes the operating procedures of the Sysmac Studio.
CX-Integrator CS/CJ/CP/NSJ-series Network Configuration Tool Operation Manual	W464		Learning how to configure networks (data links, routing tables, Communications Unit settings, etc.).	Describes operating procedures for the CX-Integrator.
CX-Designer User's Manual	V099		Learning to create screen data for NS-series Programmable Terminals.	Describes operating procedures for the CX-Designer.
CX-Protocol Operation Manual	W344		Creating data transfer protocols for general-purpose devices connected to CJ-series Serial Communications Units.	Describes operating procedures for the CX-Protocol.

Revision History

A manual revision code appears as a suffix to the catalog number on the front and back covers of the manual.

Cat. No. W507-E1-01

↑
Revision code

Revision code	Date	Revised content
01	July 2011	Original production

1

Introduction to the Motion Control Function Module

This section describes the features, system configuration, and application flow for the Motion Control Function Module.

1-1 Features	1-2
1-2 System Configuration	1-3
1-3 Application Procedure	1-4
1-4 Specifications	1-6
1-4-1 General Specifications	1-6
1-4-2 Performance Specifications	1-6
1-4-3 Function Specifications	1-7

1-1 Features

The Motion Control Function Module (sometimes abbreviated to “MC Function Module”) is a software function module that is built into the CPU Unit. The MC Function Module can perform motion control for up to 64 axes through the EtherCAT port that is built into the CPU Unit. Cyclic communications are performed with Servo Drives that are connected to the EtherCAT port to enable high-speed, high-precision machine control.

Motion Control Instructions Based on PLCopen

The motion control instructions of the MC Function Module are based on motion control function blocks that are standardized by PLCopen. These instructions allow you to program single-axis PTP positioning, interpolation control, synchronized control (e.g., of electronic cams), velocity control, and torque control. You can set the velocity, acceleration rate, deceleration rate, and jerk each time a motion control instruction is executed to flexibly control operation according to the application.



Additional Information

- **PLCopen**

PLCopen is an association that promotes IEC 61131-3. It has its headquarters in Europe and a world-wide membership. PLCopen standardizes function blocks for motion control to define a program interface for the languages specified in IEC 61131-3 (JIS B 3503).

- **Jerk**

Jerk is the rate of change in the acceleration rate or deceleration rate. If you specify the jerk, the velocity graph will form an S-curve for acceleration and deceleration.

Data Transmission Using EtherCAT Communications

The MC Function Module can be combined with OMRON G5-series Servo Drives with built-in EtherCAT communications to enable exchange of all control information with high-speed data communications. The various control commands are transmitted via data communications. That means that the Servo-motor's operational performance is maximized without being limited by interface specifications, such as the response frequency of the encoder feedback pulses. You can use the Servo Drive's various control parameters and monitor data on a host controller to unify management of system information.



Additional Information

What Is EtherCAT?

EtherCAT is an open high-speed industrial network system that conforms to Ethernet (IEEE 802.3). Each node achieves a short cycle time by transmitting Ethernet frames at high speed. A mechanism that allows sharing clock information enables high-precision synchronized control with low communications jitter.


1-2 System Configuration

The MC Function Module receives sensor signal status from devices and control panels. It receives commands from the motion control instructions that are executed in the user program. It uses both of these to perform motion control with the Servo Drives and Encoder Input Terminals.

● Motion Control Configuration

The EtherCAT network configuration and Sysmac Studio are used for the MC Function Module.


- EtherCAT Network Configuration
The MC Function Module performs control for Servo Drives and Encoder Input Terminals through the EtherCAT master port that is built into the CPU Unit. The EtherCAT network configuration is used to perform precise motion control in a fixed period with very little deviation.
- Sysmac Studio
The Sysmac Studio is connected to the peripheral USB port on the CPU Unit with a commercially available USB cable. You can also connect it to the built-in EtherNet/IP port on the CPU Unit with Ethernet cable.




1-3 Application Procedure

This section provides the basic procedure to perform motion control with the MC Function Module.

Basic Flow of Operation



* The EtherCAT Network Configuration can be set online if you are connected to the physical network.
The EtherCAT Network Configuration can be selected offline if the hardware is not available yet.



1-4 Specifications

This section gives the specifications of the MC Function Module.

1-4-1 General Specifications

General specifications conform to the general specifications of the CPU Unit.

Refer to the *NJ-series CPU Unit Hardware User's Manual* (Cat. No. W500) for details.

1-4-2 Performance Specifications

Item		Specification		
		NJ501-1300	NJ501-1400	NJ501-1500
Applicable Servo Drives		OMRON G5-series Servo Drives with Built-in EtherCAT Communications*1		
Applicable Encoder Input Terminals		OMRON GX-series GX-EC0211/EC0241 Encoder I/O Terminals*2		
Control method		Control commands using EtherCAT communications		
Control modes		Position control (Cyclic Synchronous Position Control Mode) Velocity control (Cyclic Synchronous Velocity Control Mode) Torque control (Cyclic Synchronous Torque Control Mode)		
Number of controlled axes	Maximum number of controlled axes	16 axes	32 axes	64 axes
	Single-axis control	16 axes max.	32 axes max.	64 axes max.
	Linear interpolation control	4 axes max. per axes group		
	Circular interpolation control	2 axes per axes group		
Number of axes groups		32 axes groups max.		
Unit conversions	Unit of display	Pulses, millimeters, micrometers, nanometers, degrees, or inches		
	Electronic gear ratio	Pulses per motor rotation/travel distance per motor rotation		
Positions that can be administered		Command position and actual position		
Position command values		Negative or positive long reals (LREAL) or 0 (command units*2)		
Velocity command values		Negative or positive long reals (LREAL) or 0 (command units/s)		
Acceleration command values and deceleration command values		Positive long reals (LREAL) or 0 (command units/s ²)		
Jerk command values		Positive long reals (LREAL) or 0 (command units/s ³)		
Override factors		0.00% or 0.01% to 500.00%		
Axis types		Servo axes, virtual servo axes, encoder axes, and virtual encoder axes		
Motion control period		Same as the process data communications cycle for EtherCAT communications		

Item		Specification		
		NJ501-1300	NJ501-1400	NJ501-1500
Cams	Cam data points	65,535 points max. per cam table 1,048,560 points max. total for all cam tables		
	Number of cam tables	640 tables max.		
	Cam profile curves	Created with Cam Editor. Positions (master axis phase and slave axis displacement) can be specified to change phase pitches for each section.		
	Overwriting cam data	Cam data can be overwritten from the user program.		

- *1 The recommended unit version is 2.1 or later.
- *2 The recommended unit version is 1.1 or later.
- *3 Positions can be set to within the range of 40-bit signed integers when they are converted to pulses.

1-4-3 Function Specifications

The following functions are supported when connected to an OMRON G5-series Servo Drive with built-in EtherCAT communications.

Item		Description	
Single axes	Single-axis position control	Absolute positioning	The absolute target position is specified to perform positioning.
		Relative positioning	The travel distance from the command current position is specified to perform positioning.
		Interrupt feeding	Positioning is performed for the specified travel distance from the position where an external device triggers an interrupt input.
Single-axis velocity control	Single-axis velocity control	Velocity control is implemented in Position Control Mode.	
	Cyclic synchronous velocity control	A velocity command is output each control period in Velocity Control Mode.	
Single-axis torque control	Torque control	The torque of the motor is controlled.	
Single-axis synchronized control	Starting cam operation	Cam operation is started using a specified cam table.	
	Ending cam operation	Cam operation is ended for the axis specified with the input parameter.	
	Starting gear operation	The gear ratio between the master axis and the slave axis is specified and gear operation is started.	
	Positioning gear operation	The gear ratio between the master axis and the slave axis and the position to synchronize are specified and gear operation is started.	
	Ending gear operation	The current gear operation or positioning gear operation is stopped.	
	Synchronous positioning	Positioning is performed in sync with the specified master axis.	
	Master axis phase shift	The phase of the master axis currently in synchronized control is shifted.	
	Combining axes	The sum or difference of the command positions of two axes is output as the command position.	
Single-axis manual operation	Powering the Servo	The Servo for the Servo Drive is turned ON to enable operation.	
	Jogging	Jogging is performed according to the specified target velocity.	

Item		Description	
Single axes	Auxiliary functions for single-axis control	Resetting axis errors	Axis errors are cleared.
		Homing	The motor is operated to determine the home using the limit signals, home proximity signal, and home signal.
		High-speed homing	The axis returns to home using an absolute position of 0 as the target position.
		Stopping	The axis is forced to stop.
		Immediate stop	The axis is stopped immediately.
		Setting override factors	The target velocity for an axis is changed.
		Changing the current position	The command current position or the actual current position is changed as required for an axis.
		Enabling external latches	The position of an axis is recorded when a trigger occurs.
		Disabling external latches	The current latch is disabled.
		Zone monitoring	The system determines if the command position or actual current position of an axis is within a specified zone.
		Axis following error monitoring	The following error between the command positions or actual positions of two specified axes is monitored to see if it exceeds the allowed value.
		Following error counter reset	The error between the command current position and the actual current position is set to zero.
		Torque limit	The output torque is limited by enabling and disabling the torque limit function of the Servo Drive and by setting the torque limit value.
Axes groups	Multi-axes coordinated control	Absolute linear interpolation	An absolute position is specified and linear interpolation is performed.
		Relative linear interpolation	A relative position is specified and linear interpolation is performed.
		Circular 2D interpolation	Circular interpolation is performed for two axes.
	Auxiliary functions for multi-axes coordinated control	Resetting axes group errors	Axes group errors and axis errors are cleared.
		Enabling an axes group	An axes group is enabled.
		Disabling an axes group	An axes group is disabled.
		Stopping an axes group	All axes in interpolated movement are decelerated to a stop.
		Immediately stopping an axes group	All axes in interpolated movement are stopped immediately.
		Setting axes group override factors	The blended target velocity is changed during interpolated movement.
Common items	Cams	Setting cam table properties	The end point index of the cam table that is specified in the input parameter is changed.
		Saving cam tables	The cam table that is specified in the input parameter is saved to non-volatile memory in the CPU Unit.
	Parameters	Writing MC settings	Some of the axis parameters or axes group parameters are overwritten temporarily.

Item		Description	
Auxiliary functions	Count Modes	You can select either Linear Mode (finite length) or Rotary Mode (infinite length).	
	Unit conversions	You can set the display unit for each axis according to the machine.	
	Acceleration/deceleration control	Automatic acceleration/deceleration control	The acceleration/deceleration curve is automatically adjusted for an axis motion or axes group motion. You can select a trapezoidal curve or you can set the jerk for an S-curve.
		Changing the acceleration and deceleration rates	You can change the acceleration or deceleration rate even during acceleration or deceleration.
	In-position check	You can set an in-position range and in-position check time to confirm when positioning is completed.	
	Stop Method	You can set the stop method to determine when the immediate stop input signal or limit input signal is valid.	
	Re-execution of motion control instructions	You can change the input variables for a motion control instruction during execution and execute the instruction again to change the target values during operation.	
	Multi-execution of motion control instructions (Buffer Mode)	You can specify when to start execution and how to connect the velocities between operations when another motion control instruction is executed during operation.	
	Continuous axes group motions (Transition Mode)	You can specify the Transition Mode for multi-execution of instructions for axes group operation.	
	Monitoring functions	Software limits	Software limits are set for each axis. You can detect when a range is exceeded during axis motion and when the target position is outside the range when a motion control instruction is executed. You can also set warning values.
		Following error	The following error between the command current value and the actual current value is monitored for each axis and an error is created to stop motion if a set value is exceeded.
		Velocity, acceleration rate, deceleration rate, torque, interpolation velocity, interpolation acceleration rate, and interpolation deceleration rate	You can set warning values for each axis and each axes group.
Absolute encoder support	You can use an OMRON G5-series Servomotor with an Absolute Encoder to eliminate the need to perform homing at startup.		
Backlash compensation	Servo Drive auxiliary functions are used. The compensation method and setting range depend on the specifications of the Servo Drive.		
External interface signals	The following Servo Drive input signals are used. Home signal, home proximity signal, positive limit signal, negative limit signal, immediate stop signal, and interrupt input signal		

2


Motion Control Configuration and Principles

This section outlines the internal structure of the CPU Unit and describes the configuration and principles of the MC Function Module.

2-1	Internal Configuration of the CPU Unit	2-2
2-2	Motion Control Configuration	2-3
2-3	Motion Control Principles	2-4
2-3-1	CPU Unit Tasks	2-4
2-3-2	Example of Task Operations for Motion Control	2-7
2-4	EtherCAT Communications and Motion Control	2-11
2-4-1	CAN Application Protocol over EtherCAT (CoE)	2-11
2-4-2	Relationship between EtherCAT Master Function Module and MC Function Module	2-12
2-4-3	Relationship between Process Data Communications Cycle and Motion Control Period	2-13

2-1 Internal Configuration of the CPU Unit

This section provides an overview of the internal mechanisms of the NJ-series CPU Unit. The CPU Unit has the following software configuration. The Motion Control Function Module is a software module that performs motion control.



* Refer to the *NJ-series CPU Unit Hardware User's Manual* (Cat. No. W500) for details.

The PLC Function Module runs on top of the OS. The other Function Modules run on top of the PLC Function Module. A description of each Function Module is given in the following table.

Function Module name	Abbreviation	Description
PLC Function Module	PLC	This module manages overall scheduling, executes the user program, sends commands to the Motion Control Function Module, and provides interfaces to USB and the SD Memory Card.
Motion Control Function Module	MC	This module performs motion control according to the commands from motion control instructions that are executed in the user program. It sends data to the EtherCAT Master Function Module.
EtherCAT Master Function Module	ECAT	This module communicates with the EtherCAT slaves as the EtherCAT master.


Note Refer to the *NJ-series CPU Unit Hardware User's Manual* (Cat. No. W500) for details on other Function Modules.

This manual provides the specifications and operating procedures for the Motion Control Function Module (sometimes abbreviated to "MC Function Module"). Refer to the other NJ-series user's manuals as required when using the MC Function Module in an application.

2-2 Motion Control Configuration

A control system built with Servo Drives generally controls motor operation with a semi-closed loop. The semi-closed loop uses an encoder attached to the motor to detect the amount of rotation that has been performed by the motor in response to the command value. This is provided as feedback of the machine's travel distance. The following error between the command value and actual motor rotation is calculated and control is performed to bring the following error to zero.

In a machine configuration that uses the MC Function Module, no feedback information is provided for the commands from the user program in the CPU Unit. A feedback system is built into the Servo Drive.



- When motion control instructions are executed in the user program, the MC Function Module interprets the resulting commands.
- The MC Function Module then performs motion control processing at a fixed period based on the results of the command interpretation. It generates command values to send to the Servo Drive. The following command values are generated: target position, target velocity, and target torque.
- The command values are sent by using PDO communications during each process data communications cycle of EtherCAT communications.
- The Servo Drive performs position loop control, velocity loop control, and torque loop control based on the command values received during each process data communications cycle of EtherCAT communications.
- The encoder's current value and the Servo Drive status are sent to the CPU Unit during each process data communications cycle of EtherCAT communications.



Additional Information

- Motion control processing and process data communications in EtherCAT communications are performed during the same time period.
- The MC Function Module controls the Servo Drive, which contains the position control loop, velocity control loop, and torque control loop.

2-3 Motion Control Principles

This section provides information on the CPU Unit tasks and how they relate to motion control.

2-3-1 CPU Unit Tasks

Tasks are attributes of programs that determine the execution conditions and sequence of the programs. The NJ-series CPU Units support the following tasks.

Type of task	Task name
Tasks that execute programs at a fixed period	Primary periodic task
	Periodic tasks (execution priority: 16, 17, and 18)

Refer to the *NJ-series CPU Unit Software User's Manual* (Cat. No. W501) for details on programs, tasks, and setting methods.

Types of Tasks and Task Priority

The NJ-series CPU Unit can execute the user program with a single task or multiple tasks. Tasks have an execution priority. Tasks with the highest execution priority are executed first. If the execution conditions are met for another task with a higher execution priority while a task is under execution, the task with the higher execution priority is given priority in execution. The following table lists the tasks in which you can use motion control instructions and the task priorities for the NJ-series CPU Unit.

Type of task	Number of tasks	Priority	Operation
Primary periodic task	1	4 (fixed)	This task executes I/O refreshing, programs, and motion control in the specified task period. This task has the highest execution priority of all tasks and can be executed quickly and precisely. Therefore, this task is best suited for situations when synchronized control or highly responsive control is required. Use the primary periodic task to execute all control with a single task.
Periodic tasks	0 or 1	16*	These tasks execute programs and I/O refreshing in the specified task period. The execution period for this task is longer than the execution period of the primary periodic task. Therefore, periodic tasks are used to execute programs. For example, synchronized control and control requiring a fast response time are placed in the primary periodic task. Overall device control is placed in a periodic task.

* The CPU Unit has some periodic tasks with an execution priority of 17 or 18. However, you cannot use motion control instructions in these tasks. These tasks also do not perform I/O refreshing.




Precautions for Correct Use

- Motion control instructions can be used in the primary periodic task and in a priority-16 periodic task.
- If motion control instructions are used in any other tasks, an error will occur when the user program is built on the Sysmac Studio.

Basic Operation of Tasks


● Overall Task Operation

The primary periodic task and periodic tasks operate based on the task period of the primary periodic task (also known as the primary period). The primary periodic task includes operations such as system common processing and motion control in addition to I/O refreshing and user program execution. Processing of motion control instructions in the programs is executed during the next motion control (MC) period after the END instruction is executed in the task.



- IO: I/O refreshing
- UPG: User program execution
- MC: Motion control

● Operation of the Primary Periodic Task




Processing	Processing contents
Output data processing	<ul style="list-style-type: none"> • Output refresh data is created for Output Units that execute I/O refreshing. • If forced refreshing is set, the forced refreshing values are reflected in the output refresh data.
Refresh execution	<ul style="list-style-type: none"> • This process exchanges data with I/O.
Input data processing	<ul style="list-style-type: none"> • Input refresh data is loaded from Input Units that execute I/O refreshing. • If forced refreshing is set, the forced refreshing values are reflected in the input refresh data that was read.
System common processing 1	<ul style="list-style-type: none"> • Variable refresh processing (if there are accessing tasks) is performed. • Motion input processing is performed. • Data tracing processing (sampling and trigger checking) is performed.

Processing	Processing contents
User program execution	<ul style="list-style-type: none"> Programs assigned to tasks are executed in the order that they are assigned.
Motion control	<ul style="list-style-type: none"> The motion control commands from the motion control instructions in the programs are executed. Motion output processing is performed.
System common processing 2	<ul style="list-style-type: none"> Variable refresh processing (if there are refreshing tasks) is performed. Variable access processing is performed.

● **Operation of a Periodic Task with an Execution Priority of 16**

You can refresh I/O in the priority-16 periodic task.



* The CPU Unit will temporarily interrupt the execution of a task in order to execute a task with a higher execution priority.

Task Period

The primary period, which is the task period for the primary periodic task, is the standard period for execution. The primary period is automatically used as the motion control period. (It is also the same as the process data communications cycle for EtherCAT communications.) Periodic task execution is synchronized with the primary period. Set the task period of a periodic task as an integer multiple of the primary period. For example, if the primary period is 1 ms, then you can set the task period of a priority-16 periodic task to 4 ms. In that case, the start of the period for the primary periodic task and the periodic task will match once every four primary periods. The following table lists the possible combinations of primary periodic task and periodic task periods.


Primary period	Valid task periods for periodic tasks
500 μs	1 ms, 2 ms, 3 ms, 4 ms, 5 ms, 8 ms, 10 ms, 15 ms, 20 ms, 25 ms, 30 ms, 40 ms, 50 ms, 60 ms, 75 ms, or 100 ms
1 ms	1 ms, 2 ms, 3 ms, 4 ms, 5 ms, 8 ms, 10 ms, 15 ms, 20 ms, 25 ms, 30 ms, 40 ms, 50 ms, 60 ms, 75 ms, or 100 ms
2 ms	2 ms, 4 ms, 8 ms, 10 ms, 20 ms, 30 ms, 40 ms, 50 ms, 60 ms, or 100 ms
4 ms	4 ms, 8 ms, 20 ms, 40 ms, 60 ms, or 100 ms

2-3-2 Example of Task Operations for Motion Control

Motion control instructions can be used in the primary periodic task or in a priority-16 periodic task. This section provides examples of task operations.

Using Motion Control Instructions in the Primary Periodic Task

If high-speed motion control is required, place the motion control instructions (FB) in the primary periodic task.



1 Loading Data

The input data from the EtherCAT slaves (slave A) is loaded during the I/O refresh (IO).

2 Instruction Execution

The motion control instructions (FB) are executed based on the data that was loaded during user program execution (UPG).

The output variables of the motion control instructions are refreshed at this point.

3 Command Generation

Motion processing according to the motion control instructions (FB) that were executed is performed during motion control (MC) immediately after user program execution in the primary periodic task. During this processing, execution commands for the Servo Drives are generated.

4 Sending Commands

The execution commands that were generated are sent to the Servo Drive during the I/O refresh (IO) in the next period.



Additional Information



All instructions from inputs to execution command outputs to the Servo Drive are processed quickly in this task. We recommend placing all motion control instructions in the primary periodic task.

Using Motion Control Instructions in a Priority-16 Periodic Task

If high speed motion control is not required and/or your user program is too large, place motion control instructions in a priority-16 periodic task.

● Timing of Processing

Motion control processing (MC) for the motion control instructions (FB) that are executed in the same task period as the priority-16 periodic task are performed at the same time. Therefore, processing for multiple axes can be simultaneously executed or stopped.



1 Loading Data

The input data from the EtherCAT slaves (slave A) is loaded during the I/O refresh (IO).

2 Instruction Execution

The motion control instructions (FB) are executed based on the data that was loaded during user program execution (UPG) in the priority-16 periodic task.

The output variables of the motion control instructions are refreshed at this point.

3 Command Generation

Motion control instructions (FB) are executed in the task period of the priority-16 periodic task according to the motion control instructions (FB) that were executed. Motion processing is performed during motion control processing (MC) in the next primary periodic task after the periodic task. During this processing, execution commands for the Servo Drives are generated.

4 Sending Commands


The execution commands that were generated are sent to the Servo Drive during the I/O refresh (IO) in the next period.

● Axis Variable Update Timing

Axis Variables are system-defined variables for some of the axis parameters and for the monitor information, such as the actual position and error information for the axes controlled by the MC Function Module.

If you access an Axis Variable during the priority-16 periodic task, the values of the variable that were read at the start of the periodic task are used.

Also, the values of an Axis Variable are not written when a motion control instruction (FB) is executed. They are written in motion control processing (MC) at the start of the next periodic task.



*1 The values of an Axis Variable are read at the start of user program execution for the periodic task.

*2 The values of an Axis Variable are not written when a motion control instruction (FB) is executed in the periodic task.

*3 The values are written during this motion control processing (MC).



Precautions for Correct Use

- When motion control instructions are placed in a periodic task, the response time of the Servo Drive will increase if the task period of the periodic task is lengthened.
- Make sure that all axes can be stopped safely for emergency stops, including emergency stops commanded from external devices.
- The execution timing of motion control instructions in a priority-16 periodic task is not the same as the execution timing for I/O control. Design the user program to allow for this.



Additional Information

For information on Axis Variables, refer to 3-1-3 Introduction to Axis Variables.


Using Motion Control Instructions in Two Different Types of Tasks

If you have processes that require high-speed motion control and processes that do not require high-speed motion control for the same axis, you can place the motion control instructions (FB) both in the primary periodic task and in a priority-16 periodic task.

If motion control instructions (FB) are executed in both tasks within the period of the priority-16 periodic task, the MC Function Module will perform motion processing for instructions in the primary periodic task first.

For example, the MC_MoveAbsolute instruction is executed in the priority-16 periodic task. Then, the MC_MoveRelative is executed for the same axis in the primary periodic task. The operation for this is shown below.

- The MC Function Module will execute MC_MoveRelative first. MC_MoveAbsolute is executed with multi-execution of instructions.



The values of output variables for a motion control instruction and the values of system-defined variables for motion control will change during the I/O refresh of the task that executed the instruction. Therefore, you may notice different behavior depending on the task if you use motion control instructions for the same axis in different tasks. Make sure that you thoroughly understand the processes of each task before you start to develop your user program.



Precautions for Correct Use

- If you include motion control instructions for the same axis in both the primary periodic task and the priority-16 periodic task, pay close attention to the following when you develop your user program: the execution order of the motion control instructions, the timing of updates for system-defined variables for motion control, and the output timing of command values.
- If you use system-defined variables for motion control for the same axis in multiple tasks, pay close attention to the differences in timing for updating system-defined variables for motion control when you develop your user program.



Additional Information

For information on multi-execution of instructions, refer to *9-5-7 Multi-execution of Motion Control Instructions (Buffer Mode)*.


2-4 EtherCAT Communications and Motion Control

The MC Function Module controls Servo Drive and encoder input slaves through the PDO communications of the EtherCAT Master Function Module in the CPU Unit. This section describes EtherCAT communications and other items related to the MC Function Module.

2-4-1 CAN Application Protocol over EtherCAT (CoE)

The MC Function Module exchanges data with the slaves on EtherCAT using the CAN application protocol over EtherCAT (CoE). With CoE, the parameters and control information held by the slaves are specified according to data specifications of the object dictionary (OD). To communicate the data between the Controller (communications master) and slaves, two methods are used: process data objects (PDOs), which periodically exchange data in realtime, and service data objects (SDOs), which exchange data when required.

The MC Function Module uses PDO communications for commands to refresh I/O data, such as data for Servomotor position control, on a fixed control period. It uses SDO communications for commands to read and write data at specified times, such as for parameter transfers.



2-4-2 Relationship between EtherCAT Master Function Module and MC Function Module

The NJ-series CPU Unit can perform sequence control and motion control through connections to EtherCAT slaves.


● Sequence Control

- I/O ports for configuration slaves are automatically created when you create the EtherCAT Configuration in EtherCAT Edit Tab Page.
- Perform sequence control through instructions other than motion control instructions.

● Motion Control

- I/O ports for configuration slaves are automatically created when you create the EtherCAT Configuration in EtherCAT Edit Tab Page.
- Create Axis Variables in Motion Control Setup View and assign the EtherCAT slaves for which motion control is performed.
- Perform motion control through motion control instructions.

There are two types of EtherCAT slaves that can be assigned to Axis Variables: Servo Drive slaves and encoder input terminal slaves.



Additional Information


- Commands are not sent directly through PDO communications to an EtherCAT slave that is assigned to an Axis Variable for instructions other than motion control instructions. However, the status of such an EtherCAT slave can be accessed indirectly through the Axis Variables.
- You can use SDO communications to read and write the objects of EtherCAT slaves that are assigned to axes variables. However, do not use SDO communications to write objects that are mapped to PDO communications. If you do, the operation of the slaves will depend on slave specifications. For OMRON slaves, SDO communications will result in errors.
- If Servo Drive and encoder input terminal EtherCAT slaves are not assigned to axes variables, you must execute sequence control for them in the same way as for general-purpose EtherCAT slaves.

2-4-3 Relationship between Process Data Communications Cycle and Motion Control Period

The PLC Function Module sends motion control commands to the MC Function Module when motion control instructions are executed in the user program. The MC Function Module then performs motion control processing based on those commands and sends the results of processing as commands to the EtherCAT's Servo Drive.

This type of data exchange is updated as shown in the following processing period.

Primary period = Motion control period = Process data communications cycle for EtherCAT communications



3

Configuring Axes and Axes Groups

This section describes the concept of axes and axes groups, the settings for axes that are required for the MC test run function to operate on the Sysmac Studio, and the instructions for creating and configuring axes and axes groups using the Sysmac Studio.

3-1	Axes	3-2
3-1-1	Introduction to Axes	3-2
3-1-2	Introduction to Axis Parameters	3-3
3-1-3	Introduction to Axis Variables	3-5
3-1-4	Specifying an Axis in the User Program	3-7
3-2	Axis Setting Procedure	3-8
3-2-1	Axis Configuration Procedure	3-8
3-2-2	Setting Procedure	3-8
3-3	Axes Groups	3-17
3-3-1	Introduction to Axes Groups	3-17
3-3-2	Introduction to Axes Group Parameters	3-18
3-3-3	Introduction to Axes Group Variables	3-19
3-3-4	Specifying an Axes Group in the User Program	3-21
3-4	Setting Procedures for Axes Groups	3-22
3-4-1	Setting Procedure for an Axes Group	3-22
3-4-2	Setting Procedure	3-22

3-1 Axes

This section describes the axes that are used in a MC Function Module.

3-1-1 Introduction to Axes

In a motion control system, the targets of motion control are called axes. An axis can be an actual Servo Drive or encoder connected using EtherCAT or it can be a virtual Servo Drive or encoder within the MC Function Module.

The MC Function Module supports the axis types that are given in the following table.

Axis type	Description
Servo axis	These are the axes used by the EtherCAT slave Servo Drives* ¹ . They are assigned to actual Servo Drives. One Servomotor is used as one axis.
Virtual servo axis	These are virtual axes that exist only inside the MC Function Module. They are not used by actual Servo Drives. For example, they are used as master axes for synchronizing control.
Encoder axis	An encoder axis uses an EtherCAT slave encoder input terminal* ² . Encoder axes are assigned to actual encoder input terminals. If one encoder input terminal contains two encoder inputs, the individual encoder inputs will act as one axis.
Virtual encoder axis	These axes are used virtually for encoder operation. A virtual encoder axis is used temporarily in place of an encoder axis when there is no physical encoder.* ³

*¹ The applicable Servo Drives are the OMRON G5-series Servo Drives with Built-in EtherCAT Communications.

*² The applicable Encoder Input Terminals are the OMRON GX-series GX-EC0211/EC0241 Encoder I/O Terminals.

*³ Virtual encoder axes are used in combination with motion control instructions that update the actual position of the virtual encoder axis. Counting cannot be used with versions of the MC Function Module that do not support these instructions.

The following elements are related to the axes of the MC Function Module.

These elements exist for each axis. The NJ501-1300 has axis parameters for 16 axes, the NJ501-1400 has axis parameters for 32 axes, and the NJ501-1500 has axis parameters for 64 axes.

Configuration element	Description	Page
Axis parameters	The axis parameters set the maximum velocity, jogging, homing, and other items for the axes operations controlled by the MC Function Module. Use the Sysmac Studio to set the axis parameters.	3-3
Axis Variables	Axis Variables are system-defined variables for the actual position, error information, and other monitor information for axes controlled by the MC Function Module. Axis Variables are created when you add an axis from the Multiview Explorer of the Sysmac Studio. The names of the Axis Variables (called the Axis Variable names) are set here.	3-5
Specifying axes in the user program	In the user program, motion control is implemented with motion control instructions. Motion control instructions that perform single-axis control are used to create axis commands. To control an axis with axis commands, specify the Axis Variable name of the system-defined variable or the Axis Variable name that was set with the Sysmac Studio for the <i>Axis</i> in-out variable of the instruction.	3-7

3-1-2 Introduction to Axis Parameters

● Axis Parameters

Classification	Parameter name
Axis Basic Settings	Axis Number
	Axis Use
	Axis Type
	Node Address (input devices and output devices)
Unit Conversion Settings	Unit of Display
	Command Pulse Count Per Motor Rotation
	Work Travel Distance Per Motor Rotation
Operation Settings	Maximum Velocity
	Maximum Jog Velocity
	Maximum Acceleration
	Maximum Deceleration
	Acceleration/Deceleration Over
	Operation Selection at Reversing
	Velocity Warning Value
	Acceleration Warning Value
	Deceleration Warning Value
	Positive Torque Warning Value
	Negative Torque Warning Value
	Actual Velocity Filter Time Constant
	In-position Range
	In-position Check Time
Zero Position Range	
Other Operation Settings	Immediate Stop Input Stop Method
	Limit Input Stop Method
	Drive Error Reset Monitoring Time
	Maximum Positive Torque Limit
	Maximum Negative Torque Limit
Limit Settings	Software Limits
	Positive Software Limit
	Negative Software Limit
	Following Error Over Value
	Following Error Warning Value
Position Count Settings	Count Mode
	Modulo Maximum Position Setting Value
	Modulo Minimum Position Setting Value
	Encoder Type
Servo Drive Settings	Modulo Maximum Position Setting Value
	Modulo Minimum Position Setting Value

Classification	Parameter name
Homing Settings	Homing Method
	Home Input Signal
	Homing Start Direction
	Home Input Detection Direction
	Operation Selection at Positive Limit Input
	Operation Selection at Negative Limit Input
	Homing Velocity
	Homing Approach Velocity
	Homing Acceleration
	Homing Deceleration
	Homing Jerk
	Home Input Mask Distance
	Home Offset
	Homing Holding Time
Homing Compensation Value	
Homing Compensation Velocity	

Refer to *5-2 Axis Parameters* for details on axis parameters.

● Settings Required to Use Axes

The following settings must be made to use the axes that are created with the Sysmac Studio.

Classification	Parameter name	Setting	Page
Axis Basic Settings	Axis Number	Axis numbers are automatically set in the order that the axes are created.	5-5
	Axis Use	Select <i>Used axis</i> .	
	Axis Type	Select the type of axis to control.	
	Node Address (input devices and output devices)	Specify the node address of the EtherCAT slave device that is assigned to the axis. The Node Address parameter cannot be selected if the Axis Type parameter is set to use a virtual axis.	

● Required Settings to Perform a Servo Drive Test Run from the Sysmac Studio

Make the following settings to operate an EtherCAT-connected Servo Drive using the MC test run function of the Sysmac Studio.

Classification	Parameter name	Setting	Page
Axis Basic Settings	Axis Number	Axis numbers are set in order from the lowest number.	5-5
	Axis Use	Select <i>Used axis</i> .	
	Axis Type	Select <i>Servo axis</i> .	
	Node Address (input devices and output devices)	Specify the node address of the EtherCAT slave device that is assigned to the axis. The Node Address parameter cannot be selected if the Axis Type parameter is set to use a virtual axis.	

Classification	Parameter name	Setting	Page
Unit Conversion Settings	Unit of Display	Select the display unit (mm, degrees, etc.).	5-8
	Command Pulse Count Per Motor Rotation	Set the number of command pulses per motor rotation according to the encoder resolution.*	
	Work Travel Distance Per Motor Rotation	Set the workpiece travel distance per motor rotation according to the machine specifications.	
Position Count Settings	Count Mode	Set this parameter according to the machine specifications.	5-13
Limit Settings	Software Limits	Set this parameter according to the device specifications.	5-13

* For example, if the encoder resolution is 10,000 pulses/rotation, set 10,000.



Precautions for Correct Use

- Select the appropriate values based on the machine's operating conditions for parameters such as the maximum velocity, maximum acceleration/deceleration, or stop settings when the motor is actually operated.
- OMRON G5-series Servo Drives can be set to specific node addresses by using the rotary switches on the front panels. If the rotary switches are set to 00, the node address will be determined by the settings made in the EtherCAT Editor of the Sysmac Studio. If the rotary switches are set to 00 for all connected Servo Drives, errors will not occur even if the Servo Drive's connection position is changed. Set the node addresses on the rotary switches to assign specific Servo Drives for each machine control.

3-1-3 Introduction to Axis Variables

Axis Variables are system-defined variables for some of the axis parameters and for the monitor information, such as the actual position and error information, for the axes controlled by the MC Function Module. When you create axes with the Sysmac Studio, Axis Variables are registered in the variable table in the order that the axes are created. Axis variables are structures with a data type of `_sAXIS_REF`.

● Axis Variables

Each Axis Variable in the MC Function Module has two variable names: The Axis Variable name in the system-defined variables and the Axis Variable name that is assigned when the axis is added on the Sysmac Studio. The Axis Variable names in the system-defined variables are `_MC_AX[0]` to `_MC_AX[63]`.

When you add axes on the Sysmac Studio, the `MC_Axis000` to `MC_Axis063` are set by default for `_MC_AX[0]` to `_MC_AX[63]`. The numbers are assigned in the order that the axes are added. You can change each of these Axis Variables as required from the Sysmac Studio. You can use either the Axis Variables for the system-defined variables or the Axis Variables that are added on the Sysmac Studio to specify the Axis Variables in the user program.

Axis Variable name in the system-defined variables (AT specification in global variable table)*	Default Axis Variable name when axis is added on the Sysmac Studio	Axis number example
<code>_MC_AX[0]</code>	<code>MC_Axis000</code>	Axis 0
<code>_MC_AX[1]</code>	<code>MC_Axis001</code>	Axis 1
⋮	⋮	⋮
<code>_MC_AX[63]</code>	<code>MC_Axis063</code>	Axis 63

* An error will occur if you change the names in the AT column in the global variable table on the Sysmac Studio.

● Examples of Axis Variable Levels and Changing Axis Variable Names


<code>_MC_AX[0]</code>	Axis Variable
<code>_MC_AX[0].Status</code>	Level that indicates the axis status
<code>_MC_AX[0].Status.Ready</code>	Variable that indicates that the axis is ready for operation
<code>_MC_AX[0].Status.Disabled</code>	Variable that indicates when the axis is disabled
:	
<code>_MC_AX[0].Details</code>	Level that indicates the axis control status
<code>_MC_AX[0].Details.Idle</code>	Variable that indicates when the axis is idle
<code>_MC_AX[0].Details.InPosWaiting</code>	Variable that indicates in-position waiting
:	
<code>_MC_AX[0].Cmd</code>	Level that indicates the axis command values
<code>_MC_AX[0].Cmd.Pos</code>	Variable that indicates the command current position
<code>_MC_AX[0].Cmd.Vel</code>	Variable that indicates the command current velocity
<code>_MC_AX[0].Cmd.AccDec</code>	Variable that indicates the command current acceleration/deceleration rate in the axis monitor
:	
<code>_MC_AX[0].Act</code>	Level that indicates the axis current values
<code>_MC_AX[0].Act.Pos</code>	Variable that indicates the actual current position
<code>_MC_AX[0].Act.Vel</code>	Variable that indicates the actual current velocity
<code>_MC_AX[0].Act.Trq</code>	Variable that indicates the actual current torque
:	
<code>_MC_AX[0].Cfg</code>	Level that indicates the axis basic settings
<code>_MC_AX[0].Cfg.AxNo</code>	Variable that indicates the axis number
<code>_MC_AX[0].Cfg.AxEnable</code>	Variable that indicates when the axis is enabled
<code>_MC_AX[0].Cfg.AxType</code>	Variable that indicates the axis type
:	
<code>_MC_AX[0].Scale.Units</code>	Variable that indicates the display unit
<code>_MC_AX[1]</code>	Axis Variable
:	

Example: If `MC_Axis000` is changed to `MyAxis1`, then either `MyAxis1.Act.Pos` or `_MC_AX[0].Act.Pos` can be used as the variable that indicates the actual current position.

Refer to *Axis Variables* on page 6-19 for details on Axis Variables.

3-1-4 Specifying an Axis in the User Program

In the user program, an Axis Variable name is specified for the in-out variable *Axis* in motion control instructions. In the following example, the Axis Variable name for the axis that was added for the system-defined Axis Variable name of `_MC_AX[0]` has been changed to `MyAxis1` in the Sysmac Studio.



You can also use the `_MC_AX[0]` system-defined variable in place of `MyAxis1`.


Refer to *6-2 Motion Control Instructions* for details on motion control instructions.

Refer to the instruction descriptions in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508) for details on motion control instructions.

3-2 Axis Setting Procedure

This section gives the procedures to set servo axes that are newly created with the Sysmac Studio.

3-2-1 Axis Configuration Procedure




3-2-2 Setting Procedure


This section describes how to set an axis.

Starting the Sysmac Studio

- 1** Start the Sysmac Studio and click the **New Project** Button.
- 2** Set the project properties and click the **Create** Button.



A new project is displayed.




Creating the EtherCAT Network Configuration

There are two methods to create an EtherCAT Network Configuration: online and offline.

● Online Method


- 1 Double-click **EtherCAT** in the Multiview Explorer. The EtherCAT Edit Tab Page is displayed.
- 2 Select **Online** from the Controller Menu. The Sysmac Studio goes online with the Controller.
- 3 Right-click the **Master Icon** in the EtherCAT Tab Page and select **Compare and Merge with Actual Network Configuration** from the menu.




When obtaining the information is completed, the physical slave configuration of the EtherCAT slaves is displayed. Right-click the displayed physical configuration and select **Apply actual network configuration**.

● Offline Method


- 1 Double-click **EtherCAT** in the Multiview Explorer. The EtherCAT Edit Tab Page is displayed.




- 2 Right-click the slave to connect and select **Insert** from the menu.



The slave is inserted on the display.



3 Insert the remaining slaves.




3-2 Axis Setting Procedure

3


3-2-2 Setting Procedure

Adding Axes

- 1 Right-click **Axis Settings** in the Multiview Explorer and select **Axis Settings** from the Add Menu.



An axis is added to the Multiview Explorer. The default name for the new axis is `MC_Axis000`.




- **Copying an Axis**


You can also add an axis by copying the axis settings for an existing axis.

Assigning an Axis


- 1 Right-click an axis in the Multiview Explorer and select **Edit** from the menu.




The Axis Basic Settings are displayed in the Axis Parameter Settings Tab Page.



- 2 Select **Servo axis** in the **Axis type** Box.




- 3** Select the Servo Drive to use in the *Input Device Box*.
This setting allows you to use the EtherCAT slave Servo Drive as an axis.




Setting Axis Parameters

- 1** Click each of the icons in the Axis Parameter Settings Tab Page.
The settings for each icon are displayed on the Axis Parameter Settings Tab Page.



Right-click **Axis Settings** in the Multiview Explorer and select **Axis Setting Table** to enable setting the axes parameters for all axes at the same time.



Precautions for Correct Use

When making operation settings such as the display unit, electronic gear (unit conversion formula), maximum velocity, or maximum acceleration/deceleration, be sure to use appropriate values for the operating conditions of the device.



Additional Information

Changing Axis Variable Names in the User Program

Perform the following two procedures to change Axis Variable names that are already used.


- Change the Axis Variable name in the variable table in the variable declarations.
- Change the Axis Variable name in the user program.

Even if you change the Axis Variable names in the variable table, the Axis Variable names in the user program do not change. An error will occur if you use a variable name that is not declared in the variable table, in the user program. Always change the names in both places.

Downloading to the CPU Unit

Use the Synchronization menu command of the Sysmac Studio to download the project to the CPU Unit.

- 1 Select **Online** from the Controller Menu. The Sysmac Studio goes online with the Controller.
- 2 Select **Synchronization** from the Controller Menu and then click the **Transfer to Controller** Button.



Additional Information

Introduction to Servo Drive Settings

The MC Function Module connects to OMRON G5-series Servo Drives with built-in EtherCAT communications.

Compatible Models

The applicable model numbers are R88D-KN□□□-ECT.

The R88D-KN□□□-ECT-R Servo Drives support only Position Control Mode (Cyclic Synchronous Position Control Mode). Therefore, any functions that use Velocity Control Mode (Cyclic Synchronous Velocity Control Mode) or Torque Control Mode (Cyclic Synchronous Torque Control Mode) cannot be used.

Servo Drive Settings

The MC Function Module uses some of the input signals and functions of the Servo Drives. Servo Drive signal wiring and object setting are required to use the MC Function Module properly. Refer to *A-1 Connecting the Servo Drive* for specific settings.

3-3 Axes Groups

This section describes the axes groups of the MC Function Module.

3-3-1 Introduction to Axes Groups

Use axes groups to perform complex operations on multiple axes, such as linear or circular interpolation. An axes group consists of multiple axes. Use the Sysmac Studio to set Axes Group Variables to enable execution of axes group motion control instructions or to enable access of the status of the axes group. The MC Function Module can handle up to 32 groups. The specifications for axes groups are shown in the following table.

Item	Specification
Number of axes groups	32 groups max.
Number of composition axes	4 axes max. per axes group

The following elements are related to the axes groups of the MC Function Module.

Configuration element	Description	Page
Axes group parameters	The axes group parameters set the maximum interpolation velocity, maximum interpolation acceleration/deceleration, and other items for the axes groups controlled by the MC Function Module. Use the Sysmac Studio to set the axes group parameters.	3-18
Axes Group Variable	Axes Group Variables are system-defined variables that include a portion of the axes group parameters as well as the command interpolation velocity, error information, and other monitor information for the axes groups controlled by the MC Function Module. Axes Group Variables are created when you add an axes group from the Multiview Explorer of the Sysmac Studio. The names of the Axes Group Variables (called the Axes Group Variable names) are set here.	3-19
Specifying axes groups in the user program	In the user program, motion control is implemented with motion control instructions. Motion control instructions that perform multi-axis coordinated control are used to create axes group commands. To control an axes group with axes group commands, specify the axes group variable name of the system-defined variable or the axes group variable name that was set with the Sysmac Studio for the <i>AxesGroup</i> in-out variable of the instruction.	3-21

3-3-2 Introduction to Axes Group Parameters

● Axes Group Parameters

Classification	Parameter name
Axes Group Basic Settings	Axes Group Number
	Axes Group Use
	Composition
	Composition Axes
Axes Group Operation Settings	Maximum Interpolation Velocity
	Maximum Interpolation Acceleration
	Maximum Interpolation Deceleration
	Interpolation Acceleration/Deceleration Over
	Interpolation Velocity Warning Value
	Interpolation Acceleration Warning Value
	Interpolation Deceleration Warning Value
	Axes Group Stop Method
Correction Allowance Ratio	

Refer to *5-3 Axes Group Parameters* for details on axes group parameters.

● Settings Required to Use an Axes Group

The following settings must be made to use the axes groups that are created with the Sysmac Studio.

Classification	Parameter name	Setting	Page
Axes Group Basic Settings	Axes Group Number	Axes group numbers are automatically set in the order that the axes groups are created.	5-21
	Axes Group Use	Select <i>Use</i> .	
	Composition	Select the axis composition to control.	
	Composition Axes	This parameter sets the axes to assign to the axes group.	



Precautions for Correct Use

Set appropriate values for the maximum interpolation velocity, stop method, and other items based on the operating conditions.

3-3-3 Introduction to Axes Group Variables

Axes Group Variables are system-defined variables for the setting information and the monitoring information, such as the actual position and error information, for the axes groups controlled by the MC Function Module. When you create axes groups with the Sysmac Studio, Axes Group Variables are registered in the variable table in the order that the axes groups are created. Axes Group Variables are structures with a data type of `_sGROUP_REF`.

● Axes Group Variable Names

Each Axes Group Variable in the MC Function Module has two variable names: The Axes Group Variable name in the system-defined variables and the Axes Group Variable that is assigned when the axes group is added on the Sysmac Studio. The Axes Group Variable names in the system-defined variables are `_MC_GRP[0]` to `_MC_GRP[31]`.

When you add axes groups on the Sysmac Studio, `MC_Group000` to `MC_Group031` are set by default for `_MC_GRP[0]` to `_MC_GRP[31]`. The numbers are assigned in the order that the axes are added. You can change each of these Axes Group Variable names as required from the Sysmac Studio.

You can use either the Axes Group Variable names for the system-defined variables or the Axes Group Variable names that are set on the Sysmac Studio to specify the Axes Group Variables in the user program.

Axes Group Variable name in the system-defined variables (AT specification in global variable table)*	Default Axes Group Variable name when axes group is added on Sysmac Studio	Axes group number example
<code>_MC_GRP[0]</code>	<code>MC_Group000</code>	Axes group 0
<code>_MC_GRP[1]</code>	<code>MC_Group001</code>	Axes group 1
⋮	⋮	⋮
<code>_MC_GRP[31]</code>	<code>MC_Group031</code>	Axes group 31

* An error will occur if you change the names in the AT column in the global variable table on the Sysmac Studio.

● Examples of Axes Group Variable Levels and Changing Axes Group Variable Names


<code>_MC_GRP[0]</code>	Axes Group Variables
<code>_MC_GRP[0].Status</code>	Level that indicates the axes group status
<code>⋮</code>	
<code>_MC_GRP[0].Cmd</code>	Level that indicates the axes group command values
<code>_MC_GRP[0].Cmd.Vel</code>	Variable that indicates the command interpolation velocity
<code>_MC_GRP[0].Cmd.AccDec</code>	Variable that indicates the command interpolation acceleration/deceleration rate
<code>⋮</code>	
<code>_MC_GRP[0].Cfg</code>	Level that indicates the axes group basic settings
<code>_MC_GRP[0].Cfg.GrNo</code>	Variable that indicates the axes group number
<code>_MC_GRP[0].Cfg.GrEnable</code>	Variable that indicates when the axes group is enabled
<code>_MC_GRP[0].Kinematics</code>	Level that indicates the kinematics transformation settings
<code>_MC_GRP[0].Kinematics.GrType</code>	Variable that indicates the axis composition
<code>_MC_GRP[0].Kinematics.Axis[0]</code>	Variable that indicates the axis A0 composition axis
<code>⋮</code>	
<code>_MC_GRP[0].Kinematics.Axis[3]</code>	Variable that indicates the axis A3 composition axis
<code>_MC_GRP[1]</code>	Axes Group Variable
<code>⋮</code>	

Example: If *MC_Group000* is changed to *MyGroup1*, then either *MyGroup1.Cmd.Vel* or *_MC_GRP[0].Cmd.Vel* can be used as the variable that indicates the command interpolation velocity.

Refer to *Axes Group Variables* on page 6-25 for details on Axes Group Variables.

3-3-4 Specifying an Axes Group in the User Program

In the user program, an axes group variable name is specified for the in-out variable *AxesGroup* in motion control instructions. In the following example, the Axes Group Variable name for the axes group that was added for the system-defined Axes Group Variable name of *_MC_GRP[0]* has been changed to *MyGroup1* in the Sysmac Studio.



You can also use the `_MC_GRP[0]` system-defined variable in place of `MyGroup1`.


Refer to *6-2 Motion Control Instructions* for details on motion control instructions.

Refer to the instruction descriptions in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508) for details on motion control instructions.

3-4 Setting Procedures for Axes Groups

This section gives the procedures to use the Sysmac Studio to set up an axes group. No configuration is required if you are not going to use any axes group command instructions, such as linear interpolation or circular interpolation.

3-4-1 Setting Procedure for an Axes Group




3-4-2 Setting Procedure

This section gives the procedures to use the Sysmac Studio to set up an axes group in a project that already contains the axes.


Starting the Sysmac Studio

- 1 Start the Sysmac Studio and open the project.




Adding an Axes Group

- 1 Right-click **Axes Group Settings** in the Multiview Explorer and select **Axes Group Settings** from the Add Menu.



An axes group is added to the Multiview Explorer. The default name for the new axes group is *MC_Group000*.




- **Copying an Axes Group**


You can also create an axes group by copying an axes group from a project.

Setting Axes Group Parameters


- 1 Right-click an axes group in the Multiview Explorer and select **Edit** from the menu.




The Axes Group Basic Settings are displayed in the Axes Group Parameter Settings Tab Page.




2 Select *Used axes group* in the *Axes group use* Box.




3 Select the composition of the axes group in the *Composition* Box. A 2-axis composition is selected in the following example.



4 Assign the axis to use in the *Logical axes* Box.



- 5 Click the bottom icon. The Axes Group Operation Settings Tab Page is displayed. Set appropriate values for the settings based on the operating conditions of the device.



Additional Information

Changing Axes Group Variable Names in the User Program

Perform the following two procedures to change Axes Group Variable names that are already used.


- Change the Axes Group Variable name in the variable table in the variable declarations.
- Change the Axes Group Variable name in the user program.

Even if you change the Axes Group Variable names in the variable table, the Axes Group Variable names in the user program do not change. An error will occur if you use a variable name that is not declared in the variable table, in the user program. Always change the names in both places.

Downloading to the CPU Unit

Use the Synchronization menu command of the Sysmac Studio to download the project to the CPU Unit.

- 1 Select **Online** from the Controller Menu. The Sysmac Studio goes online with the Controller.
- 2 Select **Synchronization** from the Controller Menu and then click the **Transfer to Controller** Button.



4

Checking Wiring from the Sysmac Studio

This section describes the MC Test Run operations of the Sysmac Studio. You can use the MC Test Run to monitor sensor signals, check Servomotor wiring, and more, all without any programming.

4

4-1	Functions of the Sysmac Studio	4-2
4-1-1	MC Test Run Function	4-2
4-1-2	Application Procedure	4-4
4-1-3	Axis Parameter Setting Example	4-5
4-1-4	Starting the MC Test Run Function	4-6
4-2	Monitoring Sensor Signals	4-7
4-3	Checking Motor Operation	4-8
4-3-1	Turning ON the Servo	4-8
4-3-2	Jogging	4-8
4-3-3	Homing	4-9
4-3-4	Absolute Positioning	4-10
4-3-5	Relative Positioning	4-11

4-1 Functions of the Sysmac Studio

This section describes how to use the MC test run function to check wiring and basic settings. You can use the MC test run function in the Sysmac Studio to check wiring without any programming.

4-1-1 MC Test Run Function

The MC test run operation supports the following functions.

Category	Function	Description	Setting/monitor item
Axis operation	Deceleration stop	A deceleration stop is performed during the MC Test Run.	---
	Servo ON/OFF	The Servo is turned ON and OFF.	---
	Resetting errors	The errors in the MC Function Module are reset.	---
	Jogging	Jogging is performed in the positive or negative direction.	Target Velocity Acceleration/Deceleration
	Absolute positioning	Absolute positioning is performed.*	Target Position Target Velocity Acceleration/Deceleration Jerk
	Relative positioning	Relative positioning is performed.	Travel Distance Target Velocity Acceleration/Deceleration Jerk
	Homing	Homing is performed using the homing parameter settings.	Homing Parameters

Category	Function	Description	Setting/monitor item
Monitoring	Error list	The errors in the MC Function Module are monitored.	MC Common Errors Axis Errors Axes Group Errors
	Axis status	The status of the axes is monitored.	Axis Ready-to-execute Standstill Discrete Motion Continuous Motion Homing Stopping Home Defined In Home Position
	Actual position monitor	The actual position is monitored.	Command and Actual Current Positions
	Actual velocity monitor	The actual velocity is monitored.	Command and Actual Current Velocities
	Servo Drive status	The status of the Servo Drive is monitored.	Servo ON/OFF Servo Ready Main Power
	Input signals	The status of the input signals are monitored.	Positive Limit Input Negative Limit Input Immediate Stop Input Home Proximity Input Home Input External Latch Inputs 1 to 2

* When the Count Mode of the axis is set to Rotary Mode, positioning is performed toward the target position in the positive direction. For details, refer to the MC_MoveAbsolute (Absolute Positioning) instruction in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).


Note This MC Test Run is used for an OMRON G5-series Servo Drive with built-in EtherCAT communications. Do not use it with servo drives from any other manufacturer.

4-1-2 Application Procedure

Before you perform an MC Test Run, check the following two items.

- Are the Sysmac Studio and Controller connected and are they online?
- Is the MC Test Run Mode currently in use from any other copy of the Sysmac Studio?

After you have confirmed these two items, perform the following operations as instructed.



Precautions for Correct Use

- When one of the following operations is performed for a command from the Sysmac Studio, the Servomotor will operate at the set velocity: Servo ON, jogging, relative positioning, absolute positioning, or homing. Always confirm that it is safe for the Servomotor to operate before executing any of these operations.
- When operating the Controller from the Sysmac Studio, always install external emergency circuits so that the Servomotor can be stopped safely whenever necessary. The Sysmac Studio may not be able to send commands under some circumstances, e.g., if an error occurs in the computer.
- Set the EtherCAT communications and establish communications before you attempt to perform operation from the Sysmac Studio.



Additional Information


You can perform the following operations to end the MC test run function at any time.

- Select **MC Test Run – Stop** from the Controller Menu of the Sysmac Studio.
- Right-click the axis in the Multiview Explorer of the Sysmac Studio and select **Stop MC Test Run** from the menu.
- Close the MC Test Run Tab Page on the Sysmac Studio.
- Exit the Sysmac Studio.

Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for specific procedures.

4-1-3 Axis Parameter Setting Example

Set the following axis parameters before you execute the MC Test Run Mode in the Sysmac Studio. The following setting example is for a one-axis device.




Parameter name	Setting
Axis Variable Name	Axis1*1
Axis Number	1*2
Axis Use	Used axis
Axis Type	Servo axis
Node Address (input device)	1*3
Unit of Display	μm
Command Pulse Count Per Motor Rotation	1,048,576*4
Work Travel Distance Per Motor Rotation	10,000*4
Maximum Velocity	500,000*5
Maximum Jog Velocity	50,000*6
Maximum Acceleration	5,000,000*7
Maximum Deceleration	5,000,000*7
Software Limits	Immediate stop for command position
Positive Software Limit	500,000*8
Negative Software Limit	0*8
Count Mode	Linear Mode

- *1 If there is more than one axis, a different variable name is set for each axis.
- *2 If there is more than one axis, a different value is set for each axis.
- *3 Set the same node address as for the Servo Drive.
If there is more than one axis, a different value is set for each axis.
- *4 The position command unit will be 1 μm .
- *5 The maximum velocity will be 3,000 r/min = 30 m/min = 0.5 m/s = 500,000 $\mu\text{m/s}$.
- *6 The maximum jog velocity will be 10% of the maximum velocity, i.e., 0.05 m/s = 50,000 $\mu\text{m/s}$.
- *7 The maximum acceleration and the maximum deceleration will be 5 m/s².
The acceleration time to the maximum velocity (3,000 r/min) will be 0.1 s.
- *8 Set a value that is within the movable range of the device.
The positive software limit is set to 50 cm = 500,000 μm .


4-1-4 Starting the MC Test Run Function

The MC Test Run Mode is started from the Sysmac Studio.


- 1 Start the Sysmac Studio and open a project in which the axis settings are completed.
- 2 Select **Online** from the Controller Menu. The Sysmac Studio goes online with the Controller.
- 3 Select **MC Test Run – Start** from the Controller Menu.



When the following caution dialog box appears, read the message carefully. After you confirm safety, click the **OK** Button.




The MC Test Run Tab Page is displayed.



4-2 Monitoring Sensor Signals

You can use the input signal display to check sensor signal wiring.

- 1 Select the axis to check on the MC Test Run Tab Page.



- 2 Check to see if the signals turn ON and OFF properly on the monitor screen by turning ON and OFF the sensor connected to each input signal.


4-3 Checking Motor Operation

Use the functions of the MC Test Run to check motor operation.

4-3-1 Turning ON the Servo

You can use the **Servo ON** Button to turn the Servo ON and OFF.

- 1 Select the axis for which to turn ON the Servo.





- 2 Click the **Servo ON** Button to turn ON the Servo.
- 3 Click the **Servo OFF** Button to turn OFF the Servo.



Precautions for Correct Use

- When one of the following operations is performed for a command from the Sysmac Studio, the Servomotor will operate at the set velocity: Servo ON, jogging, relative positioning, absolute positioning, or homing. Always confirm that it is safe for the Servomotor to operate before executing any of these operations.
- When you operate the Controller from the Sysmac Studio, always install external emergency circuits so that the Servomotor can be stopped safely whenever necessary. The Sysmac Studio may not be able to send commands under some circumstances, e.g., if an error occurs in the computer.
- Set the EtherCAT communications and establish communications before you attempt to perform operation from the Sysmac Studio.

4-3-2 Jogging

- 1 Select the axis to jog on the Jogging Tab Page of the MC Test Run Tab Page.
- 2 Click the **Servo ON** Button to turn ON the Servo.
- 3 Enter the target velocity, acceleration rate, and deceleration rate, and then press the **Apply** Button.
- 4 Click the  or  Button.


The motor will operate in either the positive or negative direction while one of these buttons is clicked. Check to see if the motor operates in the set direction.

4-3-3 Homing

1 Set the homing parameters in the Homing Settings on the Axis Parameter Settings Tab Page.

2 Click the **Homing** Tab on the MC Test Run Tab Page.

The following dialog box is displayed.



3 Select the axis to home.

4 Click the **Servo ON** Button to turn ON the Servo.

5 Click the **Apply homing parameters** Button.

6 Click the  Button.

Check to see if the homing operation agrees with the settings.





Additional Information

- When you click the **Homing Settings** Button, the Homing Settings are displayed on the Axis Parameter Settings Tab Page. Set the homing parameters.
- If the homing parameters were set in advance, click the **Apply homing parameters** Button to apply those settings.

4-3-4 Absolute Positioning


- 1 Click the **Absolute positioning** Tab on the MC Test Run Tab Page. The following dialog box will appear.




- 2 Select the axis to perform absolute positioning.
- 3 Click the **Servo ON** Button to turn ON the Servo.
- 4 Enter the target position, target velocity, acceleration rate, deceleration rate, and jerk, and then click the **Apply** Button.
- 5 Click the  Button. Absolute positioning will start. Check to see if positioning agrees with the settings.

4-3-5 Relative Positioning

- 1 Click the **Relative positioning** Tab on the MC Test Run Tab Page. The following dialog box will appear.



- 2 Select the axis to perform relative positioning.
- 3 Click the **Servo ON** Button to turn ON the Servo.
- 4 Enter the target travel distance, target velocity, acceleration rate, deceleration rate, and jerk, and then click the **Apply** Button.
- 5 Click the  Button. Relative positioning will start. Check to see if the travel distance agrees with the settings.

5

Motion Control Parameters


This section explains about axis parameters and axes group parameters used for motion control.

5-1	Introduction	5-2
5-2	Axis Parameters	5-4
5-2-1	Axis Parameters	5-4
5-2-2	Axis Basic Settings	5-5
5-2-3	Unit Conversion Settings	5-8
5-2-4	Operation Settings	5-11
5-2-5	Other Operation Settings	5-12
5-2-6	Limit Settings	5-13
5-2-7	Position Count Settings	5-13
5-2-8	Servo Drive Settings	5-15
5-2-9	Homing Settings	5-16
5-2-10	Axis Parameter Setting Example	5-17
5-3	Axes Group Parameters	5-20
5-3-1	Axes Group Parameters	5-20
5-3-2	Axes Group Basic Settings	5-21
5-3-3	Axes Group Operation Settings	5-22
5-3-4	Enabling an Axes Group	5-23

5-1 Introduction

You can use motion control instructions to perform single-axis operations and multi-axis operations on axes groups with the NJ-series CPU Unit's MC Function Module. Axis and axes group parameters are used to set these operations. Axis parameters must be set, but axes group parameters are not required if you do not use multi-axis operations for axes groups.

These parameters are called motion control parameter settings (MC parameter settings).



*1 There are no MC Common Parameter Settings for the current version of the MC Function Module.

*2 Use the Synchronization menu command of the Sysmac Studio to upload and download the project.

● Data Flow for Setting MC Parameters

- Download your MC Parameter Settings to the CPU Unit using the Sysmac Studio to save those settings in the CPU Unit's non-volatile memory.
- Saved settings are applied to the main memory after you download them or when the power is turned ON.
- If there are no problems with the saved settings, the MC Function Module executes control based on the settings in the main memory.
- The settings of some of the parameters can be accessed as system-defined variables for motion control.
- You can upload and download MC parameter settings regardless of the CPU Unit's mode or the status of the MC Function Module.
- When you start the download process, all axes in motion will stop immediately and the Servo will turn OFF.

● Overwriting Parameters with the MC_Write (Write MC Setting) Instruction

- You can use the MC_Write (Write MC Setting) motion control instruction to change the settings of some parameters in the main memory while the user program is running.
- If the specified setting value is outside the allowed range, the output variable *Error* from the instruction changes to TRUE and the parameter setting is not changed.
- Parameter settings become valid in either of the following two situations.
 - The axis or axes group is stopped and you execute an instruction for an axis command or axes group command.
 - You set the Buffer Mode Selection for the instruction to Aborting and execute more than one instruction.

- For details on the MC_Write (Write MC Setting) instruction, refer to the *NJ-series Motion Instructions Reference Manual* (Cat. No. W508).



Precautions for Correct Use

- Changes made using the MC_Write (Write MC Setting) instruction will not be saved to non-volatile memory in the CPU Unit. If you cycle the power supply or download the settings from the Sysmac Studio, the parameter settings in the non-volatile memory are restored. If you need to save settings to the non-volatile memory, use the Sysmac Studio to change the parameter settings and then download those settings to the CPU Unit.
-

The following sections provide details on the parameter settings that you can set from the Sysmac Studio.

5-2 Axis Parameters

The axis parameters set the maximum velocity, jerk, homing, and other items for the axes controlled by the MC Function Module. There are axis parameters for each axis. The NJ501-1300 has axis parameters for 16 axes, the NJ501-1400 has axis parameters for 32 axes, and the NJ501-1500 has axis parameters for 64 axes. The same parameter settings are provided for each axis. This section describes only the parameters for axis 1.

5-2-1 Axis Parameters

Use the Sysmac Studio to set the axis parameters for each axis.

Classification	Parameter name	Temporary changes* ¹	Reading variables* ²	Page
Axis Basic Settings	Axis Number	---	OK	5-5
	Axis Use	---	OK	
	Axis Type	---	OK	
	Node Address (input devices and output devices)	---	OK	
Unit Conversion Settings	Unit of Display	---	OK	5-8
	Command Pulse Count Per Motor Rotation	---	OK	
	Work Travel Distance Per Motor Rotation	---	OK	
Operation Settings	Maximum Velocity	---	---	5-11
	Maximum Jog Velocity	---	---	
	Maximum Acceleration	---	---	
	Maximum Deceleration	---	---	
	Acceleration/Deceleration Over	---	---	
	Operation Selection at Reversing	---	---	
	Velocity Warning Value	OK	---	
	Acceleration Warning Value	OK	---	
	Deceleration Warning Value	OK	---	
	Positive Torque Warning Value	OK	---	
	Negative Torque Warning Value	OK	---	
	In-position Range	---	---	
	In-position Check Time	OK	---	
	Actual Velocity Filter Time Constant	---	---	
	Zero Position Range	---	---	
Other Operation Settings	Immediate Stop Input Stop Method	---	---	5-12
	Limit Input Stop Method	---	---	
	Drive Error Reset Monitoring Time	---	---	
	Maximum Positive Torque Limit	---	---	
	Maximum Negative Torque Limit	---	---	
Limit Settings	Software Limits	OK	---	5-13
	Positive Software Limit	OK	---	
	Negative Software Limit	OK	---	
	Following Error Over Value	OK	---	
	Following Error Warning Value	OK	---	

Classification	Parameter name	Temporary changes ^{*1}	Reading variables ^{*2}	Page
Position Count Settings	Count Mode	---	---	5-13
	Modulo Maximum Position Setting Value	---	---	
	Modulo Minimum Position Setting Value	---	---	
	Encoder Type	---	---	
Servo Drive Settings	Modulo Maximum Position Setting Value	---	---	5-15
	Modulo Minimum Position Setting Value	---	---	
Homing Settings	Homing Method	---	---	5-16
	Home Input Signal	---	---	
	Homing Start Direction	---	---	
	Home Input Detection Direction	---	---	
	Operation Selection at Positive Limit Input	---	---	
	Operation Selection at Negative Limit Input	---	---	
	Homing Velocity	---	---	
	Homing Approach Velocity	---	---	
	Homing Acceleration	---	---	
	Homing Deceleration	---	---	
	Homing Jerk	---	---	
	Home Input Mask Distance	---	---	
	Home Offset	---	---	
	Homing Holding Time	---	---	
Homing Compensation Value	---	---		
Homing Compensation Velocity	---	---		

*1 Indicates whether you can use the MC_Write (Write MC Setting) instruction to temporarily change a parameter.

*2 Indicates whether you can access the parameter with a system-defined variable for motion control in the user program.

Refer to *3-2 Axis Setting Procedure* for details on how to set axis parameters.

For details on the MC_Write (Write MC Setting) instruction, refer to the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Refer to *6-6 System-defined Variables for Motion Control* for information on system-defined variables for motion control.

5-2-2 Axis Basic Settings

The Axis Basic Settings are used to set whether to use the axis. If you use the axis, set the axis type and the node address of the EtherCAT slave device.

Parameter name	Function	Setting range	Default
Axis Number	Set the logical number of the axis. This number is accessed to recognize the axis number when accessing <code>_sAXIS_REF</code> .	---	---
Axis Use	Set whether to enable or disable the axis. An error occurs if you execute a motion control instruction for an undefined axis, but an error will not occur for an unused axis.* 0: Undefined axis 1: Unused axis 2: Used axis	0 to 2	0

Parameter name	Function	Setting range	Default
Axis Type	Set the axis type. I/O wiring is not required for virtual axes. 0: Servo axis 1: Encoder axis 2: Virtual servo axes 3: Virtual encoder axis	0 to 3	0
Node Address (input devices and output devices)	Specify the node address of the EtherCAT slave device that is assigned to the axis. The Node Address parameter cannot be selected if the Axis Type parameter is set to a virtual axis.	0 to 192	0

* *Busy* (Controlling) changes to TRUE if you execute a motion control instruction for an undefined or unused axis. *Busy* changes to FALSE when *Execute* or *Enable* changes to FALSE. You can set axes as unused axes to enable using the same user program for different axis configurations without the need to delete programming for axes that are not used.

Axis Types

The following table describes the different axis types that you can select in the Axis Type parameter.

Axis type	Description
Servo axis	These axes are used by the EtherCAT slave Servo Drives* ¹ . They are assigned to actual Servo Drives. One Servomotor is used as one axis.
Virtual servo axis	These virtual axes exist only inside the MC Function Module. They are not used by actual Servo Drives. For example, they are used as master axes for synchronizing control.
Encoder axis	An encoder axis is used for an EtherCAT slave encoder input terminal* ² . An encoder axis is assigned to an actual encoder input terminal. If one encoder input terminal contains two counters, each counter will act as one axis.
Virtual encoder axis	These virtual axes are used for encoder operation. A virtual encoder axis is used temporarily in place of an encoder axis when there is no physical encoder.* ³

*¹ The applicable Servo Drives are the OMRON G5-series Servo Drives with Built-in EtherCAT Communications.

*² The applicable Encoder Input Terminals are the OMRON GX-series GX-EC0211/EC0241 Encoder I/O Terminals.

*³ Virtual encoder axes are used in combination with motion control instructions that update the actual position of the virtual encoder axis. They cannot be used in place of encoder axes for versions of the MC Function Module that do not support such instructions.

● Virtual Servo Axes

A virtual servo axis does not have a physical encoder or external I/O signals. Therefore, virtual servo axes differ from servo axes in the following ways.

- They are always in Servo ON state.
- The actual current position equals the command current position.*
- The actual current velocity equals the command current velocity.*
- External input signals cannot be used.
- If the MC_Home instruction is executed, the instruction is processed as a zero position preset regardless of the setting of the Homing Method axis parameter.

- If a motion control instruction that uses a latch function is executed, you must set the trigger input condition to Controller Mode. An error does not occur if you set it to Drive Mode, but a latch trigger will not occur, so execution of the instruction will not end.
Latches are used by the following instructions: MC_TouchProbe (Enable External Latch), MC_MoveFeed (Interrupt Feeding), MC_MoveLink (Synchronous Positioning), and other instructions.
- Errors do not occur for immediate stop inputs or positive/negative limit inputs because the input signals do not exist.

* However, there is sometimes calculation error because processing is performed with long reals in the MC Function Module.

● **Encoder Axes and Virtual Encoder Axes**

Encoder and virtual encoder axes differ from servo and virtual servo axes in the following ways.

- They do not have command positions. They have only actual positions.
- You cannot use motion-type motion control instructions for them.


Node Addresses (Input Devices and Output Devices)

For a servo or encoder axis, the node address specifies the node address of the EtherCAT slave device that is assigned to the axis. The Node Address parameter cannot be selected if the Axis Type parameter is set to a virtual axis.



Additional Information

- The following example shows the EtherCAT device's node address setting for an OMRON G5-series Servo Drive with built-in EtherCAT communications.



- The rotary switches in the display area on the Servo Drive are used to set the EtherCAT node address.

Rotary switch setting	Node address setting range	
	OMRON slaves	Non-OMRON slaves
00	Value set from the Sysmac Studio (1 to 65,535)	Value set from the Sysmac Studio (1 to 65,535)
01 to 99	Node address switch setting	



Precautions for Correct Use

- OMRON G5-series Servo Drives can be set to specific node addresses by using the node address switches on the front panels. If the node address switches are set to 00, the node address will be determined by the settings made in the EtherCAT Editor of the Sysmac Studio. If the node address switches are set to 00 for all connected Servo Drives, errors will not occur even if the Servo Drive's connection position is changed. Set the node addresses on the node address switches to assign specific Servo Drives for each machine control.

- The value set on the Servo Drive's node address switches is loaded only once when the Servo Drive's control power is turned ON. Such changes are enabled only after the power supply is turned ON again. Do not change the setting on the node address switches after the power supply has been turned ON.
- An error occurs if the same node address is used more than once.
- The value set from the Sysmac Studio will be used for all non-OMRON slaves, regardless of any setting at the slave.

5-2-3 Unit Conversion Settings

These parameters set position units.


Parameter name	Function	Setting range	Default
Unit of Display	Set the unit for command positions. pulse mm μm nm degree inch	0 to 5	0
Command Pulse Count Per Motor Rotation*1	Set the number of pulses per motor rotation for command positions according to the encoder resolution.*2 The command value is converted to a number of pulses based on the electronic gear ratio.	1 to 4,294,967,295	10,000
Work Travel Distance Per Motor Rotation*3	Set the workpiece travel distance per motor rotation for command positions.	0.000000001 to 4,294,967,295	10,000

*1 This is the numerator of the electronic gear ratio (unit conversion formula).

*2 For example, if the encoder resolution is 10,000 pulses/rotation, set 10,000.

*3 This is the denominator of the electronic gear ratio (unit conversion formula).

Positions are generally given in pulses between the MC Function Module and Servo Drives or encoder input terminals. Use a display unit of millimeters or degrees for motion control instructions so that you can easily understand the operation.



You can use the Unit of Display parameter and electronic gear (unit conversion formula) settings to change from a pulse unit to millimeters or degrees.

Unit of Display


You can use the Unit of Display parameter to set the unit to display on the Sysmac Studio. The display shows the position's display unit. The following table describes the units you can set.

Unit	Description
pulse	Use this unit to express values in pulses.
mm	Use this unit for comparatively long-distance direct operation.
μm	Use this unit for precise direct operation.

Unit	Description
nm	Use this unit for more precise direct operation than μm .
degree	Use this unit for rotary tables or other rotating axes.
inch	Use this unit for direct operation.

Electronic Gear Ratio (Unit Conversion Formula)

Use the electronic gear to set the relationship between the display unit and pulse unit in the MC Function Module. Use the Sysmac Studio and set the electronic gear ratio.



Command position value (pulses) = Command position (X units) × Electronic gear ratio

$$\text{Electronic gear ratio} = \frac{\text{Command Pulse Count Per Motor Rotation}^*1 \text{ (Y Pulses)}}{\text{Work Travel Distance Per Motor Rotation}^*2 \text{ (X Units)}}$$

*1 For an encoder axis, this is the number of pulses per encoder rotation.

*2 For an encoder axis, this is the travel distance per encoder rotation.




Additional Information

The electronic gear converts units to the values that are used for positioning by the MC Function Module and motion control instructions. Motion control instructions specify the target position as LREAL data. However, an instruction error will occur if the command position after conversion to pulses by the electronic gear exceeds 40 bits.

● Setting Example

In this example, an OMRON G5-series Servomotor with a 17-bit absolute encoder is used. The reduction ratio of the reducer is 1/5 and the workpiece moves 10 mm for every rotation of the ball screw.



The Unit of Display parameter is set to millimeters. The Command Pulse Count Per Motor Rotation is set to the resolution of the encoder on the Servomotor.

A reducer with a reduction ratio of 1/5 is used, so the ball screw turns 1/5 of a rotation for every Servomotor rotation. The workpiece moves 2 mm (10 mm × 1/5), so the Work Travel Distance Per Motor Rotation is set to 2.

Parameter name	Setting
Unit of Display	mm
Command Pulse Count Per Motor Rotation	131072
Work Travel Distance Per Motor Rotation	2

With these settings, the command unit for positions in the user program is 1 mm.

For example, to move to an absolute position of 100.5 mm, the *Position* (Target Position) input variable to the MC_MoveAbsolute (Absolute Positioning) instruction is set to 100.5.



Additional Information

Parameter Settings for a Reduction Ratio of 1/9 for the Setting Example

The travel distance of the workpiece for one rotation of the Servomotor is $10 \text{ mm} \times 1/9$, or 1.1111... mm (a repeating decimal number).

For numbers that do not divide evenly, multiply the command pulse count per motor rotation and the work travel distance per motor rotation by the same coefficient and set the parameters to the results. Here, the reduction ratio is 1/9, so we use 9 as our coefficient.

- Command Pulse Count Per Motor Rotation: 1,179,648 (131072×9)
- Work Travel Distance Per Motor Rotation: 10 ($10 \times 1/9 \times 9$)

5-2-4 Operation Settings

These parameters set items for axis operation, such as the maximum velocity and maximum acceleration/deceleration rate. Set them according to the specifications of the device you are controlling.

Parameter name	Function	Setting range	Default
Maximum Velocity	Set the maximum velocity for each axis. *1 (Unit: command units/s)	Positive long reals	400,000,000
Maximum Jog Velocity	Set the maximum jog velocity for each axis. *2 (Unit: command units/s)	Positive long reals	1,000,000
Maximum Acceleration	Set the maximum acceleration rate for an axis operation command. There will be no limit to the acceleration rate if 0 is set. (Unit: command units/s ²)	Non-negative long reals	0
Maximum Deceleration	Set the maximum deceleration rate for an axis operation command. There will be no limit to the deceleration rate if 0 is set. (Unit: command units/s ²)	Non-negative long reals	0
Acceleration/Deceleration Over	Set the operation for when the maximum acceleration/deceleration rate would be exceeded after excessive acceleration/deceleration during acceleration/deceleration control of the axis because stopping at the target position is given priority. 0: Use rapid acceleration/deceleration. (Blending is changed to Buffered.) 1: Use rapid acceleration/deceleration. 2: Minor fault stop	0 to 2	0
Operation Selection at Reversing	Specify the operation for reversing rotation for multi-execution of instructions, re-execution of instructions, and interrupt feeding. *3 0: Deceleration stop 1: Immediate stop	0 to 1	0
Velocity Warning Value	Set the percentage of the maximum velocity at which to output a velocity warning for the axis. No velocity warning is output if 0 is set. (Unit: %)	0 to 100	0
Acceleration Warning Value	Set the percentage of the maximum acceleration rate at which to output an acceleration warning for the axis. No acceleration warning is output if 0 is set. (Unit: %)	0 to 100	0

Parameter name	Function	Setting range	Default
Deceleration Warning Value	Set the percentage of the maximum deceleration rate at which to output a deceleration warning for the axis. No deceleration warning is output if 0 is set. (Unit: %)	0 to 100	0
Positive Torque Warning Value	Set the torque command value at which to output a positive torque warning. No positive torque warning is output if 0 is set. (Unit: %)	0 to 1,000	0
Negative Torque Warning Value	Set the torque command value at which to output a negative torque warning. No negative torque warning is output if 0 is set. (Unit: %)	0 to 1,000	0
Actual Velocity Filter Time Constant	Set the time period to calculate the average travel of the actual velocity in milliseconds. The average travel is not calculated if 0 is set. (Unit: ms) Use this to reduce variations in the actual current velocity when axis velocity is slow.	0 to 100	0
In-position Range	Set the in-position width. (Unit: command units)	Non-negative long reals	10
In-position Check Time	Set the in-position check time in milliseconds. Set 0 to check for the end of positioning only when you define the home position during homing and not check positioning at other times. (Unit: ms)	0 to 10,000	0
Zero Position Range	Set the home position detection width. (Unit: command units)	Non-negative long reals	10

- *1 The maximum velocity is used as the command velocity if you specify a velocity command value that is greater than the maximum velocity. This parameter also applies to interpolation control operation.
- *2 The maximum jog velocity is used as the command velocity if you specify a velocity command value that is greater than the maximum jog velocity.
- *3 Refer to 9-5-6 *Re-executing Motion Control Instructions* and 9-5-7 *Multi-execution of Motion Control Instructions (Buffer Mode)* for details on the Operation Selection at Reversing parameter.

5-2-5 Other Operation Settings

These parameters are used to set the stopping methods and torque limits to use when the input signals are enabled.

Parameter name	Function	Setting range	Default
Immediate Stop Input Stop Method	Set the stopping method in the MC Function Module when the immediate stop input is enabled. 0: Immediate stop 2: Immediate stop and error reset 3: Immediate stop and Servo OFF	0, 2, or 3	0
Limit Input Stop Method	Set the stopping method in the MC Function Module when the positive limit input or negative limit input is enabled. 0: Immediate stop 1: Deceleration stop 2: Immediate stop and error reset 3: Immediate stop and Servo OFF	0 to 3	0
Drive Error Reset Monitoring Time	Set the monitor time for a drive error reset. (Unit: ms) After the monitor time has elapsed, reset processing will end even if the drive error is not yet reset.	1 to 1,000	200

Parameter name	Function	Setting range	Default
Maximum Positive Torque Limit	Set the maximum value of the positive torque limit.* (Unit: %)	0.0 to 1000.0	300.0
Maximum Negative Torque Limit	Set the maximum value of the negative torque limit.* (Unit: %)	0.0 to 1000.0	300.0

* If Positive Torque Limit (60E0 hex) and Negative Torque Limit (60E1 hex) are mapped as PDOs, the set values of these parameters are sent with EtherCAT process data communications. If a torque limit is enabled with the MC_SetTorqueLimit instruction, the value that is specified with the input variable to the instruction is sent.

5-2-6 Limit Settings

Use the following parameters to select functions for limiting the following error and for software limits.

Parameter name	Function	Setting range	Default
Software Limits*	Select the software limit function. 0: Disabled. 1: Deceleration stop for command position 2: Immediate stop for command position 3: Deceleration stop for actual position 4: Immediate stop for actual position	0 to 4	0
Positive Software Limit	Set the software limit in the positive direction. (Unit: command units)	Long reals	2,147,483,647
Negative Software Limit	Set the software limit in the negative direction. (Unit: command units)	Long reals	-2,147,483,648
Following Error Over Value	Set the excessive following error check value. Set 0 to disable the excessive following error check. (Unit: command units)	Non-negative long reals	0
Following Error Warning Value	Set the following error warning check value. Set 0 to disable the following error warning check. (Unit: command units)	Non-negative long reals that are less than or equal to the Following Error Over Value	0

* This function is enabled only when the Count Mode is Linear Mode and the home is defined. Refer to 9-8-5 *Software Limits* for details on software limits.

5-2-7 Position Count Settings

Set the count mode for the position.


Parameter name	Function	Setting range	Default
Count Mode	Set the count mode for the position. 0: Linear Mode (finite length) 1: Rotary Mode (infinite length)	0 to 1	0
Modulo Maximum Position Setting Value	Set the modulo maximum position when the Count Mode is set to Rotary Mode. (Unit: command units)	Long reals	2,147,483,647
Modulo Minimum Position Setting Value	Set the modulo minimum position when the Count Mode is set to Rotary Mode. (Unit: command units)	Long reals	-2,147,483,648
Encoder Type	Set the encoder type. 0: Incremental encoder (INC) 1: Absolute encoder (ABS)	0 to 1	0

Count Modes

The Count Mode is the feed mode for the axis. Select the count mode for the command positions for each axis. There are two Count Modes: Linear Mode, which has a finite axis feed range and Rotary Mode, which has an infinite axis feed range.


● Linear Mode (Finite-length Axis)

- The linear mode is centered around 0. This mode is used for devices with a mechanically limited range of motion, such as an XY stage.
- The setting range when the value is converted to pulses is 40 bits (signed integer: 0x8000000000 to 0x7FFFFFFF).¹
- You cannot specify a target position for relative or absolute positioning that exceeds this range.
- A command position overflow or underflow observation will occur if this range is exceeded for operations that do not have a target position, such as velocity control, homing, or torque control. Command position output will continue, but the actual position is not updated and will be fixed to either the upper limit or the lower limit.
- While the value of the actual position is fixed, you can execute commands and stop the axis with any operation that does not have a target position in the direction toward the linear range. Any command that specifies a direction away from the range will cause an error on execution of the instruction.
- The actual position does not update until the overflow or underflow status is cleared.



● Rotary Mode (Infinite Length Axis)

- This mode repeatedly counts with a ring counter for an infinite amount within the set range. Use this mode for rotary tables or winding shafts.
- Use the Sysmac Studio to set the modulo maximum position and the modulo minimum position to define the range of the ring counter.
- The setting range when the value is converted to pulses is 40 bits (signed integer: 0x8000000000 to 0x7FFFFFFF).¹



Modulo Maximum Position and Modulo Minimum Position Setting Values

The settings of these parameters are enabled when the Count Mode is set to Rotary Mode. Set the upper and lower limits of the ring counter.



Precautions for Correct Use

- If you set the Count Mode to Rotary Mode, make sure that the value for only cycle of the ring counter converts to an integer in pulses. If the number of pulses for one cycle of the ring counter is not an integer, position offset occurs because the decimal portion is truncated. The command current position will also not be displayed correctly.
- If 0 is not included between the upper and lower limits of the ring counter, an error occurs when the MC_MoveZeroPosition (High-speed Home) instruction is executed.
- When you perform absolute positioning with a MC_MoveAbsolute or MC_Move instruction, make sure that the target position is within the range of the ring counter. An error occurs if the target position is not within the range of the ring counter. If the *Direction* input variable to the instruction is set to *No direction specified*, you can set a target position that is not within the range of the ring counter. If that occurs, relative positioning is performed using the difference between the target position and the command current position as the target distance.

Encoder Type

Set the type of encoder to use for feedback input. The setting of this parameter is disabled for a virtual axis.

5-2-8 Servo Drive Settings

These parameters set the values for settings on the connected Servo Drive.

Parameter name	Function	Setting range	Default*
Modulo Maximum Position Setting Value	Set the modulo maximum position setting value on the Servo Drive.	-2^{63} to $2^{63}-1$	2,147,483,647
Modulo Minimum Position Setting Value	Set the modulo minimum position setting value on the Servo Drive.	-2^{63} to $2^{63}-1$	-2,147,483,648

* The default range is all DINT integers. You can use the default range with OMRON G5-series Servo Drives.

5-2-9 Homing Settings

Set the motor operation to use to determine home.

Parameter name	Function	Setting range	Default
Homing Method* ¹	Set the homing operation. 0: Proximity reverse turn/home proximity input OFF 1: Proximity reverse turn/home proximity input ON 4: Home proximity input OFF 5: Home proximity input ON 8: Limit input OFF 9: Proximity reverse turn/home input mask distance 11: Limit inputs only 12: Proximity reverse turn/holding time 13: No home proximity input/holding home input 14: Zero position preset	0, 1, 4, 5, 8, 9, or 11 to 14	14
Home Input Signal	Select the input to use for the home input signal. 0: Use Z-phase input as home 1: Use external home input* ²	0 or 1	0
Homing Start Direction	Set the start direction for when homing is started. 0: Positive direction 2: Negative direction	0 or 2	0
Home Input Detection Direction	Set the home input detection direction for homing. 0: Positive direction 2: Negative direction	0 or 2	0
Operation Selection at Positive Limit Input	Set the stopping method when the positive limit input turns ON during homing. 0: No reverse turn/minor fault stop 1: Reverse turn/immediate stop 2: Reverse turn/deceleration stop	0 to 2	1
Operation Selection at Negative Limit Input	Set the stopping method when the negative limit input turns ON during homing. 0: No reverse turn/minor fault stop 1: Reverse turn/immediate stop 2: Reverse turn/deceleration stop	0 to 2	1
Homing Velocity	Set the homing velocity. (Unit: command units/s)	Positive long reals	10,000
Homing Approach Velocity	Set the velocity to use after the home proximity input turns ON. (Unit: command units/s)	Positive long reals	1,000
Homing Acceleration	Set the acceleration rate for homing. Set 0 for no acceleration. (Unit: command units/s ²)	Non-negative long reals	0
Homing Deceleration	Set the deceleration rate for homing. Set 0 for no deceleration. (Unit: command units/s ²)	Non-negative long reals	0
Homing Jerk	Set the jerk for homing. Set 0 for no jerk. (Unit: command units/s ³)	Non-negative long reals	0
Home Input Mask Distance	Set the home input mask distance when you set the Homing Operation Mode to a proximity reverse turn and home input mask distance. (Unit: command units)	Non-negative long reals	10,000
Home Offset	Preset the actual position for the value that is set after homing. (Unit: command units)	Long reals	0
Homing Holding Time	Set the holding time when you set the Homing Operation Mode to a proximity reverse turn and holding time. (Unit: ms)	0 to 10,000	100

Parameter name	Function	Setting range	Default
Homing Compensation Value	Set the homing compensation value that is applied after the home is defined. (Unit: command units)	Long reals	0
Homing Compensation Velocity	Set the velocity to use for homing compensation. (Unit: command units/s).	Positive long reals	1,000

*1 These parameters are for homing operation. Refer to *Section 8 Homing* for details.


*2 This setting can be used for an OMRON G5-series Servo Drive with built-in EtherCAT communications. In the default setting of the OMRON G5-series Servo Drives, the external home input is allocated to latch 1. The allocation of latch 1 can be changed using a servo parameter object in the Servo Drive. Refer to the *OMRON G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications User's Manual* (Cat. No. I576) for details.

5-2-10 Axis Parameter Setting Example

This section provides examples of axis parameter settings related to positioning.

Single-axis Positioning

The following example is for a device that performs single-axis positioning separately for each of two axes.




Parameter name	Settings	
	Axis 1	Axis 2
Axis Variable Names	Axis1	Axis2
Axis Number	1	2
Enabled Axes	Used axis	Used axis
Axis Type	Servo axis	Servo axis
Node Address (input device)	1	2
Unit of Display	μm^*1	μm
Command Pulse Count Per Motor Rotation	1,048,576	1,048,576
Work Travel Distance Per Motor Rotation	10,000	10,000
Maximum Velocity	$500,000^*2$	$500,000^*2$
Maximum Jog Velocity	$50,000^*3$	$50,000^*3$
Maximum Acceleration	$5,000,000^*4$	$5,000,000^*4$
Maximum Deceleration	$5,000,000^*4$	$5,000,000^*4$

Parameter name	Settings	
	Axis 1	Axis 2
Software Limits	Immediate stop for command position	Immediate stop for command position
Positive Software Limit	500,000*5	500,000
Negative Software Limit	0*5	0
Count Mode	Linear Mode	Linear Mode

- *1 The position command unit will be 1 μm .
- *2 The maximum velocity will be 3,000 r/min = 30 m/min = 0.5 m/s = 500,000 $\mu\text{m/s}$.
- *3 The maximum jog velocity will be 10% of the maximum velocity, i.e., 0.05 m/s = 50,000 $\mu\text{m/s}$.
- *4 The maximum acceleration and the maximum deceleration are 5 m/s². The acceleration time to the maximum velocity (3,000 r/min) is 0.1 s.
- *5 Set a positioning that is within the movable range of the device. The positive software limit is set to 50 cm = 500,000 μm .

Synchronized Control with Encoder as Master Axis

The following example is for a device that uses the actual position of axis 2 (an encoder), which is attached to a conveyor, as the master axis. The Servo Drive on axis 1 is synchronized within a finite range.



Parameter name	Settings	
	Axis 1	Axis 2
Axis Variable Name	Axis1	Axis2
Axis Number	1	2
Enabled Axes	Used Axis	Used Axis
Axis Type	Servo axis	Encoder axis
Node Address (input device)	1	2
Unit of Display	μm^1	μm^1
Command Pulse Count Per Motor Rotation	1,048,576	1,048,576
Work Travel Distance Per Motor Rotation	10,000	10,000
Maximum Velocity	500,000*2	---
Maximum Jog Velocity	50,000*3	---
Maximum Acceleration	5,000,000*4	---
Maximum Deceleration	5,000,000*4	---
Software Limits	Immediate stop for command position	Disabled.

Parameter name	Settings	
	Axis 1	Axis 2
Positive Software Limit	500,000* ⁵	---
Negative Software Limit	0* ⁵	---
Count Mode	Linear Mode	Rotary Mode
Modulo Maximum Position	---	1,000,000* ⁶
Modulo Minimum Position	---	0* ⁶

- *1 The position command unit will be 1 μm .
- *2 The maximum velocity will be 3,000 r/min = 30 m/min = 0.5 m/s = 500,000 $\mu\text{m/s}$.
- *3 The maximum jog velocity will be 10% of the maximum velocity, i.e., 0.05 m/s = 50,000 $\mu\text{m/s}$.
- *4 The maximum acceleration and the maximum deceleration are 5 m/s². The acceleration time to the maximum velocity (3,000 r/min) is 0.1 s.
- *5 Set a positioning that is within the movable range of the device. The positive software limit is set to 50 cm = 500,000 μm .
- *6 The periodic range of the position is 0 to 1 m (1,000,000 μm).



Additional Information

You can select the axis type for the master axis according to the configuration of the device. There are four axis types: servo axes, virtual servo axes, encoder axes, and virtual encoder axes. In this example, the axis type of the master axis is an encoder axis. Specify the actual position for the motion control instruction input variable *ReferenceType* (Position Type Selection).

5-3 Axes Group Parameters

Use the axes group parameters to set axes group operations related to axes groups that the MC Function Module controls, such as the axis configuration, maximum interpolation velocity, and axes group stopping method. There are axes group parameters for each of 32 groups for the NJ501-1300, NJ501-1400, or NJ501-1500. The same parameter settings are provided for each axes group. This section describes only the parameters for axes group 1.

5-3-1 Axes Group Parameters

Use the Sysmac Studio to set the axes group parameters for each axes group.

Classification	Parameter name	Temporary changes*1	Reading variables*2	Page
Axes Group Basic Settings	Axes Group Number	---	OK	5-21
	Axes Group Use	---	OK	
	Composition	---	OK	
	Composition Axes	---	OK	
Axes Group Operation Settings	Maximum Interpolation Velocity	---	---	5-22
	Maximum Interpolation Acceleration	---	---	
	Maximum Interpolation Deceleration	---	---	
	Interpolation Acceleration/Deceleration Over	---	---	
	Interpolation Velocity Warning Value	OK	---	
	Interpolation Acceleration Warning Value	OK	---	
	Interpolation Deceleration Warning Value	OK	---	
	Axes Group Stop Method	---	---	
	Correction Allowance Ratio	---	---	

*1 Indicates whether you can use the MC_Write (Write MC Setting) instruction to temporarily change a parameter.

*2 This column indicates whether you can access the parameter with a variable in the user program.

Refer to *3-4 Setting Procedures for Axes Groups* for details on how to set axes group parameters. For details on the MC_Write (Write MC Setting) instruction, refer to the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508). Refer to *6-6 System-defined Variables for Motion Control* for information on system-defined variables for motion control.

5-3-2 Axes Group Basic Settings

Set whether to use the axes group. If you are going to use the axes group, set the axis configuration and the axes to use.

Parameter name	Function	Setting range	Default
Axes Group Use	Set whether to enable or disable the axes group. An error occurs if you execute a motion control instruction for an undefined or unused axes group.* 0: Undefined axes group 1: Unused axes group 2: Used axes group	0 to 2	0
Composition	Set the axis composition of the axes group. 0: 2 axes 1: 3 axes 2: 4 axes	0 to 2	0
Composition Axes	Sets the axis number to assign to the axes group. Set Axis Variable names from the Sysmac Studio to use for the A0 to A3 axes.	2 to 4 axes	0

* An error occurs if you execute the MC_GroupEnable (Enable Axes Group) instruction for an axes group that contains an unused axis.

Composition

The following table lists the axis compositions you can use with the MC Function Module. The default is *group disabled*. Use the Sysmac Studio to set the axis composition according to the actual devices.

Composition	Description
2 axes	A two-axis configuration is used. For example, a machine with a two-axis Cartesian coordinate system is used.
3 axes	A three-axis configuration is used. For example, a machine with a three-axis Cartesian coordinate system is used.
4 axes	A four-axis configuration is used. For example, a machine with a three-axis Cartesian coordinate system is used with a rotary axis at the end tool.

Composition Axes

The axes that are in an axes group are called composition axes. To make it easier to reuse programming with interpolation instructions for axes groups commands, logical axes (axis A0 to axis A3) are used instead of axis numbers (axis 0 to axis 63). For the Composition Axes parameter, set the axis numbers and logical axis numbers for the axes in the axes group. Servo axes or virtual servo axes can be selected for logical axes.

Use the Sysmac Studio to assign axes from axis A0 for the number of axes you selected in the axis composition.

Set axis numbers from axis A0 for each axes group if you create more than one axes group. You can also set the same axis number in more than one axes group.

Axis composition setting	Settings in Composition Axes parameter
2 axes	Set Axis Variable names (axis numbers) for axis A0 and axis A1.
3 axes	Set Axis Variable names (axis numbers) for axis A0, axis A1, and axis A2.
4 axes	Set Axis Variable names (axis numbers) for axis A0, axis A1, axis A2, and axis A3.

● Composition Axes Setting Examples

- Example 1: Assigning Four Axes with Axis Numbers 1, 2, 5, and 8 to an Axes Group

Logical axis	Axis number
Axis A0	Axis 1
Axis A1	Axis 2
Axis A2	Axis 5
Axis A3	Axis 8

- Example 2: Assigning Three Axes with Axis Numbers 1, 8, and 2 to an Axes Group

Logical axis	Axis number
Axis A0	Axis 1
Axis A1	Axis 8
Axis A2	Axis 2
Axis A3	None

5-3-3 Axes Group Operation Settings

These parameters set items for axes group operation, such as the maximum interpolation velocity and axes group stopping method. Set them according to the specifications of the device you are controlling.

Parameter name	Function	Setting range	Default
Maximum Interpolation Velocity	Set the maximum interpolation velocity for the path. Set 0 for no interpolation velocity limit. If a target velocity that exceeds the maximum interpolation velocity is specified for an axes group operation instruction, the axis will move at the maximum interpolation velocity. (Unit: command units/s)	Non-negative long reals	800,000,000
Maximum Interpolation Acceleration	Set the maximum interpolation acceleration for the path. Set 0 for no interpolation acceleration limit. (Unit: command units/s ²)	Non-negative long reals	0
Maximum Interpolation Deceleration	Set the maximum interpolation deceleration for the path. Set 0 for no interpolation deceleration limit. (Unit: command units/s ²)	Non-negative long reals	0
Interpolation Acceleration/Deceleration Over	Set the operation for when the maximum interpolation acceleration/deceleration rate would be exceeded after excessive acceleration/deceleration during acceleration/deceleration control of the axes group because stopping at the target position is given priority. 0: Use rapid acceleration/deceleration. (Blending is changed to Buffered.) 1: Use rapid acceleration/deceleration. 2: Minor fault stop	0 to 2	0
Interpolation Velocity Warning Value	Set the percentage of the maximum interpolation velocity at which to output an interpolation velocity warning. No interpolation velocity warning is output if 0 is set. (Unit: %)	0 to 100	0

Parameter name	Function	Setting range	Default
Interpolation Acceleration Warning Value	Set the percentage of the maximum interpolation acceleration at which to output an interpolation acceleration warning. No interpolation acceleration warning is output if 0 is set. (Unit: %)	0 to 100	0
Interpolation Deceleration Warning Value	Set the percentage of the maximum interpolation deceleration rate at which to output an interpolation deceleration warning. No interpolation deceleration warning is output if 0 is set. (Unit: %)	0 to 100	0
Axes Group Stop Method	Set the stop method of the composition axes for which an error did not occur when an error occurs that forces an immediate stop of an axis that is in a multi-axes coordinated motion. 0: Immediate stop 1: Decelerate axes to a stop at maximum deceleration rate of the axes 3: Immediate stop and Servo OFF	0, 1, or 3	0
Correction Allowance Ratio	This parameter applies when the center designation method is used for a circular interpolation instruction. It compensates the distance when the distance between the start point and the center point does not equal the distance between the end point and the center point. Set the allowable range for that correction as a percentage of the radius. Set the percentage to 0.1% or greater. Error checking is not performed if 0 is set.	Single-precision floating-point number between 0 and 100	0

5-3-4 Enabling an Axes Group

Specify the number of the axes group to enable in the MC_GroupEnable (Enable Axes Group) instruction to enable operation instructions for an axes group in the user program. An instruction error occurs if you execute a motion control instruction for an axes group that is not enabled. You can enable more than one axes group at the same time, but if you enable more than one axes group that include the same axis, an instruction error occurs.

If you want to operate the same axis in different axes groups for each work process, create multiple axes groups that include that axis. You can then use the MC_GroupEnable (Enable Axes Group) and MC_GroupDisable (Disable Axes Group) instructions to enable and disable these axes groups as you need to use them.

If you execute the MC_GroupDisable (Disable Axes Group) instruction during multi-axis operation, the axes in the group will decelerate to a stop.

6

Motion Control Programming


This section provides the specifications of a motion control program and the operation procedures that are required up through actual program development.

6-1	Introduction	6-2
6-2	Motion Control Instructions	6-3
6-2-1	Function Blocks for PLCopen Motion Control	6-3
6-2-2	Motion Control Instructions of the MC Function Module	6-3
6-3	State Transitions	6-4
6-3-1	Status of the Motion Control Function Module	6-4
6-3-2	Axis States	6-4
6-3-3	Axes Group States	6-6
6-4	Execution and Status of Motion Control Instructions	6-8
6-4-1	Basic Rules for Execution of Instructions	6-8
6-4-2	Execution Timing Charts	6-10
6-4-3	Timing Chart for Re-execution of Motion Control Instructions	6-12
6-4-4	Timing Chart for Multi-execution of Motion Control Instructions	6-13
6-5	Positions	6-14
6-5-1	Types of Positions	6-14
6-5-2	Valid Positions for Each Axis Type	6-14
6-6	System-defined Variables for Motion Control	6-15
6-6-1	Overview of System-defined Variables for Motion Control	6-15
6-6-2	System for System-defined Variables for Motion Control	6-17
6-6-3	Tables of System-defined Variables for Motion Control	6-18
6-7	Cam Tables and Cam Data Variables	6-28
6-8	Programming Motion Controls	6-32
6-9	Creating Cam Tables	6-34

6-1 Introduction

The NJ-series CPU Unit can perform both sequence control and motion control. Write motion control instructions into the user program to perform motion control with EtherCAT slave Servo Drives and other devices.

Programs that contain motion control instructions are called motion control programs.



Normally, you must assign Axis Variables to EtherCAT slave Servo Drives. If you do not assign Axis Variables, assign device variables in the same way as for a general-purpose slave. Motion control instructions can be used in the primary periodic task and in a periodic task with an execution priority of 16 (i.e., a priority-16 periodic task).

6-2 Motion Control Instructions

Motion control instructions are used in the user program to execute motion controls for an NJ-series Controller. These instructions are defined as function blocks (FBs). The motion control instructions of the MC Function Module are based on the technical specifications of function blocks for PLCopen motion control. There are two types of motion control instructions: PLCopen-defined instructions and instructions that are unique to the MC Function Module. This section provides an overview of the PLCopen motion control function blocks and gives the specifications of the MC Function Module.

Refer to the *NJ-series CPU Unit Software User's Manual* (Cat. No. W501) for basic information on the NJ-series function blocks (FBs).

6-2-1 Function Blocks for PLCopen Motion Control

PLCopen standardizes motion control function blocks to define a program interface for the languages specified in IEC 61131-3 (JIS B 3503). Single-axis positioning, electronic cams, and multi-axis coordinated control are defined along with basic procedures for executing instructions.

By using PLCopen motion control function blocks, the user program can be more easily reused without hardware dependence. Costs for training and support are also reduced.



Additional Information

PLCopen

PLCopen is an association that promotes IEC 61131-3. It has its headquarters in Europe and a world-wide membership. IEC 61131-3 is an international standard for PLC programming.

- The website of headquarters of PLCopen in Europe is <http://www.plcopen.org/>.

6-2-2 Motion Control Instructions of the MC Function Module

There are three types of motion control instructions. They are given in the following table.

Type	Outline
Common commands	Common instructions for the MC Function Module
Axis commands	Instructions for MC Function Module to perform single-axis control
Axes group commands	Instructions for MC Function Module to perform multi-axis coordinated control

For a list of the instructions that you can use with the MC Function Module, refer to the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

6-3 State Transitions

The states of axes and axes groups and state transitions caused by the execution of instructions are based on the technical specifications of function blocks for PLCopen motion control. This section provides an overall description of the MC Function Module, states, and state transitions.

6-3-1 Status of the Motion Control Function Module

The overall states of the MC Function Module are described in the following table.

State name	Definition
MC Run Mode*1	Motion control instructions are enabled. The motion control instructions in the user program are interpreted and motion control is performed. You can set the MC Run Mode state regardless of the operating mode of the CPU Unit.
MC Test Mode*2	In this state, you can execute a test run from the Sysmac Studio.
Saving Cam Table File*3	This state exists while the system performs save or wait processing for a cam table file.


*1 This state can be monitored with the MC Common Variable `_MC_COM.Status.RunMode`.

*2 This state can be monitored with the MC Common Variable `_MC_COM.Status.TestMode`.

*3 This state can be monitored with the MC Common Variable `_MC_COM.Status.CamTableBusy`.

6-3-2 Axis States

The operation of an axis when motion control instructions are executed for it is shown in the following figure. Motion control instructions are executed in sequence and axes enter one of the states listed in the following table.




- *1 Transition into this state occurs when there is an axis error in any state except for *Coordinated Motion* state.
- *2 Transition into this state occurs when there are no axis errors and the Status output to the MC_Power instruction is FALSE. (The Servo is OFF.)
- *3 Transition into this state occurs if an error is reset with the MC_Reset or ResetMCError instruction when the Servo is OFF.
- *4 Transition into this state occurs if an error is reset with the MC_Reset or ResetMCError instruction when the Servo is ON.
- *5 Transition into this state occurs when the *Enable* input to the MC_Power instruction changes to TRUE and the *Status* (Servo ON) output from the MC_Power instruction changes to TRUE. (The Servo is ON.)
- *6 Transition into this state occurs when the *Done* output from the MC_Stop instruction is TRUE and the *Execute* input to the MC_Stop instruction changes to FALSE.
- *7 Transition into the *Deceleration Stopping* state occurs when the MC_ResetFollowingError instruction is executed.
- *8 The Continuous Motion state exists from when velocity control is set for the *MoveMode* input variable of the MC_MoveFeed instruction until a trigger input is detected.

State name	Definition
Servo OFF	In this state, the Servo is OFF for the axis. When this state is moved to, the buffered status for multi-execution of instructions is cleared.
Axis Disabled	In this state, the Servo is OFF for the axis, the axis is stopped, and execution preparations are completed.
Error Deceleration Stopping	In this state, the Servo is OFF for the axis, the axis is stopped, and an axis error has occurred.
Servo ON	In this state, the Servo is ON for the axis.
Stopped	In this state, the Servo is ON for the axis and the axis is stopped.
Discrete Motion	In this state, positioning is performed for the specified target position. This includes when waiting the in-position status and when the velocity is 0 because the override factor was set to 0 during a discrete motion.
Continuous Motion	In this state, continuous motion control is executed with no specified target position. This state exists during velocity control or torque control. This includes when the velocity is 0 because the target velocity is set to 0 and when the velocity is 0 due to an override factor set to 0 during continuous motion.
Synchronized Motion	In this state, the synchronized control is performed for the axis with synchronized control commands. This includes waiting for synchronization after changing to synchronized control instructions.
Deceleration Stopping	In this state, the axis is stopping due to a MC_Stop or MC_TouchProbe (Enable External Latch) instruction. This includes when <i>Execute</i> is TRUE after stopping for the MC_Stop instruction. In this state, it is not possible to execute axis operation commands. If an attempt is made to execute one, <i>CommandAborted</i> for the instruction changes to TRUE.
Error Deceleration Stopping	In this state, the Servo is ON for the axis and an axis error has occurred. This includes during execution of the MC_ImmediateStop (Immediate Stop) instruction and during a deceleration stop for an axis error. It is not possible to execute axis operation commands in this state. The instruction will enter the aborted (<i>CommandAborted</i> = TRUE) status if executed.
Homing	In this state, home is being searched for by the MC_Home instruction.
Coordinated Motion	In this state, the axis is being controlled by an instruction for an axes group command. In this state, the axis is in motion for an axes group state of <i>Group-Moving</i> , <i>GroupStopping</i> , or <i>GroupErrorStop</i> .

Note Axis status can be monitored in the member variables of the Axis Variables `_MC_AX[0].Status` to `_MC_AX[63].Status`.

6-3-3 Axes Group States

The operation of an axes group when motion control instructions are executed for it is shown in the following figure.



- *1 The *Moving* state is entered for any axes group motion control instruction.
- *2 The *ErrorStop* state is entered from any other state. It is even entered if an error occurs when the axes group is disabled.
- *3 The *Standby* state is entered when the MC_GroupReset or ResetMCError instruction is executed for an enabled axes group.
- *4 The *Disabled* state is entered when the MC_GroupReset or ResetMCError instruction is executed for a disabled axes group.
- *5 The same state is returned to if the MC_GroupDisable is executed in *ErrorStop* state.
- *6 *Stopping* state is entered when the *Done* output variable from the MC_GroupStop instruction is TRUE and the *Execute* input variable to the same instruction is FALSE.
- *7 *Ready* state is entered if all of the following conditions are met in *Standby* state.
 - The Servo is ON for all composition axes.
 - Execution of the MC_Stop instruction is not in progress for any composition axis.
 - Home is defined for all composition axes.

State name	Definition
Axes Group Disabled	The axes group is disabled in this state. When this state is entered, the buffered status for multi-execution of instructions is cleared.
Error Deceleration Stopping	In this state, an error occurred in an axes group that is disabled.
Axes Group Enabled	The axes group is enabled in this state.

State name	Definition
Group Standby	In this state, no instructions for axes group commands are executing. (This is independent of the Servo ON/OFF status of the composition axes in the axes group)
Moving	In this state, positioning is performed for the specified target position due to a motion instruction for an axes group command. This includes during the in-position check and when the velocity is 0 because the override factor was set to 0 while the group was in motion.
Deceleration Stopping	In this state, the MC_GroupStop instruction is executing. This includes when <i>Execute</i> is TRUE after stopping for the MC_GroupStop instruction. In this state, it is not possible to execute a motion for an axes group command. If one is executed, <i>CommandAborted</i> for the instruction will change to TRUE.
Error Deceleration Stopping	In this state, an axes group error has occurred. This includes during execution of the MC_GroupImmediateStop (Axes Group Immediate Stop) instruction and during a deceleration stop for an axes group error. If an attempt is made to execute one of them, <i>CommandAborted</i> for the instruction will change to TRUE.

Note You can monitor the axes group status in the member variables of the Axes Group Variables `_MC_GRP[0].Status` to `_MC_GRP[31].Status`.

6-4 Execution and Status of Motion Control Instructions

Variables that represent the execution status of instructions and variables that are used to execute motion control instructions are defined in the MC Function Module. There are two input variables that you use to execute motion control instruction functions: *Execute* and *Enable*. The following output variables indicate the execution status of an instruction: *Busy*, *Done*, *CommandAborted*, and *Error*.

6-4-1 Basic Rules for Execution of Instructions

The basic rules for the MC Function Module are listed in the following table. You can find execution examples in *6-4-2 Execution Timing Charts*. Refer to these examples as well.

Item	Rule
Exclusiveness of outputs	The following output variables are exclusively controlled and only one of them can be TRUE at the same time: <i>Busy</i> , <i>Done</i> , <i>Error</i> , and <i>CommandAborted</i> . Similarly, only one of the following output variables can be TRUE at the same time: <i>Active</i> , <i>Done</i> , <i>Error</i> , and <i>CommandAborted</i> . <i>Busy</i> and <i>Active</i> may be TRUE at the same time in some cases.
Output status	The output variables <i>Done</i> , <i>InGear</i> (Gear Ratio Achieved), <i>InSync</i> , <i>InVelocity</i> (Target Velocity Reached), and <i>CommandAborted</i> change to FALSE when the input variable <i>Execute</i> changes to FALSE. The actual execution of a motion control instruction is not stopped when <i>Execute</i> changes to FALSE. Even if <i>Execute</i> changes to FALSE before the instruction finishes execution, the corresponding output variable will be TRUE for at least one period if the status of the instruction instance changes. The output variable <i>Error</i> will not reset to FALSE and the output variable <i>ErrorID</i> (Error Code) will not reset to 0 until you execute one of the following instructions: <i>MC_Reset</i> , <i>MC_GroupReset</i> , or <i>ResetMCError</i> . ^{*1} If the <i>Execute</i> variable of the same instruction instance changes to TRUE again (i.e., if the instruction is restarted) during the execution of a motion control instruction, the <i>CommandAborted</i> variable will not change to TRUE.
Input parameters	For motion control instructions that are started with the input variable <i>Execute</i> , the values of the input parameters when <i>Execute</i> changes to TRUE are used. For motion control instructions that start for the input variable <i>Enable</i> , the current values of the input parameters during each period when <i>Enable</i> is TRUE are used.
Omitting input parameters	The default value applies if you omit an input parameter for an instruction instance. ^{*2}
<i>Position</i> (Target Position) and <i>Distance</i> (Travel Distance)	The input variable <i>Position</i> is defined as a value in the coordinate system. The input variable <i>Distance</i> is the relative length, i.e., it is the difference between two positions.
Sign rules	The input variables <i>Acceleration</i> , <i>Deceleration</i> , and <i>Jerk</i> are non-negative values. <i>Position</i> (Target Position), <i>Distance</i> (Travel Distance), and <i>Velocity</i> (Target Velocity) can be positive, negative, or 0.

Item	Rule
Error processing	<p>There are two output variables that represent an error when a problem occurs during the execution of an instruction instance. These outputs are defined as follows:</p> <ul style="list-style-type: none"> • <i>Error</i>: The output variable <i>Error</i> changes to TRUE to indicate that an error occurred during the execution of the instruction instance. • <i>ErrorID</i> (Error Code): This is an error code that represents the cause of the error. <p>The output variables <i>Done</i>, <i>InVelocity</i> (Target Velocity Reached), <i>InGear</i> (Gear Ratio Achieved), and <i>InSync</i> all represent normal completion or normal operation and therefore will never be TRUE when the output variable <i>Error</i> is TRUE.</p> <p>Types of errors:</p> <ul style="list-style-type: none"> • Instruction instance errors (e.g., parameter out of range and illegal condition for state transition) • Axis errors (e.g., Following Error Over Limit and Servo Drive errors) <p>Some instruction instance errors may not cause an axis error but will cause the axis to stop.</p>
Operation of output variable <i>Done</i>	<p>The output variable <i>Done</i>, <i>InGear</i> (Gear Ratio Achieved), or <i>InSync</i> will change to TRUE when the instruction ends operation normally or when the commanded condition is reached. When working with multiple instructions that operate on the same axis, the output variable <i>Done</i> from the first instruction will not change to TRUE if another operation instruction takes over before the axis operation for the first instruction reaches the target position.</p>
Operation of output variable <i>CommandAborted</i>	<p>The output variable <i>CommandAborted</i> will change to TRUE when another operation instruction interrupts the commanded operation. For the MC Function Module, this variable will change to TRUE when a motion control instruction is executed and the target axis or axes group causes an error or is decelerating to a stop. All other output variables change to FALSE when <i>CommandAborted</i> changes to TRUE.</p>
Input variables outside of valid range	<p>The instruction instance will output an error when it is executed with an input variable that is outside of the valid range.</p>
Operation of output variable <i>Busy</i>	<p>The output variable <i>Busy</i> is TRUE when the instruction instance is executing. <i>Busy</i> will change to TRUE when the input variable <i>Execute</i> changes to TRUE. <i>Busy</i> will change to FALSE when the output variable <i>Done</i>, <i>CommandAborted</i>, or <i>Error</i> changes to TRUE. It is impossible to know when the above output variables will change. Write your programs so that the instruction instance executes every period*³ while <i>Busy</i> is TRUE so that you can monitor for changes in the output variables. For a single axis or single axes group, the <i>Busy</i> variable of more than one instruction instance can be TRUE at the same time. However, the output variable <i>Active</i> of only one instruction instance can be TRUE at one time. However, the MC_Phasing (Shift Master Axis Phase) instruction is an exception to this rule.</p>
Output variable <i>Active</i>	<p>The output variable <i>Active</i> changes to TRUE when the instruction instance obtains permission to control the applicable axis.</p> <p>The output variable <i>Active</i> may change slower than the <i>Busy</i> variable.*⁴</p>

*1 Under the PLCopen specifications, *Error* changes to FALSE and *ErrorID* changes to 0 when *Execute* changes to FALSE. When *Error* is TRUE, the motion control instruction is not executed. Instructions are not executed after an error is cleared even if *Execute* is TRUE. *Execute* must change from FALSE to TRUE to execute the instruction. Enable-type motion control instructions are executed if their *Enable* variable is TRUE when an error is reset.

*2 When you program the instruction in a ladder diagram, insert an input between the input variable *Execute* or *Enable* and the left bus bar. If the instruction is connected directly to the left bus bar without an input, an error occurs when the program is built. Set the initial value for or omit any input variable that is reserved.

*3 If the condition expressions or set values for ST Structure instructions do not match, the instructions in that statement are not executed. For details, refer to the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

*4 Refer to the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508) for an output variable timing chart.



Precautions for Correct Use

- Confirm that EtherCAT process data communications are active and normal before you execute motion control instructions.
Refer to *10-2-1 Monitoring EtherCAT Communications and Turning ON Servos* for details.
- Write the user program so that *Execute* is FALSE during the first period in which the instruction is executed.

6-4-2 Execution Timing Charts

The motion control instructions in the MC Function Module are function blocks that are unconditionally executed. This section calls instructions that are executed according to the *Execute* input variable "execute-type instructions" and instructions that are executed according to the *Enable* input variable "enable-type instructions."

Execution condition	Description
<i>Execute</i> variable	These motion control instructions are executed when the input variable <i>Execute</i> to the instruction changes to TRUE. These instructions will continue execution until one of the following status occurs. <ul style="list-style-type: none"> • The specified operation is completed. • Another motion control instruction is executed and interrupts operation. • The instruction is restarted when <i>Execute</i> changes from FALSE to TRUE again. Values for the other input variables are input when <i>Execute</i> changes to TRUE.
<i>Enable</i> variable	These motion control instructions are executed every period while the input variable <i>Enable</i> to the motion control instruction is TRUE. As long as <i>Enable</i> is TRUE, the other input variables are also input every period. However, MC_MoveJog input variables <i>Velocity</i> , <i>Acceleration</i> , and <i>Deceleration</i> are an exception to this rule. The values when <i>PositiveEnable</i> or <i>NegativeEnable</i> changes to TRUE are used for these input variables.




Precautions for Correct Use


The timing in the timing charts that are given in this manual may not necessarily be the same as the timing displayed for data traces on the Sysmac Studio. Refer to the *NJ-series CPU Unit Software User's Manual* (Cat. No. W501) for details on data tracing.

Timing Charts for Execute-type Instructions


- The following timing chart shows the operation of the instruction when it is completed while the input variable *Execute* is TRUE. The following timing chart is for when an error does not occur through when *Execute* changes to FALSE.




- The following timing chart is for when an error occurs while input variable *Execute* is TRUE. After completion, the output variable *Error* will remain TRUE even if *Execute* changes to FALSE.




- The following timing chart is for when the instruction is interrupted during execution while input variable *Execute* is TRUE.



- The following timing chart is for when the input variable *Execute* is TRUE for only one period and an error does not occur for the instruction. The output variable *Done* will change to TRUE for only one period after the instruction operation is completed.




- The following timing chart is for when the input variable *Execute* is TRUE for only one period and an error occurs for the instruction. The output variable *Error* will remain TRUE.




Timing Charts for Enable-type Instructions

- The following timing chart is for when the input variable *Enable* changes to TRUE and an error does not occur for the instruction.



- The following timing chart is for when the input variable *Enable* changes to TRUE and an error occurs for the instruction.




Additional Information

Enable and *Enabled* change at the same time for instructions such as MC_ZoneSwitch (Zone Monitor) and MC_AxesObserve (Monitor Axis Following Error). For details on the timing of individual instructions, refer to the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

6-4-3 Timing Chart for Re-execution of Motion Control Instructions

If the values of the input variables to the same instance are changed while the motion control instruction is under execution and *Execute* is changed to TRUE, FALSE, and then back to TRUE again, operation will follow the new values.

The following timing chart is for when the velocity is changed for MC_MoveAbsolute (Absolute Positioning) instruction.




For details on re-executing instructions for the MC Function Module, refer to 9-5-6 *Re-executing Motion Control Instructions* and 9-7-4 *Re-executing Motion Control Instructions for Multi-axes Coordinated Control*.

6-4-4 Timing Chart for Multi-execution of Motion Control Instructions

Another instance can be executed for an axis during axis motion. Set the input variable *BufferMode* to specify when to start operation.

The following figure shows an example in which *BufferMode* (Buffer Mode Selection) is set to aborting when MC_MoveAbsolute (Absolute Positioning) instructions are executed with multi-execution of instructions.

“FB1” and “FB2” in the following figure are the instance names of the instructions.



For details on multi-execution of instructions for the MC Function Module, refer to 9-5-7 *Multi-execution of Motion Control Instructions (Buffer Mode)* and 9-7-5 *Multi-execution (Buffer Mode) of Motion Control Instructions for Multi-axes Coordinated Control*.

6-5 Positions


This section describes the positions that are used in motion control programming.

6-5-1 Types of Positions

The MC Function Modules uses the following two types of positions.

Type of position	Definition
Command position	This is the position that the MC Function Module outputs to control an axis.
Actual position	The actual position as input from the Servo Drive or encoder input.

The following figure shows the relationship between the command position and the actual position.



The command position and actual position share the following items.

Item	Command position	Actual position
Count Mode	You can set Linear Mode or Rotary Mode.	The same Count Mode is used as for the command position.
Position increment	You can set one of the following: mm, μm , nm, inch, degree, or pulse.	The unit is the same as the unit of the command position.
Software limits	You can set the range of operation of the software.	The range is the same as the range for the command position.
Changing the current position	You can change the actual position to any desired position.	This value will be set to the same position as the command position.*
Defining home	Home is either defined or undefined.	The status of home is the same as the command position.

* If there is any following error before the change, the following error value is maintained in the actual position.

6-5-2 Valid Positions for Each Axis Type

The following table lists the valid positions for each axis type.

Axis type	Types of positions	
	Command position	Actual position
Servo axis	Applicable	Applicable
Virtual servo axis	Applicable	Applicable* ¹
Encoder axis	Cannot be used.	Applicable
Virtual encoder axis	Cannot be used.	Applicable* ²

*¹ For a virtual servo axis, the actual position is the same as the command position. (However, there is sometimes calculation error because processing is performed with long reals in the MC Function Module.)

*² This is used when there is no actual encoder.

6-6 System-defined Variables for Motion Control

This section describes the variables of the MC Function Module.

6-6-1 Overview of System-defined Variables for Motion Control

The NJ-series Controller is compliant with the IEC 61131-3 standard. Parameter settings, status information, and other data are handled as variables in the user program in the NJ-series Controller. Of these, system-defined variables that belong to the MC Function Module are called system-defined variables for motion control.

Types of System-defined Variables for Motion Control

The following table lists all of the types of system-defined variables for motion control.

Level 1	Level 2	Level 3	Description
System-defined variables	System-defined variables for motion control	MC Common Variable	You can monitor the overall status of the MC Function Module.
		Axis Variables	You can monitor axis status and the settings of part of the axis parameters.
		Axes Group Variables	You can monitor axes group status and the settings of part of the axes group parameters.

● MC Common Variable

You can monitor the overall status of the MC Function Module with the MC Common Variable. The variable name is `_MC_COM`.

● Axis Variables

Use these variables to handle EtherCAT slaves, Servo Drives, encoder input terminals, virtual Servo Drives, and virtual encoder input terminals.

You can use either the system-defined variables or the variables that are set on the Sysmac Studio to specify the Axis Variables in the user program.

You can change any of the Axis Variables that you create on the Sysmac Studio.

- Axis Variables in the system-defined variables: `_MC_AX[0]` to `_MC_AX[63]`
- Default Axis Variables when axes are created on Sysmac Studio: `MC_Axis000` to `MC_Axis063`

● Axes Group Variables

Use these variables to handle multiple axes as a single group.

You can use either the system-defined variables or the variables that are set on the Sysmac Studio to specify the Axes Group Variables in the user program.

You can change any of the Axes Group Variables that you create on the Sysmac Studio.

- Axes Group Variables in the system-defined variables: `_MC_GRP[0]` to `_MC_GRP[31]`
- Default Axes Group Variables when axes groups are created on Sysmac Studio: `MC_Group000` to `MC_Group031`

Refer to the *NJ-series CPU Unit Software User's Manual* (Cat. No. W501) for details on the variables that are used by an NJ-series Controller.

Data Types Used for System-defined Variables for Motion Control

System-defined variables for motion control use both basic data types and derivative data types.

● Basic Data Types

Category	Data type	Size	Range of values	Notation
Boolean	BOOL	2*	TRUE or FALSE	TRUE or FALSE
Integer	UINT	2	0 to +65,535	Binary expression: "2#" is added to the front of the number Octal expression: "8#" is added to the front of the number Decimal expression: "10#" is added to the front of the number Hexadecimal expression: "16#" is added to the front of the number If you do not add any notation to the beginning of a number, that number is treated as a decimal number. Example: Binary Notation 2#1111_1111 2#1110_0000 Octal Notation 8#377 8#340 Decimal Notation -12 0 123_456 +986 10#1234 Hexadecimal Notation 16#FF 16#ff 16#E0 16#e0
	UDINT	4	0 to +4,294,967,295	
Floating-point numbers	LREAL	8	-1.79769313486231e+308 to -2.22507385850720e-308, 0, 2.22507385850720e-308 to 1.79769313486231e+308, positive infinity, or negative infinity	Written as (<i>sign</i>) + <i>integer_part</i> + (<i>decimal_point</i>) + (<i>decimal_part</i>) + (<i>exponent</i>). You can omit items in parentheses. Example: 2 -12.0 0.0 0.4560 3.14159_26 -1.34E-12 -1.34e-12 1.0E+6 1.0e+6 1.234E6 1.234e6

* BOOL data is only 1 bit in size but it takes up 2 bytes of memory.

● **Derivative Data Types**

Type	Description
Enumerated data types	This data type uses one item from a prepared name list as its value. Variables with this data type start with “_e.”
Structure data type	This data type consists of multiple data types placed together into a single layered structure. Variables with this data type start with “_s.”

Refer to the *NJ-series CPU Unit Software User's Manual* (Cat. No. W501) for details on the other data types that are used by an NJ-series Controller.

Attributes of System-defined Variables for Motion Control

The attributes that are shown in the following table are the same for all system-defined variables for motion control.

Attribute	Attribute of system-defined variables for motion control
Global/Local	Global variable
R/W access	Read only
Retain	Non-retain
Network Publish	Publish*


* Variables are published on the network with the variable names of the system-defined variables. The variable names that are created when the axes or axes groups are created on the Sysmac Studio are not published to the network.

6-6-2 System for System-defined Variables for Motion Control

System-defined variables for motion control consist of information representing the status of the MC Function Module, status information for slave devices connected via EtherCAT communications, and the portion of the MC parameter settings used to perform motion control.

You can access system-defined variables for motion control as variables in the user program and monitor them from the Sysmac Studio.

System-defined variables for motion control are updated every primary period.



6-6-3 Tables of System-defined Variables for Motion Control

This section provides tables that describe the system-defined variables for motion control.

MC Common Variable

The variable name `_MC_COM` is used for the MC Common Variable. The data type is `_sCOMMON_REF`, which is a structure variable. This section describes the configuration of the MC Common Variable and provides details on the members.

Variable name	Data type	Meaning	Function
<code>_MC_COM</code>	<code>_sCOMMON_REF</code>	MC Common Variable	
Status	<code>_sCOMMON_REF_STA</code>	MC Common Status	
RunMode	BOOL	MC Run	TRUE during MC Function Module operation.
TestMode	BOOL	MC Test Run	TRUE during test mode operation from the Sysmac Studio.
CamTableBusy	BOOL	Cam Table Busy	TRUE while the Cam Table is being saved or on standby.
PFaultLvl	<code>_sMC_REF_EVENT</code>	MC Common Partial Fault	
Active	BOOL	MC Common Partial Fault Occurrence	TRUE while there is an MC common partial fault.
Code	WORD	MC Common Partial Fault Code	Contains the code for an MC common partial fault. The upper four digits of the event code have the same value.
MFaultLvl	<code>_sMC_REF_EVENT</code>	MC Common Minor Fault	
Active	BOOL	MC Common Minor Fault Occurrence	TRUE while there is an MC common minor fault.
Code	WORD	MC Common Minor Fault Code	Contains the code for an MC common minor fault. The upper four digits of the event code have the same value.
Obsr	<code>_sMC_REF_EVENT</code>	MC Common Observation	
Active	BOOL	MC Common Observation Occurrence	TRUE while there is an MC common observation.
Code	WORD	MC Common Observation Code	Contains the code for an MC common observation. The upper four digits of the event code have the same value.

Axis Variables

`_MC_AX[0]` to `_MC_AX[63]` are the Axis Variables in the system-defined variables. The data type is `_sAXIS_REF`, which is a structure variable. This section describes the configuration of the Axis Variables and provides details on the members.

Variable name	Data type	Meaning	Function
<code>_MC_AX[0-63]</code>	<code>_sAXIS_REF</code>	Axis Variable	
Status	<code>_sAXIS_REF_STA</code>	Axis Status	
Ready	BOOL	Axis Ready-to-execute	TRUE when preparations for axis execution are finished and the axis is stopped. This variable indicates the same status as when <code>_MC_AX[XX].Status.Standstill</code> is TRUE (stopped).
Disabled	BOOL	Axis Disabled	TRUE while the Servo is OFF for the axis. The following axis states are mutually exclusive. Only one can be TRUE at the same time. <i>Disabled, Standstill, Discrete, Continuous, Synchronized, Homing, Stopping, ErrorStop, or Coordinated</i>
Standstill	BOOL	Stopped	TRUE while the Servo is OFF for the axis.
Discrete	BOOL	Discrete Motion	TRUE while position control is executed toward the target position. This includes when the velocity is 0 because the override factor was set to 0 during a discrete motion.
Continuous	BOOL	Continuous Motion	TRUE during continuous motion without a target position. This state exists during velocity control or torque control. This includes when the velocity is 0 because the target velocity is set to 0 and when the velocity is 0 due to an override factor set to 0 during continuous motion.
Synchronized	BOOL	Synchronized Motion	TRUE during execution of synchronized control. This includes waiting for synchronization after changing to synchronized control instructions.
Homing	BOOL	Homing	TRUE when homing for the <code>MC_Home</code> instruction.
Stopping	BOOL	Deceleration Stopping	TRUE until the axis stops for a <code>MC_Stop</code> or <code>MC_TouchProbe</code> instruction. This includes when <i>Execute</i> is TRUE after the axis stops for an <code>MC_Stop</code> instruction. Axis motion instructions are not executed while decelerating to a stop. (<i>CommandAborted</i> is TRUE.)
ErrorStop	BOOL	Error Deceleration Stopping	This status exists when the axis is stopping or stopped for execution of the <code>MC_ImmediateStop</code> instruction or a minor fault (while <code>_MC_AX[XX].MFAultLvl.Active</code> is TRUE (Axis Minor Fault Occurrence). Axis motion instructions are not executed in this state. (<i>CommandAborted</i> is TRUE.)
Coordinated	BOOL	Coordinated Motion	TRUE when an axes group is enabled by a multi-axis coordinated control instruction.

Variable name	Data type	Meaning	Function
Details	_sAXIS_REF_DET	Axis Control Status	Gives the control status of the command.
Idle	BOOL	Standstill	TRUE when processing is not currently performed for the command value, except when waiting for in-position state.* ¹ <i>Idle</i> and <i>InPosWaiting</i> are mutually exclusive. They cannot both be TRUE at the same time.
InPosWaiting	BOOL	In-position Waiting	TRUE when waiting for in-position state. The in-position check performed when positioning for the in-position check.
Homed	BOOL	Home Defined	TRUE when home is defined. FALSE: Home not defined. TRUE: Home is defined
InHome	BOOL	In Home Position	TRUE when the axis is in the range for home. It gives an AND of the following conditions. <ul style="list-style-type: none"> • Home defined • The actual current position is in the zero position range with home as the center. TRUE also when the zero position is passed by while the axis is moving in command status.
VelLimit	BOOL	Command Velocity Saturation	TRUE while the command velocity is limited to the maximum velocity during synchronized control.
Dir	_sAXIS_REF_DIR	Command Direction	Gives the command travel direction.
Posi	BOOL	Positive Direction	TRUE when there is a command in the positive direction.
Nega	BOOL	Negative Direction	TRUE when there is a command in the negative direction.
DrvStatus	_sAXIS_REF_STA_DRV	Drive Status	Gives the status of the Servo Drive.
ServoOn	BOOL	Servo ON	TRUE when the Servomotor is powered.
Ready	BOOL	Servo Ready	TRUE when the Servo is ready.
MainPower	BOOL	Main Power	TRUE when the Servo Drive main power is ON.
P_OT	BOOL	Positive Limit Input	TRUE when the positive limit input is enabled.
N_OT	BOOL	Negative Limit Input	TRUE when the negative limit input is enabled.
HomeSw	BOOL	Home Proximity Input	TRUE when the home proximity input is enabled.
Home	BOOL	Home Input	TRUE when the home input is enabled.* ²
ImdStop	BOOL	Immediate Stop Input	TRUE when the immediate stop input is enabled.
Latch1	BOOL	External Latch Input 1	TRUE when latch input 1 is enabled.
Latch2	BOOL	External Latch Input 2	TRUE when latch input 2 is enabled.
DrvAlarm	BOOL	Drive Error Input	TRUE while there is a Servo Drive error.
DrvWarning	BOOL	Drive Warning Input	TRUE while there is a Servo Drive warning.
ILA	BOOL	Drive Internal Limiting	TRUE when the Servo Drive limiting function actually limits the axis. This corresponds to one of the following limits in the G5-series Servo Drive.* ³ Torque limits, velocity limit, drive prohibit inputs, software limits
CSP	BOOL	Cyclic Synchronous Position (CSP) Control Mode	TRUE when the Servo is ON at the Servo Drive and the current mode is CSP Mode.* ⁴
CSV	BOOL	Cyclic Synchronous Velocity (CSV) Control Mode	TRUE when the Servo is ON at the Servo Drive and the current mode is CSV Mode.* ³
CST	BOOL	Cyclic Synchronous Torque (CST) Control Mode	TRUE when the Servo is ON at the Servo Drive and the current mode is CST Mode.* ³

Variable name	Data type	Meaning	Function
Cmd	_sAXIS_REF_CMD_DATA	Axis Command Values	
Pos	LREAL	Command Current Position	Contains the current value of the command position. (Unit: command units) When the Servo is OFF and the mode is not position control mode, this variable contains the actual current position.
Vel	LREAL	Command Current Velocity	Contains the current value of the command velocity. (Unit: command units/s) A plus sign is added during travel in the positive direction, and a minus sign during travel in the negative direction. The velocity is calculated from the difference with the command current position. When the Servo is OFF and the mode is not the position control mode, the velocity is calculated based on the actual current position.
AccDec	LREAL	Command Current Acceleration/Deceleration	Contains the current value of the command acceleration/deceleration rate. (Unit: command units/s ²) The acceleration/deceleration rate is calculated from the difference with the command current velocity. A plus sign is added for acceleration, and a minus sign is added for deceleration. The value is 0 when the command acceleration/deceleration rate of the instruction under execution is 0.
Jerk	LREAL	Command Current Jerk	Contains the current value of the command jerk. (command units/s ³) A plus sign is added when the absolute value of acceleration/deceleration is increasing, and a minus sign is added when it is decreasing. The value is 0 when the command acceleration/deceleration rate and command jerk of the instruction under execution is 0.
Trq	LREAL	Command Current Torque	Contains the current value of the command torque. (Unit: %) A plus sign is added during travel in the positive direction, and a minus sign during travel in the negative direction. Contains the same value as the actual current torque except in torque control mode.
Act	_sAXIS_REF_ACT_DATA	Axis Current Value	
Pos	LREAL	Actual Current Position	Contains the actual current position. (Unit: command units)
Vel	LREAL	Actual Current Velocity	Contains the actual current velocity. (Unit: command units/s) A plus sign is added during travel in the positive direction, and a minus sign during travel in the negative direction.
Trq	LREAL	Actual Current Torque	Contains the current value of the actual torque. (Unit: %) A plus sign is added during travel in the positive direction, and a minus sign during travel in the negative direction.

Variable name	Data type	Meaning	Function
MFaultLvl	_sMC_REF_EVENT	Axis Minor Fault	
Active	BOOL	Axis Minor Fault Occurrence	TRUE while there is an axis minor fault.
Code	WORD	MC Common Minor Fault Code	Contains the code for an axis minor fault. The upper four digits of the event code have the same value.
Obsr	_sMC_REF_EVENT	Axis Observation	
Active	BOOL	Axis Observation Occurrence	TRUE while there is an axis observation.
Code	WORD	Axis Observation Code	Contains the code for an axis observation. The upper four digits of the event code have the same value.
Cfg	_sAXIS_REF_CFG	Axis Basic Settings	Gives the settings of the Axis Basic Settings parameters.
AxNo	UINT	Axis Number	Contains the number of the axis.
AxEnable	_eMC_AXIS_USE	Axis Use	Shows if the axis is enabled or disabled. 0: mcNoneAxis (Undefined Axis) 1: mcUnusedAxis (Unused Axis) 2: mcUsedAxis (Used Axis)
AxType	_eMC_AXIS_TYPE	Axis Type	Contains the axis type. I/O wiring is not required for variable axes. 0: mcServo (Servo axis) 1: mcEncdr (Encoder Axis) 2: mcVirServo (Virtual Servo Axis) 3: mcVirEncdr (Virtual Encoder Axis)
NodeAddress	UINT	Node Address	Contains the EtherCAT slave address. A value of 16#FFFF indicates that there is no address.
Scale	_sAXIS_REF_SCALE	Unit Conversion Settings	Gives settings of the electronic gear ratio.
Num	UDINT	Command Pulse Count Per Motor Rotation	Contains the number of pulses per motor rotation for command positions. The command value is converted to the equivalent number of pulses based on the electronic gear ratio.
Den	LREAL	Work Travel Distance Per Motor Rotation	Contains the workpiece travel distance per motor rotation for command positions.
Units	_eMC_UNITS	Unit of Display	Contains the display unit for command positions. 0: _mcPIs (pulse) 1: _mcMm (mm) 2: _mcUm (μm) 3: _mcNm (nm) 4: _mcDeg (degree) 5: _mcInch (inch)

*1 This also includes states where processing is performed while in motion at velocity 0, during following error resets, during synchronized control, and during coordinated motion.

*2 The Detailed Settings Display on the Axis Basic Settings Tab Page of the Sysmac Studio gives the signal that is set for encoder Z-phase detection digital input. You may not be able to map a PDO to this signal for servo drives from other manufacturers. Refer to the manual for the connected servo drive for details.

*3 This variable gives the status of bit 11 (internal limit enabled) in the Status Word (6041 hex) that is mapped to a PDO. The conditions for this variable changing to TRUE depend on the specifications of the Servo Drive. Refer to the manual for the connected servo drive for details.

*4 This variable gives the value of the Modes of Operation Display (6061 hex) that is mapped to a PDO. The conditions CSP, CSV, and CST changing to TRUE depend on the specifications of the Servo Drive. Refer to the manual for the connected servo drive for details.
Always FALSE if Modes of Operation (6061 hex) is not mapped in a PDO.

● Relationship between Axis Variables and Axis Types

Axis Variables are enabled or disabled according to the axis type. Disabled members are FALSE or 0.

The following table shows which members are enabled for each axis type.

Variable name	Data type	Meaning	Servo axis	Virtual servo axis	Encoder axis	Virtual encoder axis
_MC_AX[0-63]	_sAXIS_REF	Axis Variable				
Status	_sAXIS_REF_STA	Axis Status				
Ready	BOOL	Axis Ready-to-execute	Enabled	Enabled	---	---
Disabled	BOOL	Axis Disabled	Enabled	Enabled	Enabled	Enabled
Standstill	BOOL	Standstill	Enabled	Enabled	---	---
Discrete	BOOL	Discrete Motion	Enabled	Enabled	---	---
Continuous	BOOL	Continuous Motion	Enabled	Enabled	---	---
Synchronized	BOOL	Synchronized Motion	Enabled	Enabled	---	---
Homing	BOOL	Homing	Enabled	Enabled	---	---
Stopping	BOOL	Deceleration Stopping	Enabled	Enabled	---	---
ErrorStop	BOOL	Error Deceleration Stopping	Enabled	Enabled	---	---
Coordinated	BOOL	Coordinated Motion	Enabled	Enabled	---	---
Details	_sAXIS_REF_DET	Axis Control Status				
Idle	BOOL	Standstill	Enabled	Enabled	Enabled	Enabled
InPosWaiting	BOOL	In-position Waiting	Enabled	Enabled	---	---
Homed	BOOL	Home Defined	Enabled	Enabled	---	---
InHome	BOOL	In Home Position	Enabled	Enabled	---	---
VelLimit	BOOL	Command Velocity Saturation	Enabled	Enabled	---	---
Dir	_sAXIS_REF_DIR	Command Direction				
Posi	BOOL	Positive Direction	Enabled	Enabled	---	---
Nega	BOOL	Negative Direction	Enabled	Enabled	---	---
DrvStatus	_sAXIS_REF_STA_DRV	Drive Status				
ServoOn	BOOL	Servo ON	Enabled	---	---	---
Ready	BOOL	Servo Ready	Enabled	---	---	---
MainPower	BOOL	Main Power	Enabled	---	---	---
P_OT	BOOL	Positive Limit Input	Enabled	---	---	---
N_OT	BOOL	Negative Limit Input	Enabled	---	---	---
HomeSw	BOOL	Home Proximity Input	Enabled	---	---	---
Home	BOOL	Home Input	Enabled	---	---	---
ImdStop	BOOL	Immediate Stop Input	Enabled	---	---	---
Latch1	BOOL	External Latch Input 1	Enabled	---	---	---
Latch2	BOOL	External Latch Input 2	Enabled	---	---	---
DrvAlarm	BOOL	Drive Error Input	Enabled	---	---	---
DrvWarning	BOOL	Drive Warning Input	Enabled	---	---	---
ILA	BOOL	Drive Internal Limiting	Enabled	---	---	---
CSP	BOOL	Cyclic Synchronous Position (CSP) Control Mode	Enabled	---	---	---
CSV	BOOL	Cyclic Synchronous Velocity (CSV) Control Mode	Enabled	---	---	---
CST	BOOL	Cyclic Synchronous Torque (CST) Control Mode	Enabled	---	---	---

Variable name	Data type	Meaning	Servo axis	Virtual servo axis	Encoder axis	Virtual encoder axis
Cmd	_sAXIS_REF_CMD_DATA	Axis Command Values				
Pos	LREAL	Command Current Position	Enabled	Enabled	---	---
Vel	LREAL	Command Current Velocity	Enabled	Enabled	---	---
AccDec	LREAL	Command Current Acceleration/Deceleration	Enabled	Enabled	---	---
Jerk	LREAL	Command Current Jerk	Enabled	Enabled	---	---
Trq	LREAL	Command Current Torque	Enabled	Enabled	---	---
Act	_sAXIS_REF_ACT_DATA	Axis Current Value				
Pos	LREAL	Actual Current Position	Enabled	Enabled	Enabled	Enabled
Vel	LREAL	Actual Current Velocity	Enabled	Enabled	Enabled	Enabled
Trq	LREAL	Actual Current Torque	Enabled	Enabled	---	---
MFaultLvl	_sMC_REF_EVENT	Axis Minor Fault				
Active	BOOL	Axis Minor Fault Occurrence	Enabled	Enabled	Enabled	Enabled
Code	WORD	Axis Minor Fault Code	Enabled	Enabled	Enabled	Enabled
Obsr	_sMC_REF_EVENT	Axis Observation				
Active	BOOL	Axis Observation Occurrence	Enabled	Enabled	Enabled	Enabled
Code	WORD	Axis Observation Code	Enabled	Enabled	Enabled	Enabled
Cfg	_sAXIS_REF_CFG	Axis Basic Settings				
AxNo	UINT	Axis Number	Enabled	Enabled	Enabled	Enabled
AxEnable	_eMC_AXIS_USE	Axis Use	Enabled	Enabled	Enabled	Enabled
AxType	_eMC_AXIS_TYPE	Axis Type	Enabled	Enabled	Enabled	Enabled
NodeAddress	UINT	Node Address	Enabled	---	Enabled	---
Scale	_sAXIS_REF_SCALE	Electronic Gear Ratio				
Num	UDINT	Command Pulse Count per Motor Rotation	Enabled	Enabled	Enabled	Enabled
Den	LREAL	Work Travel Distance per Motor Rotation	Enabled	Enabled	Enabled	Enabled
Units	_eMC_UNITS	Unit of Display	Enabled	Enabled	Enabled	Enabled

Axes Group Variables

_MC_GRP[0..31] are the system-defined Axes Group Variables. The data type is *_sGROUP_REF*, which is a structure. This section describes the configuration of the Axes Group Variables and provides details on the members.

Variable name	Data type	Meaning	Function
<i>_MC_GRP[0..31]</i>	<i>_sGROUP_REF</i>	Axes Group Variable	
Status	<i>_sGROUP_REF_STA</i>	Axes Group Status	
Ready	BOOL	Ready to Execute	TRUE when the axes group is stopped and is ready to execute. The condition for being ready to execute is an AND of the following conditions. <ul style="list-style-type: none"> • Execution of the MC_Stop instruction is not in progress for any composition axis. • <i>_MC_GRP[XX].Status.Standby</i> is TRUE (stopped). • The Servo is ON for the composition axes. • <i>_MC_AX[XX].Details.Homed</i> is TRUE (home is defined) for the composition axis.
Disabled	BOOL	Axes Group Disabled	TRUE when the axes group is disabled and stopped. The following axes group status are mutually exclusive. Only one of them can be TRUE at a time. <i>Disable, Standby, Moving, Stopping, ErrorStop</i>
Standby	BOOL	Stopped	TRUE when the axes group motion instruction is stopped. (This is independent of the Servo ON/OFF status of the composition axes in the axes group)
Moving	BOOL	Moving	TRUE while an axes group motion instruction is executed toward the target position. This includes in-position waiting status and when the velocity is 0 for an override.
Stopping	BOOL	Deceleration Stopping	TRUE until the axes group stops for an MC_GroupStop instruction. This includes when <i>Execute</i> is TRUE after the axes stop for an MC_GroupStop instruction. Axes group motion instructions are not executed in this state. (<i>CommandAborted</i> is TRUE.)
ErrorStop	BOOL	Error Deceleration Stopping	TRUE while the axes group is stopping or stopped for the MC_GroupImmediateStop instruction or for an axes group minor fault (when <i>_MC_GRP[XX].MFaultLvl.Active</i> is TRUE). Axes group motion instructions are not executed in this state. (<i>CommandAborted</i> is TRUE.)
Details	<i>_sGROUP_REF_DET</i>	Axes Group Control Status	Gives the control status of the instruction.
Idle	BOOL	Idle	TRUE when processing is not currently performed for the command value, except when waiting for in-position state.*1 <i>Idle</i> and <i>InPosWaiting</i> are mutually exclusive. They cannot both be TRUE at the same time.
InPosWaiting	BOOL	In-position Waiting	TRUE when waiting for in-position state for any composition axis. TRUE during positioning operations during the in-position check.*2

Variable name	Data type	Meaning	Function
Cmd	_sGROUP_REF_CMD_DATA	Axes Group Command Values	
Vel	LREAL	Command Interpolation Velocity	Contains the current value of the command interpolation velocity. The interpolation velocity is calculated from the difference with the interpolation command current position. A plus sign is added during travel in the positive direction, and a minus sign is added during travel in the negative direction. The value is 0 when the axes group is disabled.
AccDec	LREAL	Command Interpolation Acceleration/Deceleration	Contains the current value of the command interpolation acceleration/deceleration. The interpolation acceleration/deceleration rate is calculated from the difference with the command interpolation velocity. A plus sign is added for acceleration, and a minus sign is added for deceleration. The value is 0 when the axes group is disabled, or when the command acceleration/deceleration rate of the current axes group motion instruction is 0.
MFaultLvl	_sMC_REF_EVENT	Axes Group Minor Fault	
Active	BOOL	Axes Group Minor Fault Occurrence	TRUE while there is an axes group minor fault.
Code	WORD	Axes Group Minor Fault Code	Contains the error code for an axes group minor fault. The upper four digits of the event code have the same value.
Obsr	_sMC_REF_EVENT	Axes Group Observation	
Active	BOOL	Axes Group Observation Occurrence	TRUE while there is an axes group observation.
Code	WORD	Axes Group Observation Code	Contains the observation code for an axes group minor fault. The upper four digits of the event code have the same value.

Variable name	Data type	Meaning	Function
Cfg	_sGROUP_REF_CFG	Axes Group Basic Settings	Gives the settings of the Axes Group Basic Settings parameters.
GrpNo	UINT	Axes Group Number	Contains the logical number of the axes group. This number is accessed to recognize the axes group number when accessing _sGROUP_REF.
GrpEnable	_eMC_GROUP_USE	Axes Group Use	Shows if the axes group is enabled or disabled. 0: mcNoneGroup (Undefined Axes Group) 1: mcUnusedGroup (Unused Axes Group) 2: mcUsedGroup (Used Axes Group)
Kinematics	_sGROUP_REF_KIM	Kinematics Transformation Settings	Contains the definition of the kinematic conversions for the axes group.
GrpType	_eMC_TYPE	Composition	Gives the axis composition of multi-axes coordinated control. 0: mcXY (two axes) 1: mcXYZ (three axes) 2: mcXYZU (four axes)
Axis[0]	UINT	Composition Axis for Axis A0	Contains the axis number that is assigned to axis A0.
Axis[1]	UINT	Composition Axis for Axis A1	Contains the axis number that is assigned to axis A1.
Axis[2]	UINT	Composition Axis for Axis A2	Contains the axis number that is assigned to axis A2.
Axis[3]	UINT	Composition Axis for Axis A3	Contains the axis number that is assigned to axis A3.


*1 This also includes states where processing is performed while in motion at a velocity of 0.

*2 This variable is FALSE when all composition axes in the axes group are within the in-position ranges set in the axis parameters.

6-7 Cam Tables and Cam Data Variables

The MC Function Module uses the cam profile curves that you create on the Cam Editor of the Sysmac Studio as cam tables. The cam table data is handled as cam data variables in the user program in the NJ-series Controller.

Creating and Saving Cam Tables



* Use the Synchronization menu command of the Sysmac Studio to upload and download the project.

● Cam Table Data Flow

- Use the Sysmac Studio to download the cam profile curves that you created in the Sysmac Studio to the CPU Unit to save them as cam tables in the non-volatile memory in the CPU Unit.
- The saved cam tables are implemented as cam data variables in the main memory after you download them or when the power is turned ON.
- You can use the user program to edit cam data variables in the main memory. Refer to *9-2-5 Cam Tables* for information on cam data variables.
- The motion control instruction MC_SaveCamTable saves the cam data variables in the main memory to non-volatile memory.
- For details on the MC_SaveCamTable instruction, refer to the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).
- You can upload and download cam tables regardless of the operating mode of the CPU Unit mode or the status of the MC Function Module. You cannot upload cam data, download cam data, start online operation, perform online editing, or start data traces during a cam table save operation. The MC_SaveCamTable instruction is not executed during online editing.
- All axes in motion will decelerate at the maximum deceleration rate and the Servo will turn OFF when you start the download process.




Precautions for Correct Use

- If you change any cam data in the user program, those changes are lost and the cam table in non-volatile memory is restored if you restart the power or download cam data from the Sysmac Studio.
- Execute the MC_SaveCamTable instruction first if you need to save cam data that you modified in the user program to non-volatile memory or if you need to upload it to the Sysmac Studio.

Editing a Cam Data Variable on the Computer after Editing It from the User Program

If you edit a cam data variable from the user program and then use the MC_SaveCamTable instruction to save the cam table to non-volatile memory, you cannot edit the data with the Cam Editor of the Sysmac Studio. This section describes how to use spreadsheet software to edit the data and then use it as a cam table.



* Use the Synchronization menu command of the Sysmac Studio to upload and download the project.

● Saving a Cam Table from Non-volatile Memory to a CSV File

- Right-click a cam profile that you edited in the Cam Data Settings of the Sysmac Studio and select **Transfer Cam Table [Controller to File]** from the menu.
- The Save Dialog Box is displayed. Enter the file save location and file name, and then click the **Save** Button.

● Editing CSV Files

- Use spreadsheet software or other CSV-compatible software to edit the CSV file.

● Transferring the CSV File to the CPU Unit

- Right-click the cam profile to download and select **Transfer Cam Table [File to Controller]** from the menu.
- The Open File Dialog Box is displayed. Specify the file to transfer, and then click the **OK** Button.
- To enable the cam table that you transferred, reset the Controller or cycle the power supply to the Controller after the cam table is transferred.



Precautions for Correct Use

- Synchronize the data with the Controller before you transfer a cam table from a file to the Controller.
 - If you transfer the cam table to the Controller during a synchronization operation after you transfer a cam table from a file to the Controller, the cam table in the Controller is replaced with the data in the Cam Data Settings. Either transfer the cam data from the file to the Controller again, or do not include the Cam Data Settings in the synchronization data.
-

You can also export the Cam Data Settings that were entered from the Cam Editor to a CSV file. Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for information on the Cam Data Settings and the export procedure.


Cam Profile Curve Names

When a cam profile is created in the Sysmac Studio, *CamProfile0* is used as the default name. Each time you create another cam profile, the number on the end of the name is incremented. You can change the name of any cam profile as required from the Sysmac Studio.

The cam profile names that are set on the Sysmac Studio are used as the cam table names.

Specifying Cam Tables in the User Program

In the user program, the cam table name is specified for the in-out variable *CamTable* in motion control instructions.



6-8 Programming Motion Controls

Place motion control instructions in the user program of the NJ-series Controller to perform motion control. Programs that contain motion control instructions are called motion control programs.



Precautions for Correct Use

- You can set and program up to 64 axes on the Sysmac Studio for any model of CPU Unit. If you download a project that exceeds the maximum number of control axes for the CPU Unit model to the CPU Unit with the Synchronization menu command, a major fault level error occurs after the download or when power is turned ON.
- When you reuse a project, make sure that the maximum number of control axes for the CPU Unit model is not exceeded.
- Even axes that are set as unused axes are included in the number of control axes.


Refer to the *NJ-series CPU Unit Software User's Manual* (Cat. No. W501) for details on programming. This section gives the procedure to create a program in an existing project on the Sysmac Studio.

1 Starting the Sysmac Studio

Start the Sysmac Studio and open the project.

2 Adding a Program


Right-click **Programs** in the Multiview Explorer and select **Multipart Ladder** or **Structured Text** from the Add Menu.




A program is added to the Multiview Explorer.

3 Editing the Program

Right-click a section in the new program and select **Edit** from the menu. The Program Edit Tab Page is displayed.



Select the required instructions from the Toolbox and enter the program.



Refer to the *NJ-series CPU Unit Software User's Manual* (Cat. No. W501) for details on programming.
Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for specific procedures.


6-9 Creating Cam Tables

This section will explain how to use the Cam Editor of the Sysmac Studio to create a cam table.


Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for details on the Cam Editor.

1 Adding a Cam Profile

Right-click **Cam Data Settings** in the Multiview Explorer and select **Cam Profile (NJ Series)** from the Add Menu.




A cam profile is added to the Multiview Explorer. You can change the name of the cam profile as required from the default name of *CamProfile0*.




2 Editing the Cam Profile

Right-click the cam profile in the Multiview Explorer and select **Edit** from the menu.



The Cam Profile Edit Tab Page is displayed.



Make the settings and enter the cam profile.
 Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for specific procedures.



Manual Operation

This section describes manual operation when the MC Function Module is used together with an OMRON G5-series Servo Drive.

7-1	Outline	7-2
7-2	Turning ON the Servo	7-3
7-2-1	Turning ON the Servo	7-3
7-2-2	Setting Axis Parameters	7-4
7-2-3	Programming Example	7-4
7-3	Jogging	7-5
7-3-1	Jogging Procedure	7-5
7-3-2	Setting Axis Parameters	7-6
7-3-3	Setting Example for Input Variables	7-6
7-3-4	Programming Example	7-7

7-1 Outline

This section describes how to combine the MC Function Module and OMRON G5-series Servo Drives together and use motion control instructions from the user program to perform manual operations.

The motion control instructions for manual operation are MC_Power and MC_MoveJog. MC_Power changes the Servo Drive to the Servo ON state and MC_MoveJog performs jogging.



Precautions for Correct Use

You must set the axes to perform manual operation. Refer to *Section 3 Configuring Axes and Axes Groups* for details on how to set axes.




Additional Information

- Use the Sysmac Studio if you want to perform manual operation without programming. Refer to *4-3 Checking Motor Operation* for information on how to use the Sysmac Studio to perform manual operation.
 - Refer to *Section 6 Motion Control Programming* for information on how to create user programs.
-

7-2 Turning ON the Servo

You can turn the Servo ON or OFF to enable or disable sending operation commands to the Servo Drive. The MC_Power (Power Servo) motion control instruction is used.



Specify the axis to move with the *Axis* in-out variable. Change the *Enable* input variable for MC_Power to TRUE to turn ON the Servo. Change *Enable* to FALSE to turn OFF the Servo.



Precautions for Correct Use

If you change *Enable* to FALSE while the axis is moving, the command stops immediately and all motion control instructions for that axis are disabled.



Additional Information

If an OMRON G5-series Servomotor with an absolute encoder is used, home is defined when *Enable* changes to TRUE.

7-2-1 Turning ON the Servo

- 1** Adding and Setting an Axis
Add and set an axis from the Sysmac Studio. For details, refer to *3-2-2 Setting Procedure*.
- 2** Setting Axis Parameters
Set the axis parameters from the Sysmac Studio. For details, refer to *3-2-2 Setting Procedure*.
- 3** Writing the User Program
Create the user program from the Sysmac Studio. For details, refer to *6-8 Programming Motion Controls*.
- 4** Downloading Axis Parameters and the User Program
Download the axis parameters and user program to the CPU Unit. Use the Synchronization menu command of the Sysmac Studio to download the project to the CPU Unit. For details, refer to *3-2-2 Setting Procedure*.
- 5** Executing the User Program
Execute the user program and change the *Enable* input variable for MC_Power to TRUE. The Servo Drive will change to the Servo ON state.

7-2-2 Setting Axis Parameters

Only the following axis parameter settings are required if you want only to change to the Servo ON state. The following table provides examples of the settings.

Parameter name	Setting
Axis Variable Name	Axis1*1
Axis Number	1*2
Axis Use	Used axis
Axis Type	Servo axis
Node Address	1*3

- *1 If there is more than one axis, a different variable name is set for each axis.
- *2 If there is more than one axis, a different value is set for each axis.
- *3 Set the node address to the same value as the node address that is set on the Servo Drive. If there is more than one axis, a different value is set for each axis.




Additional Information

If the OMRON G5-series Servo Drive is connected properly, you can use the network scan function of the Sysmac Studio to automatically set all axis parameters not listed in the previous table.

7-2-3 Programming Example


The following sample programming turns the Servo ON and OFF for an axis named *Axis1* based on the value of bit A.



For details on the MC_Power (Power Servo) instruction, refer to the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

7-3 Jogging

Use the motion control instruction MC_MoveJog for jogging.



Specify the axis to jog with the *Axis* in-out variable. Change the *PositiveEnable* input variable to TRUE to start the axis with the specified positive *Velocity* (Target Velocity) and *Acceleration* (Acceleration Rate). Change *PositiveEnable* to FALSE to decelerate and stop the axis at the specified *Deceleration* (Deceleration Rate).


Similarly, if you change the *NegativeEnable* input variable to TRUE, the axis will start in the negative direction. Change *NegativeEnable* to FALSE to stop the axis. You can perform jogging even if the home has not yet been defined.

7-3-1 Jogging Procedure

- 1** Adding and Setting an Axis
Add and set an axis from the Sysmac Studio. For details, refer to *3-2-2 Setting Procedure*.
- 2** Setting Axis Parameters
Set the axis parameters from the Sysmac Studio. For details, refer to *3-2-2 Setting Procedure*.
- 3** Writing the User Program
Create the user program from the Sysmac Studio. For details, refer to *6-8 Programming Motion Controls*.
- 4** Downloading Axis Parameters and the User Program
Download the axis parameters and user program to the CPU Unit. Use the Synchronization menu command of the Sysmac Studio to download the project to the CPU Unit. For details, refer *3-2-2 Setting Procedure*.
- 5** Executing the User Program
Execute the user program and change the *Enable* input variable for MC_Power to TRUE to change the Servo Drive to the Servo ON state. Change either the *PositiveEnable* or *NegativeEnable* input variable for the MC_MoveJog instruction to TRUE to jog.

7-3-2 Setting Axis Parameters

Set the following axis parameters if you want to jog when home is not defined. The following setting example is for a one-axis device.



Parameter name	Setting
Axis Variable Name	Axis1*1
Axis Number	1*2
Enabled Axes	Used axis
Axis Use	Servo axis
Node Address	1*3
Command Pulse Count Per Motor Rotation	1,048,576*4
Work Travel Distance Per Motor Rotation	10,000*4
Software Limits	Enabled for actual position
Unit of Display	μm
Count Mode	Linear Mode
Maximum Velocity	500,000*5
Maximum Jog Velocity	50,000*6
Maximum Acceleration	5,000,000*7
Maximum Deceleration	5,000,000*7

*1 If there is more than one axis, a different variable name is set for each axis.

*2 If there is more than one axis, a different value is set for each axis.

*3 Set the node address to the same value as the node address that is set on the Servo Drive. If there is more than one axis, a different value is set for each axis.

*4 The position command unit will be $1 \mu\text{m}$.

*5 The maximum velocity will be $3,000 \text{ r/min} = 30 \text{ m/min} = 0.5 \text{ m/s} = 500,000 \mu\text{m/s}$.

*6 The maximum jog velocity will be 10% of the maximum velocity, i.e., $0.05 \text{ m/s} = 50,000 \mu\text{m/s}$.

*7 The maximum acceleration and the maximum deceleration are 5 m/s^2 . The acceleration time to the maximum velocity ($3,000 \text{ r/min}$) is 0.1 s.


7-3-3 Setting Example for Input Variables

This section describes the settings for the MC_MoveJog input variables *Velocity* (Target Velocity), *Acceleration* (Acceleration Rate), and *Deceleration* (Deceleration Rate).

- For example, set *Velocity* to 30,000 to jog at a velocity of 0.03 m/s.
- Set *Acceleration* and *Deceleration* to 3,000,000 to accelerate and decelerate at 3 m/s^2 .

7-3-4 Programming Example

The following programming example jogs an axis named *Axis1* in the positive direction for the value of bit A and in the negative direction for the value of bit B.



In this example, *Velocity* (Target Velocity) is *Velo1*, *Acceleration* is *Acce1*, and *Deceleration* is *Dece1*.

Set the values for each variable in the user program in advance to operate the axis with the example input variable settings.

- Velo1 = 30,000
- Acce1 = 3,000,000
- Dece1 = 3,000,000

For details on the MC_MoveJog (Jog) instruction, refer to the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).



Homing


This section describes homing.

8-1	Outline	8-2
8-2	Homing Procedure	8-5
8-2-1	Setting Homing Parameters	8-5
8-2-2	Monitoring the Homing Operation	8-10
8-3	Homing Operation	8-11
8-4	Homing with an Absolute Encoder	8-12
8-4-1	Outline of Function	8-13
8-4-2	Setting Procedure	8-13
8-5	High-speed Homing	8-15

8-1 Outline

This section describes the operations that are performed when the MC Function Module is combined with an OMRON G5-series Servo Drive.

To perform positioning to absolute positions in a positioning system, you must first define the home. For example, if you want to perform positioning to the position (axis 1, axis 2) = (100 mm, 200 mm) in the XY plane shown below, you must define the position of home (0,0). The process of defining home is called homing.



In the MC Function Module, use the motion control instruction MC_Home to define home.

Name	Description
Homing	Home is defined by actually moving the motor and using the limit sensors, home proximity sensor, and home input signal to determine the position of home. Use a proximity sensor or the encoder's Z phase signal as the home input signal.



Precautions for Correct Use

The defined home is lost in the following situations.

- When MC_SetPosition is executed.
- When an overflow or underflow occurs in Linear Mode.
- When homing is started.
- The control state of EtherCAT communications is not Operational state.



Additional Information

If you are using an OMRON G5-series Servomotor with an absolute encoder, home is defined when the MC_Power input variable *Enable* changes to TRUE.

The MC_MoveZeroPosition (High-speed Home) instruction is also provided to perform positioning to home as defined for this method.

Name	Description
High-speed Homing	The axis returns to home using an absolute position of 0 as the target position.

The MC Function Module can operate the motor even when home is undefined (excluding MC_MoveZeroPosition).

Function	Operation	
Jogging and velocity control	If home is not defined, the position at startup is defined as 0 to control movement.	
High-speed homing	High-speed homing cannot be used. If it is used, an instruction error will occur.	
Positioning	If home is not defined, the position at startup is defined as 0 to control movement.	
Interrupt feeding		
Starting cam operation		
Starting gear operation		
Synchronous positioning		
Combining axes		
Torque control		
Zone monitoring		
Linear interpolation		Interpolation cannot be used.
Circular interpolation		If it is used, an instruction error will occur.



Additional Information

Software limits are not valid when home is not defined.

Changes in the home definition status for operations and events are listed in the following table.

Operation or event	Condition for change	Home definition status change
Servo turned ON or axis enabled	Incremental encoder	No change
	When absolute data is read normally from the absolute encoder	Home is defined.
	When absolute data cannot be read from the absolute encoder	Home is undefined.
Changing the current position	When starting	Home is undefined.
Homing	When starting	Home is undefined.
	When ending	Home is defined.
Overflows and underflows	When overflow or underflow occurs	Home is undefined.

**Precautions for Correct Use**

- For a virtual axis, home is always defined with a zero position preset. The setting of the Homing Method axis parameter is ignored.
 - The positive drive prohibit input (POT), negative drive prohibit input (NOT), and home proximity input (DEC) of the Servo Drive are used by the MC Function Module as the positive limit input, negative limit input, and home proximity input. Make sure that the signal widths for all of these input signals are long enough for the Servo Drive to detect them and longer than the control period of the MC Function Module. If the input signal widths are shorter than the control period, the MC Function Module may not be able to detect the input signals, resulting in incorrect operation.
 - You must set the Servo Drive parameters for each Servo Drive input signal. Refer to the manual for your Servo Drive and the appendices and make the proper settings.
-

8-2 Homing Procedure

This section describes the procedure to perform homing.


- 1** Adding and Setting an Axis
Add and set an axis from the Sysmac Studio.
- 2** Setting Axis Parameters
Set the homing method with the homing parameters.
- 3** Writing the User Program
Create the user program from the Sysmac Studio. For details, refer to *6-8 Programming Motion Controls*.
- 4** Downloading Axis Parameters and the User Program
Download the axis parameters and user program to the CPU Unit. Use the Synchronization menu command of the Sysmac Studio to download the project to the CPU Unit. For details, refer to *3-2-2 Setting Procedure*.
- 5** Executing the User Program
Execute the user program and change the *Enable* input variable for MC_Power to TRUE to change the Servo Drive to the Servo ON state. Homing is performed when the *Execute* input variable to the MC_Home instruction changes to TRUE.

8-2-1 Setting Homing Parameters

Set the homing parameters to specify the homing procedure.

Parameter name	Description
Homing Method	Set the homing operation.
Home Input Signal	Select the input to use for the home input signal.
Homing Start Direction	Set the start direction for when homing is started.
Home Input Detection Direction	Set the home input detection direction for homing.
Operation Selection at Positive Limit Input	Set the stopping method when the positive limit input turns ON during homing.
Operation Selection at Negative Limit Input	Set the stopping method when the negative limit input turns ON during homing.
Homing Velocity	Set the homing velocity. (Unit: command units/s)
Homing Approach Velocity	Set the velocity to use after the home proximity input turns ON. (Unit: command units/s)
Homing Acceleration	Set the acceleration rate for homing. Set 0 for no acceleration. (Unit: command units/s ²)
Homing Deceleration	Set the deceleration rate for homing. Set 0 for no deceleration. (Unit: command units/s ²)
Homing Jerk	Set the jerk for homing. Set 0 for no jerk. (Unit: command units/s ³)
Home Input Mask Distance	Set the home input feeding distance when you set the Homing Operation Mode to the proximity reverse turn and home input mask distance specification. (Unit: command units)
Home Offset	Preset the actual position for the value that is set after homing. (Unit: command units)

Parameter name	Description
Homing Holding Time	Set the holding time when you set the Homing Operation Mode to the proximity reverse turn and holding time specification. (Unit: ms)
Homing Compensation Value	Set the homing compensation value that is applied after the home is defined. (Unit: command units)
Homing Compensation Velocity	Set the velocity to use for homing compensation (command units/s).



Homing Methods

You can select any of the ten operations to define home.

- Proximity reverse turn/home proximity input OFF
- Proximity reverse turn/home proximity input ON
- Home proximity input OFF
- Home proximity input ON
- Limit input OFF
- Proximity reverse turn/home input mask distance
- Limit inputs only
- Proximity reverse turn/holding time
- No home proximity input/holding home input
- Zero position preset

For details, refer to the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Operation Selection at Positive Limit Input and Operation Selection at Negative Limit Input


- You can set the stopping method when the limit input in the motion direction turns ON during homing.
- The stopping method depends on the limit input stop method.
- The limit input setting in the direction of motion is enabled. It is also enabled during motion at homing velocity or homing approach velocity.
- If you set reversing in the limit input settings, an error stop will occur if the limit input signal in the home input detection direction turns ON at homing approach velocity. However, this does not apply in operation modes in which the home proximity signal is not used.
- An error will occur and operation will stop if you set reversing for the limit input operations in both directions and the home input signal cannot be detected after moving from the limit input position opposite to the home input detection direction to the other limit input position.

Homing Start Direction

Set the start direction for when homing is started. To describe the relationship between the home input detection direction and the definition pattern, we will use the proximity reverse turn with home proximity input OFF specification. The difference in operation when the homing start direction and the home input detection direction are the same and when they are not the same is shown below.

● Homing Start Direction Same as Home Input Detection Direction

Homing start direction and home input detection direction




● Homing Start Direction Different from Home Input Detection Direction

Homing start direction



Home input detection direction




Home Input Detection Direction

Set the home input detection direction. Refer to *Homing Start Direction* on page 8-7 for details on the relationship between the homing start direction and the home detection method.


Homing Holding Time

Set the holding time when you set the Homing Method to the proximity reverse turn and holding time specification. This is the time from when the home proximity input signal (i.e., from when deceleration starts) until home is defined.



Home Input Mask Distance

Set the home input mask distance in command units when you set the Homing Method to the proximity reverse turn/home input mask distance. This is the distance from when the home proximity input signal (i.e., from when deceleration starts) until home is defined.



Homing Compensation Value

After home is defined, relative positioning is performed at the set value to adjust the position of home. This homing compensation is performed at the homing compensation velocity.

Adjusting the workpiece is sometimes difficult after home is defined. The homing compensation can be used to fine-tune the position of home after it is determined. This is useful when you cannot easily replace the home proximity sensor or when home has moved after a motor replacement.

Home Offset

After home is defined, the operation for the homing compensation value is completed if a homing compensation value is set, and then the actual value is preset to the set value.

This means that you can set home to any specified value rather than to 0. For systems with absolute encoders, also the absolute encoder home offset value is calculated and saved to the battery-backup memory in the CPU Unit.

Homing Velocity

Set the homing velocity in command units.

Homing Approach Velocity

Set the velocity after the home proximity input turns ON in command units per second (command units/s).

Homing Compensation Velocity

If you set a homing compensation value, set the velocity to use for the compensation in command units per second (command units/s).

Homing Acceleration

Set the homing acceleration rate in command units per seconds squared (command units/s²). If the homing acceleration is set to 0, the homing velocity is used without an acceleration curve.

Homing Deceleration

Set the homing deceleration rate in command units per seconds squared (command units/s²). If the homing deceleration is set to 0, the velocity goes to 0 without a deceleration curve.

Homing Jerk

Set the homing jerk in command units per seconds cubed (command units/s³). If the homing jerk is set to 0, acceleration and deceleration are performed without jerk.

Home Input Signal

In a Homing Method that uses a home input signal, select either the Z phase signal of the Servo Drive or an external home signal as the signal to define home.



Precautions for Correct Use

This parameter can be used to set a home input signal only when you are connected to an OMRON G5-series Servo Drive.

8-2-2 Monitoring the Homing Operation

You can read Axis Variables in the user program to monitor the homing status and the input signal status.

Variable name	Data type	Meaning	Function
_MC_AX[0-63].Status.Homing	BOOL	Homing	TRUE when homing for the MC_Home instruction.
_MC_AX[0-63].Details.Homed	BOOL	Home Defined	TRUE when home is defined. FALSE: Home not defined. TRUE: Home is defined
_MC_AX[0-63].Details.InHome	BOOL	In Home Position	TRUE when the axis is in the range for home. It gives an AND of the following conditions. Home defined. Actual current position is within the zero position range of home. This variable is also TRUE when the zero position is passed by while the axis is moving for a command.
_MC_AX[0-63].DrvStatus.P_OT	BOOL	Positive Limit Input	TRUE when the positive limit input is enabled.
_MC_AX[0-63].DrvStatus.N_OT	BOOL	Negative Limit Input	TRUE when the negative limit input is enabled.
_MC_AX[0-63].DrvStatus.HomeSw	BOOL	Home Proximity Input	TRUE when the home proximity input is enabled.
_MC_AX[0-63].DrvStatus.Home	BOOL	Home Input	TRUE when the home input is enabled.

8-3 Homing Operation

Select the home definition method based on the configuration of the positioning system and its purpose. There are 10 Homing Operation Modes supported by the MC Function Module. You can also fine-tune the home that is detected with a homing compensation value.



Additional Information

- The most suitable mode depends on the configuration of the positioning system and the application. In linear mode (finite length), Proximity Reverse Turn and Home Proximity Input OFF is normally used if there is a home proximity sensor, positive limit input, and negative limit input.
 - The override factors are ignored for homing.
 - The in-position check will follow the in-position check settings only for the completion of the home definition and homing compensation motions.
 - Buffering and blending are not performed if you use multi-execution of other motion control instructions during homing.
-


For details on homing, refer to the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

8-4 Homing with an Absolute Encoder

This section describes how to use the absolute encoder of the G5-series Servo Drive with built-in Ether-Cat communications.

Servo Drives that use EtherCAT communications have their own position control loop. Therefore, the actual position from the encoder is not used in the MC Function Module for control. Actual position information is received via EtherCAT communications. This means that you can access the actual position in the user program and/or monitor it from the Sysmac Studio.

If you use an absolute encoder, the absolute data can be retained by the battery backup in the encoder even when the power supply to the CPU Unit is turned OFF. When you execute the MC_Power (Power Servo) instruction, the position is determined by reading the actual position from the absolute encoder. Unlike when using an incremental encoder, after home is defined, you do not need to perform the homing operation again.



Precautions for Correct Use

- If you use an absolute encoder, connect a battery to the CPU Unit and an absolute encoder backup battery to the Servo Drive.
- Always execute the MC_Home instruction to define home when you use the absolute encoder for the first time, after you replace the motor, when the battery in the absolute encoder expires, or at any other time when the absolute value data is lost.
- If there is an error for the Battery in the CPU Unit when the power supply to the Controller is turned ON, an Absolute Encoder Home Offset Read Error (event code:14600000 hex) occurs. You can use the ResetMCError instruction to reset the error and turn ON the Servo. When the Servo is turned ON, home is defined with an absolute encoder home offset of 0. To move to correct positions, execute the MC_Home instruction to define the correct home position. If the power supply to the Controller is turned OFF, home will become undefined.
- After home is defined, cycle the power to the Servo Drive. After you complete these steps, the position is defined by MC_Power alone.

8-4-1 Outline of Function

To define home with an absolute encoder system, the absolute encoder offset compensation is performed when the MC_Power (Power Servo) instruction is executed. Home can also be defined by performing a homing operation in the same way as for an incremental encoder. After home is defined, the difference between the command position and the absolute value data read from absolute encoder is saved to the battery-backup memory in the CPU Unit as the absolute encoder home offset.

The Absolute Encoder Origin Position Offset axis parameter is also set to the difference (i.e., the offset) between the command position after defining home and the absolute value when the MC_Home (Homing) instruction is executed. The MC Function Module automatically saves the absolute value encoder home offset to the battery-backup memory in the CPU Unit. You do not have to perform a save operation from the Sysmac Studio.



Precautions for Correct Use

- If you replace the CPU Unit or the Battery in the CPU Unit, make sure home is defined and back up the battery-backup memory before you start the replacement procedure. This ensures that the absolute encoder home offset is backed up.
- You can restore the backed up data after finishing the replacement procedure to use the home that was previously defined.
- Use the Sysmac Studio to back up and restore the data.
Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for specific procedures.

Applicable Servomotors

A list of Servomotors that can connect to the MC Function Module is provided below.

Manufacturer	Series	Servo Drive	Servomotor
OMRON	G5 Series	R88D-KN□□□-ECT	R88M-K□□□□□S R88M-K□□□□□T R88M-K□□□□□C

Connecting the Servo Drive

Connect the Servo Drive correctly according to information in the *NJ-series CPU Unit Built-in EtherCAT Port User's Manual* (Cat. No. W505).

8-4-2 Setting Procedure

This section describes the procedure to set the home of an absolute encoder system.

1 Absolute Encoder Setup

Refer to the *OMRON G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications User's Manual* (Cat. No. I576) for the setup procedure.

2 Setting Axis Parameters

Set *encoder type* for the Count Mode axis parameter of the MC Function Module. For details, refer to 5-2-7 *Position Count Settings*.

3 Execute Homing

Execute homing. Set the Homing Method in the Homing Settings axis parameters of the MC Function Module. After home is defined, the difference between the command position and the absolute value data read from the absolute encoder is automatically saved to the battery-backup memory in the CPU Unit as the absolute encoder home offset.

Absolute Encoder Setup

The absolute encoder must be set up the first time it is used, to initialize the rotation data to 0, when the absolute encoder is stored for an extended period of time without a battery connected, etc. Refer to the *OMRON G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications User's Manual* (Cat. No. I576) for the setup procedure.



Precautions for Correct Use


After the absolute encoder is set up, the power supply to the OMRON G5-series Servo Drive must be cycled. When setup processing for the absolute encoder is completed, an Absolute Value Clear Error (A27.1) will occur in the Servo Drive. Cycle the control power supply to the Servo Drive to clear this error and complete the absolute encoder setup procedure.

Using an Absolute Encoder in Rotary Mode

If you set the Count Mode axis parameter to Rotary Mode, the actual position will be a ring-shaped counter in the range between the modulo maximum position setting value and the modulo minimum position setting value. When using an absolute encoder in Rotary Mode, the absolute encoder home offset is automatically calculated and updated in the MC Function Module each motion control period. The updated absolute encoder home offset is automatically saved to the battery-backup memory in the CPU Unit when the power supply to the Controller is turned OFF. This enables recovering the actual position of a rotating axis from the absolute encoder the next time power is turned ON even if the power to the CPU Unit or Servo Drive is turned OFF.

8-5 High-speed Homing

This function performs quick positioning to the home. Home is defined in advance. Use the MC_MoveZeroPosition (High-speed Homing) instruction and specify the target velocity, acceleration rate, deceleration rate, and jerk. If you execute this instruction when home is not defined an instruction error will occur.



Additional Information

For details on the MC_MoveZeroPosition (High-speed Homing) instruction, refer to the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9

Motion Control Functions

This section describes the motion control functions that are used when connected to OMRON G5-series Servo Drives with built-in EtherCAT communications.

9-1	Single-axis Position Control	9-3
9-1-1	Outline of Operation	9-3
9-1-2	Absolute Positioning	9-4
9-1-3	Relative Positioning	9-4
9-1-4	Interrupt Feeding	9-5
9-1-5	Stopping	9-6
9-1-6	Override Factors	9-9
9-2	Single-axis Synchronized Control	9-11
9-2-1	Overview of Synchronized Control	9-11
9-2-2	Gear Operation	9-11
9-2-3	Positioning Gear Operation	9-12
9-2-4	Cam Operation	9-13
9-2-5	Cam Tables	9-14
9-2-6	Synchronous Positioning	9-19
9-2-7	Combining Axes	9-21
9-2-8	Master Axis Phase Shift	9-22
9-3	Single-axis Velocity Control	9-23
9-3-1	Velocity Control	9-23
9-3-2	Cyclic Synchronous Velocity Control	9-24
9-4	Single-axis Torque Control	9-25
9-5	Common Functions for Single-axis Control	9-26
9-5-1	Positions	9-26
9-5-2	Velocity	9-28
9-5-3	Acceleration and Deceleration	9-29
9-5-4	Jerk	9-31
9-5-5	Specifying the Operation Direction	9-32
9-5-6	Re-executing Motion Control Instructions	9-35
9-5-7	Multi-execution of Motion Control Instructions (Buffer Mode)	9-41
9-6	Multi-axes Coordinated Control	9-46
9-6-1	Outline of Operation	9-46
9-6-2	Linear Interpolation	9-48


9-6-3	Circular Interpolation	9-49
9-6-4	Stopping Under Multi-axes Coordinated Control	9-50
9-6-5	Overrides for Multi-axes Coordinated Control	9-51
9-7	Common Functions for Multi-axes Coordinated Control	9-53
9-7-1	Velocity Under Multi-axes Coordinated Control	9-53
9-7-2	Acceleration and Deceleration Under Multi-axes Coordinated Control	9-54
9-7-3	Jerk for Multi-axes Coordinated Control	9-55
9-7-4	Re-executing Motion Control Instructions for Multi-axes Coordinated Control	9-56
9-7-5	Multi-execution (Buffer Mode) of Motion Control Instructions for Multi-axes Coordinated Control	9-56
9-8	Other Functions	9-65
9-8-1	Changing the Current Position	9-65
9-8-2	Torque Limit	9-66
9-8-3	Latching	9-66
9-8-4	Zone Monitoring	9-67
9-8-5	Software Limits	9-68
9-8-6	Following Error Monitoring	9-69
9-8-7	Following Error Counter Reset	9-70
9-8-8	Axis Following Error Monitoring	9-70
9-8-9	In-position Check	9-71

9-1 Single-axis Position Control

The MC Function Module can be connected to OMRON G5-series Servo Drives with built-in EtherCAT communications to implement position control, velocity control, and torque control. This section describes positioning operation for single axes.

9-1-1 Outline of Operation


The single-axis control function of the MC Function Module consists of control for motion profile commands and synchronized control. There are three Control Modes for motion profile commands: position control, velocity control, and torque control. In synchronized control, the slave axis (i.e., the axis being controlled) operates in a synchronized relationship to the master axis, as expressed by a cam profile curve or a gear ratio. Manual operations such as jogging and homing are also supported.



Note You can use the command position or actual position as the input to the synchronization processing.

9-1-2 Absolute Positioning


Absolute positioning specifies the absolute coordinates of the target position in relation to home. You can perform positioning, such as shortest way positioning on a rotary table, by setting the Count Mode to Rotary Mode and specifying the operation direction.



For details, refer to the MC_MoveAbsolute (Absolute Positioning) and MC_Move (Positioning) instructions in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-1-3 Relative Positioning

Relative positioning specifies the distance from the actual position. You can specify a travel distance that exceeds the ring counter range by setting the Count Mode to Rotary Mode.




For details, refer to the MC_MoveRelative (Relative Positioning) and MC_Move (Positioning) instructions in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-1-4 Interrupt Feeding


Interrupt feeding feeds the axis at the specified velocity and for the specified distance from the actual position when a trigger signal occurs. You can also select to output an error if the trigger signal does not occur within the specified travel distance when you specify either absolute or relative travel. Feeding is not affected by following error. This is achieved by using the latch function of the Servo Drive to determine the actual position when the trigger signal occurs. You can also use the window function to disable trigger signals that occur outside of a specified position range. For applications such as wrapping machines, this enables feeding only on trigger signals for printed marks on films and eliminates other influences.

● Motion Relative to the Actual Position

Feeding for a Specified Distance in the Moving Direction



Feeding for a Specified Distance in the Direction Opposite to the Moving Direction



If decelerating to a stop after a reverse turn is specified for the Operation Selection at Reversing axis parameter, an acceleration/deceleration curve is used when reversing.

For details, refer to the MC_MoveFeed (Interrupt Feeding) instruction in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-1-5 Stopping

Functions to stop axis operation include immediate stop input signal and limit input signals connected to the Servo Drive, stop functions of motion control instructions in the user program, and stopping due to errors.

Stopping for Servo Drive Input Signals

Axis motion is stopped for the immediate stop input signal or a limit input signal from the Servo Drive. You can select the stop method with the Sysmac Studio.

● Immediate Stop Input

Stop processing in the MC Function Module is executed according to the state of the Servo Drive input signals. You can select one of the following stopping methods for the MC Function Module.

- Immediate stop
- Immediate stop and error reset
- Immediate stop and Servo OFF



Precautions for Correct Use

The immediate stop input for the OMRON G5-series Servo Drive also causes an error and executes stop processes in the Servo Drive itself.

● Limit Inputs (Positive Limit Input or Negative Limit Input)

Stop processing in the MC Function Module is executed according to the state of the Servo Drive input signals. You can select one of the following stopping methods for the MC Function Module.

- Immediate stop
- Deceleration stop
- Immediate stop and error reset
- Immediate stop and Servo OFF



Precautions for Correct Use

- If the limit input signal is ON when a single-axis operation instruction is executed, you can start motion in the direction opposite to the limit input signal, but if you attempt a motion in the same direction, an error will occur and the instruction is not executed.
- If the limit input for any of the axes in an axes group is ON, an axes group operation instruction cannot be executed for that axes group.



Additional Information

- You must set up the Servo Drive in order to use the input signals from the Servo Drive. An OMRON G5-series Servo Drive with built-in EtherCAT communications has an immediate stop input and limit input assigned in its default settings.
- Refer to *A-1 Connecting the Servo Drive* for setting examples for connection to an OMRON G5-series Servo Drive.

Stopping with Motion Control Instructions

Use the MC_Stop or MC_ImmediateStop instruction to stop single-axis operation.

● MC_Stop Instruction

You can specify the deceleration rate and jerk for single-axis control and synchronized control to decelerate to a stop. Specify a deceleration rate of 0 to send a command that immediately stops the Servo Drive. Other operation commands are not acknowledged while decelerating to a stop for this instruction and while the input variable *Execute* is TRUE.

● MC_ImmediateStop Instruction

You can perform an immediate stop for single-axis control or synchronized control functions. You can also execute this instruction on axes that are enabled in an axes group.

For details, refer to the MC_Stop and MC_ImmediateStop instructions in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).



Additional Information

When the input variable *Enable* to the MC_Power (Servo ON) instruction changes to FALSE, the MC Function Module immediately stops the command value and turns OFF the Servo. When the Servo is turned OFF, the Servo Drive will operate according to the settings in the Servo Drive.

Stopping Due to Errors or Other Problems

● Stopping for Errors during Single-axis Operation

When an error occurs during single-axis operation, the axis will stop immediately or decelerate to a stop depending on the error. Refer to *11-2-2 Error Descriptions* for details on the stop method for each error.

● Stopping for a Software Limit

To stop for a software limit, set the Software Limits axis parameter. You can select from the following stop methods for the software limits.

- Enabled for command position. Decelerate to a stop.
- Enabled for command position. Immediate stop.
- Enabled for actual position. Decelerate to a stop.
- Enabled for actual position. Immediate stop.

Refer to *9-8-5 Software Limits* for details on software limits.

● Stopping Due to Excessively Long Motion Control Period

If motion control processing does not end within two periods, it is considered to be an excessive control period. Control will be stopped immediately.

● Errors That Cause the Servo to Turn OFF

An immediate stop is performed if an error occurs that causes the Servo to turn OFF. When the Servo is turned OFF, the Servo Drive will operate according to the settings in the Servo Drive.

● Stopping Due to Start of MC Test Run

All axes will decelerate to a stop at their maximum deceleration if a MC Test Run is started from the Sysmac Studio.

● Stopping Due to End of MC Test Run

All axes will decelerate to a stop at their maximum deceleration if a MC Test Run is stopped from the Sysmac Studio.

- Click the **Stop MC Test Run** Button on the MC Test Run Tab Page of the Sysmac Studio.
- Close the MC Test Run Tab Page on the Sysmac Studio.
- Exit the Sysmac Studio.

● Stopping Due to Change in CPU Unit Operating Mode

All axes will decelerate to a stop at their maximum deceleration if the CPU Unit operating mode changes.




Additional Information


- When RUN mode changes to PROGRAM mode, any motion control instructions for current motions are aborted. The *CommandAborted* output variable from the instructions remains FALSE. The Servo remains ON even after changing to PROGRAM mode.
- If the operating mode returns to RUN mode while a deceleration stop is in progress after the operating mode changes from RUN to PROGRAM mode, the output variables from motion control instructions are cleared. The *CommandAborted* output variables from the motion control instructions therefore remain FALSE.
- The save process will continue during a save for the MC_SaveCamTable Instruction.

Stop Method


- Deceleration Stop




- Immediate Stop



- Immediate Stop and Error Reset



- Immediate Stop and Servo OFF




Stop Priorities

The priorities for each stop method are listed in the following table. If a stop with a higher priority stop method occurs while stopping, the stop method will switch to the higher priority method.

Stop method	Priority (higher numbers mean higher priority)
Immediate stop and Servo OFF	4
Immediate stop and error reset	3
Immediate stop	2
Deceleration stop	1

Example:

The following figure is an example of an immediate stop when the limit input signal is ON and the immediate stop input changes to ON during a deceleration to a stop.




9-1-6 Override Factors

You can use the MC_SetOverride instruction to set override factors for the motion of the axes that are currently in motion. The velocity override factor is set as a percentage of the target velocity. It can be set between 0% and 500%. If an override factor of 0% is set for the target velocity, operating status will continue with the axis stopped as a velocity of 0. The set override factor is read as long as the overrides are enabled. If the overrides are disabled, the override factors return to 100%. If the maximum velocity is exceeded when an override factor is changed, the maximum velocity for the axis is used.

● **Overriding the MC_MoveAbsolute Instruction**

An example of a time chart for using the Set Override Factors instruction for the MC_MoveAbsolute (Absolute Positioning) instruction is given below.

Previous Instruction: MC_MoveAbsolute



For details, refer to the MC_SetOverride (Set Override Factors) instruction in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-2 Single-axis Synchronized Control


This section describes the operation of synchronized control for single axes.

9-2-1 Overview of Synchronized Control

Synchronous control synchronizes the position of a slave axis with the position of a master axis. The command position or actual position of any axis can be specified for the master axis. If the command velocity for the slave axis exceeds the maximum velocity that is set in the axis parameters, the command is performed at the maximum velocity of the axis. If this occurs, any insufficient travel distance is distributed and output in the following periods.

9-2-2 Gear Operation

This function specifies the gear ratio between the master axis and the slave axis and starts operation. Start gear operation with the MC_GearIn (Start Gear Operation) instruction. End synchronization with the MC_GearOut (End Gear Operation) instruction or the MC_Stop instruction.




You can set the gear ratio numerator, gear ratio denominator, position type, acceleration rate, and deceleration rate for the slave axis to operate. For the master axis, you can specify the command position, actual position, or most recent command position.

For details on gear operation, refer to the MC_GearIn (Start Gear Operation), MC_GearOut (End Gear Operation), and MC_Stop instructions in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).


9-2-3 Positioning Gear Operation

This function specifies the gear ratio between the master axis and the slave axis and starts operation. Positioning gear operation allows you to set the positions of the master and slave axes at which to start synchronization. Start positioning gear operation with the MC_GearInPos instruction. End synchronization with the MC_GearOut instruction or the MC_Stop instruction.



You can set the gear ratio numerator, gear ratio denominator, position type, acceleration rate, and deceleration rate for the slave axis to operate. For the master axis, you can specify the command position, actual position, or most recent command position.



After operation starts, the slave axis uses the velocity of the master axis times the gear ratio for its target velocity, and accelerates/decelerates accordingly. The slave axis is in the catching phase until it reaches the slave axis sync start position. The slave axis enters the *InGear* phase after it reaches the slave sync start position. For either, the position of the slave axis is synchronized with the master axis.



For details on positioning gear operation, refer to the MC_GearInPos (Positioning Gear Operation), the MC_GearOut (End Gear Operation), and the MC_Stop instructions in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-2-4 Cam Operation

Cam operation synchronizes the position of the slave axis with the master axis according to a cam table. Start cam operation with the MC_CamIn (Start Cam Operation) instruction. End cam operation with the MC_CamOut (End Cam Operation) instruction or the MC_Stop instruction. Create a cam table using the Cam Editor in the Sysmac Studio and download it to the CPU Unit. Use the Synchronization menu command of the Sysmac Studio to download the project to the CPU Unit.



For details on cam operation, refer to the MC_CamIn (Start Cam Operation), MC_CamOut (End Cam Operation), and MC_Stop instructions in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

For details on the Cam Editor, refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504).


9-2-5 Cam Tables

This section describes the cam tables that are used for cam operation.

Cam Table Terminology

Term	Description
cam operation	An operation that takes one master axis and one slave axis and follows the cam profile curve to derive the displacement of the slave axis from the phase of the master axis.
cam profile curve	A curve that shows the relationship between phases and displacements in a cam operation. Cam profile curves are used in the Cam Editor. The cam profile curve is created on the Sysmac Studio. You can use the cam profile curve with a cam data variable after the cam profile curve is downloaded to the CPU Unit. Use the Synchronization menu command of the Sysmac Studio to download the project to the CPU Unit.
cam block	You can select a cam curve in this block. It represents the area between the end point of the previous cam block and the end point of the current cam block.
cam curve	A curve that represents the cam characteristics. You can select a cam curve for each cam block. The Sysmac Studio calculates the phase widths and displacement widths from the specified points and creates the actual cam profile curve. You can choose from different curves, such as straight line, parabolic, and trapezoid.
cam data	Data made up of phases (master axis) and displacements (slave axis) for cam operation.
cam data variable	A variable that represents the cam data as a structure array.
cam table	A data table that contains cam data. If phase data is not in ascending order the cam table is treated as an illegal cam table.
cam start point	The first point in the cam data.
cam end point	The last point of valid cam data in the cam data. If the cam end point is less than the number of cam data, all phases and displacements after the cam end point will be 0.
cam block start point	The start point for a cam block. It is the same as the cam start point at the start of the cam operation. If the cam profile curve continues, this will be the same as the cam block end point.
cam block end point	The end point for a cam block. It is the same as the cam end point at the end of the cam operation. If the cam profile curve continues, this will be the same as the cam block start point. The cam block end point is defined as (horizontal axis, vertical axis) = (phase end point, displacement end point).
original cam data	Cam data that is created by dividing up the cam profile curve in the Cam Editor.
program-modified cam data	The cam data changed by the user program while the CPU Unit is in operation.
master axis	The axis that serves as the input to the cam operation. You can specify either Linear Mode or Rotary Mode.
slave axis	The axis that serves as the output from the cam operation. You can specify either Linear Mode or Rotary Mode.
phase	The relative distance on the master axis from the start point of the cam table.
displacement	The relative distance on the slave axis from the master sync start position.
valid cam data	The cam data other than the cam start point and other than data where the phase is 0.
invalid cam data	The cam data other than the cam start point where the phase is 0.
number of valid cam data	The number of sets of cam data.
maximum number of cam data	The maximum number of sets of cam data that the cam table can contain.
cam data index	The number of the cam data that is executed.

Term	Description
cam table start position	The absolute position of the master axis that corresponds to the cam start point (phase = 0).
master sync start position	The master start distance where the slave axis starts cam operation represented as either an absolute position or relative position. The relative position is based on the cam start point position.
start mode	A specification of whether to represent the master sync start position as an absolute position or relative position.
null cam data	Cam data that can be set after the end point where the phase and displacement are 0.
connecting velocity	The connecting velocity that is used to connect cam profile curves. The connecting velocity cannot be specified for some curves.
connecting acceleration	The acceleration rate that is used to connect cam profile curves. The connecting acceleration cannot be specified for some curves.
phase pitch	The width when dividing the cam profile curve by phases (horizontal axis). The points after dividing the curve into the phase pitch correspond to the cam data in the cam table. You must specify the phase pitch for each cam block.




Cam Tables

The MC Function Module defines a single element of data consisting of the phase of the master axis and the displacement of the slave axis as one cam data. A cam table is defined as the combination of multiple sets of cam data. The cam table is created with the Cam Editor in the Sysmac Studio. You can modify cam data in the cam table from the user program.

The phases and displacements in the cam data that makes up the cam table are represented as relative distances from the start point 0.0. During cam operation, the command position sent to the slave axis is the displacement determined by interpolating linearly between the two cam data elements adjacent to the phase of the master axis. The more cam data there is in the cam table, the more accurate the trajectory and the smoother the cam profile curve will be.

Cam table		Cam data index
Phase	Displacement	
Cam start point → 0	0	← 0
Cam data → 60	200	1
	120	2
	180	3
	240	4
	300	5
Cam end point → 360	0	6



Precautions for Correct Use

- Make sure that the cam data is arranged in the cam table so that the phases are in ascending order. An instruction error occurs if a cam operation instruction is executed when the phases are not in ascending order.
- Cam data variables are global variables. You can therefore access or change the values of cam data variables from more than one task. If you change the values of cam data variables from more than one task, program the changes so that there is no competition in writing the value from more than one task.
- If you use exclusive control of global variables between tasks for a cam data variable, do not use the cam data variable for motion control instructions in a task that does not control the variable. An Incorrect Cam Table Specification error (error code: 5439 hex) will occur.

Cam Table Specifications

Item	Description
Maximum number of cam data per cam table	65,535 points
Maximum size of all cam data	1,048,560 points*1
Maximum number of cam tables	640 tables*2
Switching cam operation	You can switch to a different cam operation by executing a motion control instruction
Overwriting cam data	Cam data can be overwritten from the user program
Saving cam data	Cam data can be saved to non-volatile memory by using the Save Cam Table instruction.
Information attached to the cam data	Information can be downloaded or uploaded for display in the Cam Editor*3
Timing to load cam data to main memory	<ul style="list-style-type: none"> • When the data is downloaded from the Sysmac Studio • When power is turned ON

*1 If 65,535 points are used for each cam table, there will be a maximum of 16 cams. A resolution of 0.1° allows for a maximum of 3,600 points per cam table for a maximum of 291 cams.

*2 The total size is 10 MB max.

*3 Use the Synchronization menu command of the Sysmac Studio to upload and download the project.

Data Type of Cam Tables

A cam table is declared as an array of cam data structures. The type declaration for the cam data structure is shown below.

```


TYPE
  (*Cam data structure*)
  _sMC_CAM_REF :
  STRUCT
    Phase      : REAL;    (*Phase*)
    Distance   : REAL;    (*Displacement*)
  END_STRUCT;
END_TYPE
    
```

You must create the cam data with the Cam Editor in the Sysmac Studio and then specify the name of the cam table and the number of cam data (i.e., the size of the array). For example, to make a cam table called *MyCam1* with 1,000 points use the following declaration.

```

VAR
  (*Cam table*)
  MyCam1      : ARRAY [0..999] OF _sMC_CAM_REF;
END_VAR
    
```


The following notation is used to specify *MyCam1* for a cam operation instruction. In this example, the master axis is *Axis1* and the slave axis is *Axis2*.



An error will occur if the specified cam table does not exist in the Controller. You can also specify the same cam table for more than one axis.

Switching Cam Tables

You can switch cam tables by re-executing the cam operation instruction during cam operation. After switching, cam operation will be performed with the cam table you specified for re-execution of the instruction. The *EndOfProfile* and *Index* output variables from the MC_CamIn instruction are output according to the new cam table.



Precautions for Correct Use

- The cam table you want to switch to must be saved to non-volatile memory before it can be used.

- Switching cam tables during cam operation will cause discontinuous velocities. Adjust the timing for switching the cam table to avoid excessive velocity discontinuity.

camLoading/Saving Cam Data and Saving Cam Tables

Cam data can be loaded and saved from the user program just like any other variables. For example, you can use *MyCam1[0].Phase* to specify the phase and *MyCam1[0].Distance* to specify the displacement in the first array elements of a cam table named MyCam1. Cam data overwritten from the user program can be saved to the non-volatile memory in the CPU Unit as a cam table by executing the MC_SaveCamTable instruction.



Precautions for Correct Use

- Overwritten cam data will be lost if the CPU Unit is turned OFF or the cam data is downloaded from the Sysmac Studio before the Save Cam Table instruction is executed or if the instruction fails to save the data for any reason.
- Overwritten cam data will be lost if the CPU Unit is turned OFF before the Save Cam Table instruction is executed or if the instruction fails to save the data for any reason. Be careful not to lose the overwritten data when overwriting cam data from the user program in the CPU Unit.
- Cam data saved to non-volatile memory can be loaded by using the upload function of the Sysmac Studio.
- Use the Synchronization menu command of the Sysmac Studio to upload and download the project.

For details on arrays, refer to the *NJ-series CPU Unit Software User's Manual* (Cat. No. W501).

For details on the Save Cam Table instruction, refer to the MC_SaveCamTable instruction in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Updating Cam Table Properties

The MC Function Module must identify the cam end point of the cam table. If an overwrite is performed from the user program during cam operation and the number of valid cam data changes, you must update the number of valid cam data to the latest value. Use the MC_SetCamTableProperty instruction for this.

The cam end point is the data located one cam data before the first cam data with a phase of 0 after the start point in the cam table. All cam data after phase 0 is detected will be invalid.

For example, refer to the following cam table. The *EndPointIndex* (End Point Index) output variable is 999 and the *MaxDataNumber* (Maximum Number of Cam Data) output variable is 5,000 from the MC_SetCamTableProperty instruction.

Cam data structure array	Phase	Displacement	
MyCam1 [0]	0	0	Cam start point
.	.	.	
.	.	.	
.	.	.	
MyCam1 [997]	359.8	2	Valid data
MyCam1 [998]	359.9	1	
MyCam1 [999]	360.0	0	Cam end point
MyCam1 [1000]	0	0	
.	.	.	Invalid data
.	.	.	
.	.	.	
.	.	.	
MyCam1 [4999]	0	0	

Maximum number of data: 5,000



Precautions for Correct Use


- You cannot change the maximum number of cam data from the user program.
- Execute this instruction after overwriting the cam data in any way that changes the number of valid cam data. If the number of valid cam data is not updated, the cam operation and the operation of the *EndOfProfile* (End of Cam Cycle) of the MC_CamIn instruction may not be as expected.

For details on the Set Cam Table Properties instruction, refer to the MC_SetCamTableProperty (Set Cam Table Properties) instruction in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-2-6 Synchronous Positioning

This function performs positioning using a trapezoidal curve while synchronizing the specified slave axis to the specified master axis. This is a type of electronic cam, but it does not use cam tables created in the Cam Editor. Operation starts when the MC_MoveLink (Synchronous Positioning) instruction is executed. Use the MC_Stop instruction to stop the axes in motion. Operation is performed for the *Slave* (Slave Axis) and the following are set: *Master* (Master Axis), *MasterDistance* (Master Distance), *MasterDistanceInACC* (Master Distance In Acceleration), *MasterDistanceInDEC* (Master Distance In Deceleration), *SlaveDistance* (Slave Axis Travel Distance), and *MasterStartDistance* (Master Following Distance). The command position or actual position can be specified for the master axis. You can specify one of the following as the start condition for synchronous operation: start of instruction, when trigger is detected, or when master axis reaches the master following distance.

The velocity and position of the slave axis are determined by the ratio of the travel distances of the master axis and the slave axis as shown in the following figure. The sync start position shown in the following figure represents the position where the sync start condition is met.




For details on synchronous positioning, refer to the MC_MoveLink (Synchronous Positioning) and MC_Stop instructions in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-2-7 Combining Axes

The sum or difference of two command positions can be used as the command position for the slave axis. Operation starts when the MC_CombineAxes instruction is executed. Use the MC_Stop instruction to stop axes in motion.

The following figure is an example demonstrating operation when subtracting axes. *Slave* (Slave Axis) command current position = *Master* (Master Axis) command current position – *Auxiliary* (Auxiliary Axis) command current position)




For details on combining axes, refer to the MC_CombineAxes and MC_Stop instructions in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-2-8 Master Axis Phase Shift

The phase of the master axis as viewed from the slave axis can be shifted for the current instruction. The shift amount as viewed from the slave axis is a relative amount. During synchronization, the slave axis will synchronize to the relative distance of the master axis. You can execute the MC_Phasing (Shift Master Axis Phase) instruction to shift the phase for a synchronized control instruction.

You can specify the phase shift amount, target velocity, acceleration rate, deceleration rate, and jerk for the MC_Phasing (Shift Master Axis Phase) instruction.




For details on the shift master axis phase function and the synchronized control instructions for which a master axis phase shift can be applied, refer to the MC_Phasing (Shift Master Axis Phase) instruction in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-3 Single-axis Velocity Control

This section describes the operation of velocity control for single axes.

9-3-1 Velocity Control

Velocity control is used to constantly move an axis at the specified velocity. You can also specify the acceleration rate, deceleration rate, and jerk. To stop an axis, use the MC_Stop instruction or execute another motion instruction. If you specify a target velocity of 0, the axis will not move but the axis status will indicate that it is moving. If any other motion control instruction is executed with multi-execution of instructions during velocity control, the operation will switch only after reaching the target velocity.



The MC Function Module uses Position Control Mode of the Servo Drive and sends target position commands to achieve the specified target velocity.


The position control loop is enabled in the Servo Drive. Therefore, as the command velocity slows down, e.g., due to disturbance, and the following error increases, the velocity will change to eliminate this following error.

For details, refer to the MC_MoveVelocity (Velocity Control) instruction in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).


9-3-2 Cyclic Synchronous Velocity Control

The control mode of the Servo Drive is set to Velocity Control Mode and a command speed is output every control period. To stop an axis, use the MC_Stop instruction or execute another motion control instruction. If you specify a target velocity of 0, the axis will not move but the axis status will indicate that it is moving.

MC_SyncMoveVelocity Instruction



MC_Stop Instruction




The Servo Drive will receive commands in the velocity control loop. Therefore, if any disturbance causes the velocity to decrease below the command velocity, no change in velocity will occur to remove the following error.

For details, refer to the MC_SyncMoveVelocity (Cyclic Synchronous Velocity Control) instruction in the *NJ-series Motion Control Instructions Reference Manual (Cat. No. W508)*.


9-4 Single-axis Torque Control

Torque control continuously applies the specified amount of torque. You can use *TorqueRamp* to specify the rate of change of the torque until the *Torque* (Target Torque) is reached. To stop an axis, use the *MC_Stop* instruction or execute another motion instruction. If you specify a *Torque* (Target Torque) of 0, the axis will not move but the axis status will indicate that it is moving.

Example 1: Direction Designation = Positive Direction



Example 2: Direction Designation = Negative Direction



The MC Function Module uses the Torque Control Mode of the Servo Drive. The Servo Drive receives the torque command value from the MC Function Module in the torque control loop and to control the torque. You can specify the velocity limit value for the Servo Drive in the *Velocity* (Velocity Limit) input variable to the motion control instruction. You can use this to limit high-speed revolution of the motor when the load on the motor is low in Torque Control Mode.



Precautions for Correct Use

To be safe, always set a velocity limit value for torque control.

For details, refer to the *MC_TorqueControl* instruction in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-5 Common Functions for Single-axis Control

This section describes the common functions used for single-axis control.


9-5-1 Positions

Types of Positions

The MC Function Module uses the following two types of positions.

Type of position	Definition
Command position	This is the position that the MC Function Module outputs to control an axis.
Actual position	The actual position as input from the Servo Drive or encoder input.

The following figure shows the relationship between the command position and the actual position.



The command position and actual position share the following items.

Item	Command position	Actual position
Count Mode	You can set Linear Mode or Rotary Mode.	The same Count Mode is used as for the command position.
Position increment	You can set one of the following: mm, μm , nm, inch, degree, or pulse.	The unit is the same as the unit of the command position.
Software limits	You can set the range of operation of the software.	The range is the same as the range for the command position.
Changing the current position	You can change the actual position to any desired position.	This value will be set to the same position as the command position.*
Defining home	Home is either defined or undefined.	The status of home is the same as the command position.

* If there is any following error before the change, the following error value is maintained in the actual position.

Axis Parameters That Are Related to Positions

Parameter name	Function	Setting range	Default
In-position Range	Set the in-position width. (Unit: command units)	Non-negative long reals	10
In-position Check Time	Set the in-position check time in milliseconds. Set 0 to check for the end of positioning only when you define the home position during homing and not check positioning at other times. (Unit: ms)	0 to 10,000	0
Software Limits	Select the software limit function. 0: Disabled. 1: Deceleration stop for command position 2: Immediate stop for command position 3: Deceleration stop for actual position 4: Immediate stop for actual position	0 to 4	0
Positive Software Limit	Set the software limit in the positive direction. (Unit: command units)	Long reals	2,147,483,647
Negative Software Limit	Set the software limit in the negative direction. (Unit: command units)	Long reals	-2,147,483,648
Following Error Over Value	Set the excessive following error check value. Set 0 to disable the excessive following error check. (Unit: command units)	Non-negative long reals	0
Following Error Warning Value	Set the following error warning check value. Set 0 to disable the following error warning check. (Unit: command units)	Non-negative long reals that are less than or equal to the Following Error Over Value	0

Specifying Target Positions for Axis Operations

The actual position or distance for a positioning motion is specified with the *Position* (Target Position) and *Distance* (Travel Distance) input variables to the motion control instruction.

Monitoring Positions

You can read Axis Variables in the user program to monitor positions.

Variable name	Data type	Meaning	Function
_MC_AX[0-63].Cmd.Pos	LREAL	Command Current Position	This is the current value of the command position. When the Servo is OFF and the mode is not the position control mode, the actual current position is output.
_MC_AX[0-63].Act.Pos	LREAL	Actual Current Position	This is the actual current position.

9-5-2 Velocity

Types of Velocities

The following two types of axis velocities are used in the MC Function Module.

Velocity type	Definition
Command velocity	This is the velocity that the MC Function Module outputs to control an axis.
Actual velocity	This is the velocity calculated in the MC Function Module based on the actual position input from the Servo Drive or encoder input.*

* This value is given if the Velocity actual value (606C hex) is mapped in the PDOs and assigned to the Actual Current Velocity.

Velocity Unit

A velocity is given in command units/s. The command unit is the value obtained from unit conversion of the position display unit and the electronic gear.

Axis Parameters That Are Related to Velocities

Parameter name	Function	Setting range	Default
Maximum Velocity	Specify the maximum velocity for the axis. If a target velocity that exceeds the maximum velocity is specified for an axis motion instruction, the axis will move at the maximum velocity.	Positive long reals	400,000,000
Maximum Jog Velocity	Specify the maximum jog velocity for the axis. If a target velocity that exceeds the maximum jog velocity is set for a jog instruction, the axis will move at the maximum jog velocity.	Positive long reals	1,000,000
Velocity Warning Value	Set the percentage of the maximum velocity at which to output a velocity warning for the axis. No velocity warning is output if 0 is set. (Unit: %)	0 to 100	0
Actual Velocity Filter Time Constant	Set the time period to calculate the average travel of the actual velocity in milliseconds. The average travel is not calculated if 0 is set. (Unit: ms) Use this to reduce variations in the actual current velocity when axis velocity is slow.	0 to 100	0

Specifying Target Velocities for Axis Operations

The velocity used in an actual positioning motion is specified by the *Velocity* (Target Velocity) input variable to the motion control instruction.

Monitoring Velocities

You can read Axis Variables in the user program to monitor velocities.

Variable name	Data type	Meaning	Function
_MC_AX[0-63].Cmd.Vel	LREAL	Command Current Velocity	This is the current value of the command velocity. A plus sign is added during travel in the positive direction, and a minus sign is added during travel in the negative direction.
_MC_AX[0-63].Act.Vel	LREAL	Actual Current Velocity	This is the actual current velocity. A plus sign is added during travel in the positive direction, and a minus sign is added during travel in the negative direction.

9-5-3 Acceleration and Deceleration

Unit of Acceleration and Deceleration Rates

Acceleration rates and deceleration rates are given in command units/s². The command unit is the value obtained from unit conversion of the position display unit and the electronic gear.

Axis Parameters That Are Related to Acceleration and Deceleration

Parameter name	Function	Setting range	Default
Maximum Acceleration	Set the maximum acceleration rate for an axis operation command. There will be no limit to the acceleration rate if 0 is set. (Unit: command units/s ²)	Non-negative long reals	0
Maximum Deceleration	Set the maximum deceleration rate for an axis operation command. There will be no limit to the deceleration rate if 0 is set. (Unit: command units/s ²)	Non-negative long reals	0
Acceleration/Deceleration Over	Set the operation for when the maximum acceleration/deceleration rate would be exceeded after excessive acceleration/deceleration during acceleration/deceleration control of the axis because stopping at the target position is given priority. 0: Use rapid acceleration/deceleration. (Blending is changed to Buffered.) 1: Use rapid acceleration/deceleration. 2: Minor fault stop	0 to 2	0
Acceleration Warning Value	Set the percentage of the maximum acceleration rate at which to output an acceleration warning for the axis. No acceleration warning is output if 0 is set. (Unit: %)	0 to 100	0
Deceleration Warning Value	Set the percentage of the maximum deceleration rate at which to output a deceleration warning for the axis. No deceleration warning is output if 0 is set. (Unit: %)	0 to 100	0

Specifying Acceleration and Deceleration Rates for Axis Operation


The acceleration and deceleration rates used in an actual positioning motions are specified by the *Acceleration* (Acceleration Rate) and *Deceleration* (Deceleration Rate) input variables to the motion control instruction.

Monitoring Acceleration and Deceleration Rates

You can read Axis Variables in the user program to monitor acceleration and deceleration rates.

Variable name	Data type	Meaning	Function
_MC_AX[0-63].Cmd.AccDec	LREAL	Command Current Acceleration/Deceleration	This is the current value of the command acceleration/deceleration rate. A plus sign is added for acceleration, and a minus sign is added for deceleration.

Example of Acceleration/Deceleration Operation



If you specify a short travel distance or a low acceleration/deceleration rate, the target velocity may not be reached. If the target position is exceeded after re-execution of the motion control instruction with the newly updated acceleration or deceleration rate, positioning is performed at an acceleration or deceleration rate that will enable stopping at the target position.

9-5-4 Jerk

The jerk specifies the rate of change in the acceleration rate or deceleration rate. If the jerk is specified, the velocity waveform during acceleration will be an S-curve, which will reduce the shock on the machine.



Additional Information

Jerk is also called jolt, surge and lurch.

Jerk Unit

Jerk is given in command units/s³. The command unit is the value obtained from unit conversion of the position display unit and the electronic gear.

Specifying Jerk for Axis Motion

The jerk used in an actual positioning motion is specified with the *Jerk* input variable to the motion control instruction. This value is used for both acceleration and deceleration and can be set for all operations except for synchronized control operations.

Use the following formula to calculate the value to set for the jerk.

$$\text{Jerk} = \text{Acceleration rate} \div (\text{Time of acceleration} \times \text{Ratio of time to apply jerk during acceleration}/2)$$


Jerk is applied in two sections: at the start of acceleration and at the end of acceleration. The time that jerk is applied is therefore divided by 2.

● Example of Velocity Control When Jerk Is Specified

The acceleration will change at a constant rate over the range where jerk is specified. The command velocity will form a smooth S curve. A fixed acceleration rate is used in areas where the jerk is set to 0. This command velocity will form a straight line.

Example: Acceleration of 25,000 mm/s², Acceleration Time of 0.1 s, and a Jerk Application Rate of 50%

$$\text{Jerk} = 25,000 / (0.1 \times 0.5 / 2) = 1,000,000 \text{ (mm/s}^3\text{)}$$



Monitoring Jerk

You can read Axis Variables in the user program to monitor jerk.

Variable name	Data type	Meaning	Function
_MC_AX[0-63].Cmd.Jerk	LREAL	Command Current Jerk	This is the current value of the command jerk.

9-5-5 Specifying the Operation Direction


If you want to specify a rotation direction, such as shortest way, using an index table, set the Count Mode to Rotary Mode. Next, set the operation direction with the *Direction* input variable to the motion control instruction for an absolute position. You can specify any target position that is within one ring counter cycle and that is within the upper and lower limits of the ring counter. The *Direction* input variable will be ignored when the Count Mode is set to Linear Mode. Positioning will be performed to the target position.

The following table lists the different directions you can specify in the MC Function Module.

Direction	Operation
Shortest way	Motion starts in the direction where the command current position and the target position are closer to each other.
Positive direction	Motion starts in the positive direction.
Negative direction	Motion starts in the negative direction.
Current direction	Motion starts in the same direction as the previous operation.
No direction specified	Motion starts in the direction that does not pass through the upper and lower limits of the ring counter. With this direction specification, you can specify a target position that exceeds the upper or lower limits of the ring counter. If that occurs, relative positioning is performed using the difference between the target position and the command current position as the target distance. This enables you to perform multi-turn positioning on the ring counter.

Example for Shortest Way

The following example illustrates when positioning is performed towards a target position of -20 when the command current position is 50.




Additional Information

Moves in the same direction as the Current Direction specification if the travel distance is the same in the positive and negative directions.


Example for Positive Direction

The following example illustrates when positioning is performed towards a target position of -20 when the command current position is 50.




Example for Negative Direction

The following example illustrates when positioning is performed towards a target position of -20 when the command current position is 50.



Example for Current Direction

The following example illustrates when positioning is performed towards a target position of -20 when the command current position is 50 .



The direction of the previous operation is given in the Command Direction in the Axis Variable.




Precautions for Correct Use

Observe the following precautions on the operation direction of the previous operation.


- If the MC_Home instruction exceeds the point where the home input was detected and reverses operation, the opposite direction of the home input detection direction is used.
- If a homing compensation value is set for the MC_Home instruction, the direction moved for the compensation value is used.
- If an immediate stop is specified for the MC_TouchProbe (Enable External Latch) instruction, the latch position may be exceeded and the direction may be reversed.
- The direction may be reversed for the MC_MoveFeed (Interrupt Feeding) instruction.
- When the MC_ResetFollowingError instruction is executed, the error is set to zero, so the command direction is used.
- If an immediate stop is specified for an external input signal or resetting the error counter is specified for stopping for a limit input, the operation may reverse direction toward the position where the external input signal was received.

Example for No Direction Specification

The following example illustrates when positioning is performed towards a target position of -20 when the command current position is 50.



Similarly, the following example illustrates when the ring counter upper limit is 100, the lower limit is -70, the command current position is -20, and positioning is performed towards a target position of 290.



9-5-6 Re-executing Motion Control Instructions


This section describes how to modify input variables of the same instance of a motion control instruction during operation of a single axis and re-execute that instruction. The input variables *Position* (Target Position), *Distance* (Travel Distance), *Velocity* (Target Velocity), *Acceleration* (Acceleration Rate), *Deceleration* (Deceleration Rate), and *Torque* (Target Torque) and sometimes other input variables can be changed by re-execution. An instruction error will occur if you change an input variable that cannot be changed and attempt to re-execute the instruction. If you re-execute an instruction that has been buffered due to multi-execution of instructions, the input variables for the instruction in the buffer will change.

For details on input variables that can be changed, refer to the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).


Changing the Target Position

If you change the target position with re-execution, the operation may change depending on the timing of the change and the new target position. If the direction of motion reverses due to a change in the target position, you can choose to decelerate to a stop after a reverse turn or stop immediately after reversing with the Operation selection at Reversing axis parameter.

● When a Reverse Turn Does Not Occur for the New Command Value




● When a Reverse Turn Occurs for the New Command Value



● Triangular Control Patterns


The triangular control shown in the figure below may result if the travel distance is shortened due to a change in the target position.




● Excessive Deceleration Patterns

In the following case, priority is given to stopping at the target position. Therefore, the deceleration rate will exceed the specified deceleration rate. If the deceleration rate exceeds the rate that is set in the Maximum Deceleration axis parameter, the operation set in the Acceleration/Deceleration Over axis parameter setting is performed.


If There Is No Reverse Turn and the Target Position Would Be Exceeded at the Specified Deceleration Rate



If There Is A Reverse Turn and Decelerating to a Stop Would Exceed a Software Limit




If There Is A Reverse Turn and Decelerating to a Stop Would Result in Command Current Position Overflow or Underflow



Changing the Travel Distance

Even if you change the travel distance and re-execute the MC_MoveRelative (Relative Positioning) instruction, positioning is performed for the new travel distance in reference to the position where the motion first started. However, if the instruction is executed again just before positioning is completed, it may be executed as a new instruction rather than as a re-execution of the same instruction.



Precautions for Correct Use

Do not change the travel distance and re-execute the instruction just before the end of positioning.

Changing the Target Velocity

The operation is changed only during acceleration (including acceleration for triangular control) and constant-velocity motion. Changes are also accepted when the axis is decelerating, but operation is not affected.


Changing the Acceleration Rate

The operation is changed only during acceleration and acceleration during triangular control. If it is changed when moving at a constant speed, the changed rate applies to acceleration for an override. Changes are also accepted when the axis is decelerating, but operation is not affected.


Changing the Deceleration Rate

The deceleration rate is changed only during acceleration, constant-velocity motion, deceleration, triangular control, or during deceleration-exceed control. If the new deceleration rate causes the axis to exceed the target position, stopping at the target position is given the highest priority. Therefore, in this case, the actual deceleration rate will exceed the specified deceleration rate.

● Patterns Where Deceleration Rate Increases



● Patterns Where Deceleration Rate Decreases




Changing the Torque Command


The torque command value will change based on the torque ramp specification when you re-execute a motion control instruction.

Programming Example for Re-execution

This example demonstrates changing the target position from 1000 to 2000 for absolute positioning. In this example, the variable *Axis1Pos* is used as the input parameter to the target position. Specify the target position to 1000 with the MOV instruction and change *Axis1Execute* to TRUE to begin positioning. Specify the target position to 2000 during operation and change *Axis1Execute* to TRUE again to switch to a positioning operation for the new target position of 2000.



● **Timing Charts**



Precautions for Correct Use

For input variables that are not changed, always use the same values as before re-execution of the instruction.

9-5-7 Multi-execution of Motion Control Instructions (Buffer Mode)

You can execute another motion control instruction while an axis is moving. In the PLCopen technical specifications, this functionality is defined as Buffer Mode, but in the MC Function Module this is sometimes referred to as multi-execution of instructions. You can use multi-execution of instructions to execute multiple motion control instructions in sequence without stopping the overall motion.

The following terms are used in relation to multi-execution of instructions in the MC Function Module.

Term		Meaning
This manual	PLCopen	
Current instruction	Previous function block	The motion control instruction that was in operation just before executing the multi-execution instruction.
Buffered instruction	Next function block	A motion control instruction that was executed during an axis motion and is waiting to be executed.
Transit velocity	Blending	When blending is specified, it specifies the command velocity to use by the current instruction to move to the specified target position.

You can set the *BufferMode* (Buffer Mode Selection) input variable to motion control instruction to select one of the following Buffer Modes. The main difference between these modes is the timing at which the buffered instructions are executed and the transit velocity.

Buffer Mode	Description of operation
Aborting	The current instruction is aborted and the multi-executed instruction is executed.
Buffered	The buffered instruction is executed after the operation for the current instruction is normally finished.
Blending	The buffered instruction is executed after the target position of the current instruction is reached. In this mode, no stop is performed between the current instruction and the buffered instruction. You can select from the following transit velocities for when the current instruction reaches the target position.
Blending Low (low velocity)	The transit velocity is set to the target velocity of the current instruction or the buffered instruction, whichever is lowest.
Blending Previous (previous velocity)	The target velocity of the current instruction is used as the transit velocity.
Blending Next (next velocity)	The target velocity of the buffered instruction is used as the transit velocity.
Blending High (high velocity)	The transit velocity is set to the target velocity of the current instruction or the buffered instruction, whichever is highest.

The multi-execution instruction is buffered in the MC Function Module and will be executed at the specified *BufferMode* timing and transit velocity for both buffered and blending modes. There is one buffer for each axis. If aborting is specified, the instruction that was executed last is executed immediately, so it is not buffered.



Precautions for Correct Use


- Only one multi-execution instruction is buffered for each axis. If multi-execution is performed for two or more instructions, an instruction error will occur.
- Multi-execution of multi-axes coordinated control instructions (axes group instructions) is not possible for axes operating as a single axis. Similarly, multi-execution of single-axis control instructions is not possible for axes operating under multi-axes coordinated control (axes group instructions). An instruction error will occur if these rules are broken.

Aborting


This is the default mode. No buffering is performed in this mode. The current command is aborted and the new instruction is executed. Aborting Mode can be used for multi-execution of instructions for motion control instructions for both single-axis control and synchronized control.

● When a Reverse Turn Does Not Occur for the Command Position of the Multi-execution Instruction

Executing More than One Instruction during Constant-velocity Motion




Re-executing Instruction during Acceleration/Deceleration



● When a Reverse Turn Occurs for the Multi-execution Instruction Command Value


Decelerating to a Stop after Reversing



If an instruction is executed with multi-execution of instructions during acceleration, the axis starts deceleration according to the multi-execution timing.

If the travel distance upon reverse turn is small, triangular control is performed as it was for the first execution of the instruction.


Stopping Immediately after Reversing



If the instruction is executed with multi-execution of instructions during acceleration or deceleration, the axis stops immediately according to the multi-execution timing. This also occurs during deceleration.

Buffered

The buffered instruction remains in the buffer until the operation of the current instruction is finished. The buffered instruction is executed after the operation for the current instruction is normally ended.




Blending

The buffered instruction remains in the buffer until the target position of the current instruction is reached. The buffered instruction is executed after the current instruction's target position is reached. However, motion does not stop at this time. Operation transitions to the next instruction at the velocity specified with the *BufferMode* (Buffer Mode Selection) input variable. For relative travel, the final position will be the total of the values for both instructions. For absolute travel, the final position will be the target position of the second multi-execution instruction. The Acceleration/Deceleration Over axis parameter is used to select one of the following operations for when the target position would be exceeded with the values that are set in the Maximum Acceleration and Maximum Deceleration axis parameters.


- Use rapid acceleration/deceleration. (Blending is changed to Buffered.)
- Use rapid acceleration/deceleration.
- Minor fault stop

An example for an Acceleration/Deceleration Over operation is given below.


- Use Rapid Acceleration/Deceleration (Blending Is Changed to Buffered)



- Use Rapid Acceleration/Deceleration (Here, BufferMode is set to blend with previous.)



- Use Rapid Acceleration/Deceleration (Here, BufferMode is set to blend with next.)



In a blending mode you cannot combine single-axis and synchronized control.

● **Blending Low (Low Velocity)**


Operation is performed using the target position of the current instruction and the target velocity that is the slower of the target velocities for the current instruction and buffered instruction.

● **Blending Previous (Previous Velocity)**


Operation is performed with the target velocity of the current instruction until the target position of the current instruction is reached. Operation is performed after acceleration/deceleration to the target velocity of the buffered instruction once the target position is reached.

When the Direction of Operation Does Not Change


Cases Resulting in Acceleration



Cases Resulting in Deceleration




When the Direction of Operation Changes



● **Blending Next (Next Velocity)**

Operation is performed using the target position of the current instruction and the target velocity of the buffered instruction.



● **Blending High (High Velocity)**

Operation is performed using the target position of the current instruction and the target velocity that is the faster of the target velocities for the current instruction and buffered instruction.




9-6 Multi-axes Coordinated Control

This section describes the operation of multi-axes coordinated control. With the MC Function Module, you can set an axes group in advance from the Sysmac Studio to perform interpolation control for multiple axes.

9-6-1 Outline of Operation

Multi-axes coordinated control performs a motion with multiple related axes together as a single group to control the path of the target control object. The MC Function Module treats all axes that perform coordinated operation as an axes group. Axes groups are set from the Sysmac Studio. In the user program, turn ON the Servo for each axis and then enable the axes group that is going to perform the multi-axes coordinated control. The purpose of multi-axes coordinated control is the coordinated operation of all axes belonging to the target axes group. Therefore, you cannot execute any single-axis operation motion control instructions on the axes in an enabled axes group. Furthermore, if any error occurs for any axis in an axes group, all axes in the axes group will stop according to the setting of the Axis Group Stop Method group axes parameter.

The MC Function Module can perform linear interpolation with two to four axes or circular interpolation with two axes.




Additional Information

For devices that require you to modify the grouping of axes in motion to perform interpolation control, you must create multiple axes groups that include the axes to modify from the Sysmac Studio beforehand. After completing this step, you can execute by specifying the enabled axes groups from the user program during operation.

For details on axes groups, refer to *3-3 Axes Groups*.

Enabling and Disabling Axes Groups

To enable an axes group, specify the axes group for the MC_GroupEnable (Enable Axes Group) instruction. An instruction error will occur if you try to execute an axes group instruction when the axes group is still disabled. To disable an axes group, specify the axes group for the MC_GroupDisable (Disable Axes Group) instruction. When you disable an axes group that is in operation, all axes in that axes group will decelerate to a stop at the maximum deceleration rate that is specified in their axis parameter settings.



For details on enabling and disabling axes groups, refer to the MC_GroupEnable (Enable Axes Group) and MC_GroupDisable (Disable Axes Group) instructions in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Resetting Axes Group Errors

If an error occurs in an axes group, you can use the MC_GroupReset instruction to remove the error once you have eliminated the cause.

For details on resetting axes group errors, refer to the MC_GroupReset (Group Reset) instruction in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).


9-6-2 Linear Interpolation

Linear interpolation is used to move 2 to 4 of the logical axes A0 to A3 in a straight line between a start point and an end point. Either absolute or relative positioning is possible. You can specify the interpolation velocity, interpolation acceleration, interpolation deceleration, and jerk.

The MC Function Modules uses the following three kinds of linear interpolation instructions.

- **MC_MoveLinear (Linear Interpolation)**
You can specify the *MoveMode* input variable to select between linear interpolation to an absolute value or linear interpolation to a relative value. This instruction is unique to the MC Function Module.
- **MC_MoveLinearAbsolute (Absolute Linear Interpolation)**
This instruction performs linear interpolation to an absolute value. This instruction is defined in the PLCopen technical specifications.
- **MC_MoveLinearRelative (Relative Linear Interpolation)**
This instruction performs linear interpolation to a relative value. This instruction is defined in the PLCopen technical specifications.


The following figure shows linear interpolation of 2 axes from point A to point B.



For details on linear interpolation, refer to the *MC_MoveLinear (Linear Interpolation)*, *MC_MoveLinearAbsolute (Absolute Linear Interpolation)*, and *MC_MoveLinearRelative (Relative Linear Interpolation)* instructions in the *NJ-series Motion Control Instructions Reference Manual (Cat. No. W508)*.

9-6-3 Circular Interpolation

Circular interpolation is used to move two of the logical axes A0 to A3 in a circular motion on a 2D plane. Either absolute or relative positioning is possible. You can specify the circular interpolation mode, path direction, interpolation velocity, interpolation acceleration, interpolation deceleration, and combined jerk for the two axes.



With the MC Function Module, you can specify the following three kinds of circular interpolation methods with the input variable *CircMode* (Circular Interpolation Mode).

- Border point
- Center
- Radius



Precautions for Correct Use

Set the Count Mode to Linear Mode for the axis that you use for circular interpolation. If the instruction is executed with this axis in Rotary Mode, an instruction error will occur.

9-6-4 Stopping Under Multi-axes Coordinated Control

Multi-axes coordinated control of axes groups will stop when you execute certain motion control instructions in the user program or when an error or some other problem occurs.

Stopping with Motion Control Instructions

Use the MC_GroupStop or MC_GroupImmediateStop instruction to stop axes group operation.

● MC_GroupStop Instruction

For linear interpolation or circular interpolation performed on an axes group, you can decelerate to a stop along the control path. You specify the deceleration rate and jerk. Specify a deceleration rate of 0 to send a command that immediately stops the Servo Drive. Other operation commands are not acknowledged while decelerating to a stop for this instruction and while the input variable *Execute* is TRUE.

● MC_GroupImmediateStop Instruction

You can perform an immediate stop for all axes in the axes group. The immediate stopping method is determined by the setting of the Immediate Stop Input Stop Method axis parameter for each axis. The MC_GroupImmediateStop instruction can also be executed for an axes group that is decelerating to a stop for an MC_GroupStop instruction.

For details, refer to the MC_GroupStop and MC_GroupImmediateStop instructions in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Stopping Due to Errors or Other Problems

● Stopping for Errors during Axes Group Motion

If an error that results in a deceleration stop occurs for any composition axis in the axes group during an axes group motion, all of the axes will decelerate to a stop on the interpolation path at the interpolation deceleration rate. The interpolation deceleration rate is determined by the deceleration rate that is specified for the controlling instruction. If an error that results in an immediate stop occurs for any composition axis in the axes group during an axes group motion, the other axes in the axes group will stop according to the setting of the Axes Group Stop Method parameter in the axes group parameters.

You can select one of the following stop methods for axes groups.

- Immediate stop
- Decelerate axes to a stop at maximum deceleration rate of the axes.
- Immediate stop and Servo OFF

● Stopping Due to Excessively Long Control Period

If motion control processing does not end within two periods, it is considered to be an excessive control period. Control will be stopped immediately.

● Stopping Due to Start of MC Test Run

All axes will decelerate to a stop at their maximum deceleration if a MC Test Run is started from the Sysmac Studio.

● Stopping Due to Change in CPU Unit Operating Mode

All axes will decelerate to a stop at their maximum deceleration when the CPU Unit operating mode changes.



Additional Information


- If you execute the MC_GroupDisable (Disable Axes Group) instruction during axes group operation, the axes in the group will decelerate to a stop at their maximum deceleration rates.
- If you execute the MC_Stop instruction while an axes group is in operation, an error will occur for the axes and axes group and the axes group operation will decelerate to a stop with interpolation. The interpolation deceleration rate is determined by the deceleration rate that is specified for the controlling instruction.
- When the input variable *Enable* to the MC_Power (Servo ON) instruction changes to FALSE during axes group motion, the MC Function Module immediately stops the command value for that axis and turns OFF the Servo. When the Servo is turned OFF, the Servo Drive will operate according to the settings in the Servo Drive. Other axes in that axes group will stop with the stop method that is set in the Axes Group Stop Method axes group parameter. An error will occur for the axes group if this happens.
- When RUN mode changes to PROGRAM mode, any motion control instructions for current motions are aborted. The *CommandAborted* output variable from the instructions remain TRUE and the Servo remains ON.
- If the operating mode returns to RUN mode while a deceleration stop is in progress after the operating mode changes from RUN to PROGRAM mode, the output variable *CommandAborted* from the current motion control instructions change to TRUE.
- The save process will continue during a save for the MC_SaveCamTable Instruction.

9-6-5 Overrides for Multi-axes Coordinated Control

You can use the MC_GroupSetOverride (Set Group Overrides) instruction to set override factors for multi-axes coordinated control of the axes group in the current interpolation operation. The velocity override factor is set as a percentage of the target velocity for interpolation. It can be set between 0% and 500%. If an override factor of 0% is set for the interpolation target velocity, operating status will continue with the axis stopped at a velocity of 0. The set override factor is read as long as the overrides are enabled. If the overrides are disabled, the override factors return to 100%. If the maximum interpolation velocity is exceeded when an override factor is changed, the maximum interpolation velocity for the axes group is used.

● **Overrides for the MC_MoveLinear (Linear Interpolation) Instruction**

An example of a time chart for using the Set Override Factors instruction for the MC_MoveLinear (Linear Interpolation) instruction is given below.



For details, refer to the MC_GroupSetOverride (Set Group Overrides) instruction in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-7 Common Functions for Multi-axes Coordinated Control

This section describes the common functions for multi-axes coordinated control.

9-7-1 Velocity Under Multi-axes Coordinated Control

To specify the velocity for multi-axes coordinated control, specify the interpolation velocity on the path. The unit is the same as for single axes, command units/s.

Types of Velocities

The following is the only type of interpolation velocity for axes groups supported by the MC Function Module.

Velocity type	Definition
Command interpolation velocity	This is the actual value of the command interpolation velocity output by the MC Function Module to control an axes group.

Axis Parameters That Are Related to Velocities

Parameter name	Function	Setting range	Default
Maximum Interpolation Velocity	Set the maximum interpolation velocity for the path. Set 0 for no interpolation velocity limit. If a target velocity that exceeds the maximum interpolation velocity is specified for an axes group operation instruction, the axis will move at the maximum interpolation velocity.	Non-negative long reals	800,000,000
Interpolation Velocity Warning Value	Set the percentage of the maximum interpolation velocity at which to output an interpolation velocity warning. No interpolation velocity warning is output if 0 is set. (Unit: %)	0 to 100	0

Specifying Target Velocities for Axis Operations

The interpolation velocity used in an actual positioning motion is specified by the *Velocity* (Target Velocity) input variable to the motion control instruction.

Monitoring Velocities

You can read Axes Group Variables from the user program to monitor the interpolation velocity.

Variable name	Data type	Meaning	Function
_MC_GRP[0-31].Cmd.Vel	LREAL	Command Interpolation Velocity	This is the current value of the command interpolation velocity. A plus sign is added during travel in the positive direction, and a minus sign is added during travel in the negative direction.

9-7-2 Acceleration and Deceleration Under Multi-axes Coordinated Control

Multi-axes coordinated control performs control on the path for the interpolation acceleration and interpolation deceleration rates. The unit is the same as for single axes, command units/s².

Axis Parameters That Are Related to Interpolation Acceleration and Interpolation Deceleration

Parameter name	Function	Setting range	Default
Maximum Interpolation Acceleration	Set the maximum interpolation acceleration for the path. Set 0 for no interpolation acceleration limit. (Unit: command units/s ²)	Non-negative long reals	0
Maximum Interpolation Deceleration	Set the maximum interpolation deceleration for the path. Set 0 for no interpolation deceleration limit. (Unit: command units/s ²)	Non-negative long reals	0
Interpolation Acceleration/Deceleration Over	Set the operation for when the maximum interpolation acceleration/deceleration rate would be exceeded after excessive acceleration/deceleration during acceleration/deceleration control of the axes group because stopping at the target position is given priority. 0: Use rapid acceleration/deceleration. (Blending is changed to Buffered.) 1: Use rapid acceleration/deceleration. 2: Minor fault error	0 to 2	0
Interpolation Acceleration Warning Value	Set the percentage of the maximum interpolation acceleration at which to output an interpolation acceleration warning. No interpolation acceleration warning is output if 0 is set. (Unit: %)	0 to 100	0
Interpolation Deceleration Warning Value	Set the percentage of the maximum interpolation deceleration rate at which to output an interpolation deceleration warning. No interpolation deceleration warning is output if 0 is set. (Unit: %)	0 to 100	0

Specifying an Interpolation Acceleration and Interpolation Deceleration for an Axes Group

The interpolation acceleration and interpolation deceleration rates used in an actual positioning motion are specified by the *Acceleration* (Acceleration Rate) and *Deceleration* (Deceleration Rate) input variables to the motion control instruction.

Monitoring Interpolation Acceleration and Interpolation Deceleration Rates

You can read Axes Group Variables in the user program to monitor interpolation acceleration and interpolation deceleration rates.

Variable name	Data type	Meaning	Function
_MC_GRP[0-31].Cmd.AccDec	LREAL	Command Interpolation Acceleration/Deceleration	This is the current value of the command interpolation acceleration/deceleration rate. A plus sign is added for acceleration, and a minus sign is added for deceleration.

9-7-3 Jerk for Multi-axes Coordinated Control


Jerk for multi-axes coordinated control is used to reduce shock on the machine by smoothing the interpolation acceleration/deceleration rate along the interpolation path into an S-curve. The unit is the same as for single axes, command units/s³.

Specifying Jerk for Axes Group Motion

The jerk used in an actual interpolation is specified by the *Jerk* input variable to the motion control instruction.


Jerk Example (Setting Other than 0)

The acceleration/deceleration rate will change at a constant rate over the range where jerk is specified. The command interpolation velocity will form a smooth S-curve. A fixed interpolation acceleration rate is used in areas where the jerk is set to 0. This command interpolation velocity will form a straight line.



9-7-4 Re-executing Motion Control Instructions for Multi-axes Coordinated Control

If you re-execute a linear interpolation or circular interpolation instruction, an instruction error will occur.




You can change the deceleration rate if you re-execute the MC_GroupStop instruction, but you cannot change the jerk in this way.

If you re-execute the MC_GroupReset instruction, the re-execution command will be ignored and error reset processing will continue.

For details on re-executing motion control instructions, refer to each instruction in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-7-5 Multi-execution (Buffer Mode) of Motion Control Instructions for Multi-axes Coordinated Control

You can perform multi-execution for multi-axes coordinated control in axes groups the same way as you can for axis operations. You can perform path control for multiple continuous lines and/or arcs if you use Buffer Mode under multi-axes coordinated control.



You can set the *BufferMode* input variable to motion control instruction to select one of the same Buffer Modes as are supported for single-axis operations. There are a total of eight instruction buffers for axes groups. Each axes group has one buffer for the instruction currently in operation and seven buffers for multi-execution instructions. Multi-execution of instruction cannot be used from an axis operation instruction to an axes group operation instruction and vice-versa.




Precautions for Correct Use

- Up to seven instructions can be buffered at the same time for a single axes group. If multi-execution is performed for eight or more instructions, an instruction error will occur.
- Multi-execution of multi-axes coordinated control instructions (axes group instructions) is not possible for axes operating as a single axis. Similarly, multi-execution of single-axis control instructions is not possible for axes operating under multi-axes coordinated control (axes group instructions). An instruction error will occur if these rules are broken.


Aborting

This is the default mode. No buffering is performed in this mode. The current command is aborted and the new instruction is executed. Multi-execution of motion control instructions that have no *BufferMode* input variable will operate in Aborting Mode. Operation of the multi-execution instruction starts at the current interpolation velocity when the multi-execution instruction is executed. With Aborting Mode you cannot combine single-axis control, including synchronized single-axis control and axes group control. An instruction error will occur at the time of multi-execution if you execute an axes group operation on an axis currently in a single-axis motion. This will stop both the axes group and the single axis.

Multi-execution during Constant-velocity Motion




Multi-execution during Acceleration/Deceleration




Multi-execution for axes groups is done so that the interpolation velocity remains continuous between instructions. If continuous operation is performed with an instruction with a travel distance of 0, the velocity changes for the axes will not be continuous.

Example: Interpolation Velocity and Velocities of Axes for Two-axis Cartesian Coordinates



Buffered

The multi-execution instruction remains in the buffer until the current operation is finished. The buffered instruction is executed after the operation for the current instruction is normally ended.



Blending

Blending for axes groups works in the same way as blending for single-axis operations. The buffered instruction remains in the buffer until the target position of the current instruction is reached. The buffered instruction is executed after the target position of the current instruction is reached. The axes do not stop at the target position. The two motions are blended together at the interpolation velocity specified with the *BufferMode* input variable.

The Interpolation Acceleration/Deceleration Over axes group parameter is used to select one of the following operations for when the acceleration/deceleration that is specified in the buffered instruction would exceed the target position.

- Use rapid acceleration/deceleration. (Blending is changed to Buffered.)
- Use rapid acceleration/deceleration.
- Minor fault stop (Treat blending operation as buffered operation.)


● **Blending Low (Low Velocity)**

Operation is performed using the target position of the current instruction and the target velocity that is the slower of the target velocities for the current instruction and buffered instruction.


● **Blending Previous (Previous Velocity)**

Operation is performed with the target velocity of the current instruction until the target position of the current instruction is reached. Operation is performed after acceleration/deceleration to the target velocity of the buffered instruction once the target position is reached.

Cases Resulting in Acceleration




Cases Resulting in Deceleration




● **Blending Next (Next Velocity)**

Operation is performed using the target position of the current instruction and the target velocity of the buffered instruction.

Cases Resulting in Acceleration



Cases Resulting in Deceleration



● **Blending High (High Velocity)**

Operation is performed using the target position of the current instruction and the target velocity that is the faster of the target velocities for the current instruction and buffered instruction.

Transition Modes

Multi-execution of instructions for axes groups may create some shock on the device and/or workpiece due to changes in the direction of the interpolation path. You can specify the *TransitionMode* input variable to the motion control instruction to select a transition method to use between instructions in order to lessen this shock. You can choose from the following transition modes in the MC Function Module.

No.	Transition mode	Description
0	Transition disabled (TMNone)	Do not perform any processing for transitions (default). No attempt is made to lessen the shock, but this results in a shorter operation time.
10	Superimpose corners (TMCornerSuperimpose)	The deceleration of the current instruction is superimposed on the acceleration of the buffered instruction. You can keep the linear velocity of the interpolation path constant.



Additional Information


The PLCopen technology specifications define numbers 0 through 9. Number 10 is unique to the MC Function Module.

● **Transition Disabled (0: TMNone)**

No processing is performed to connect the two positions.


TransitionMode = TMNone and BufferMode = Buffered

The axis moves to position End1, stops, and then moves to position End2.




TransitionMode = TMNone and BufferMode = Blending

The axis moves to position End1, and then moves to position End2.




TransitionMode = TMNone and BufferMode = Aborting

The axis moves from End1' (multi-execution of instruction) to End2.



● **Superimpose Corners (10: TMCornerSuperimpose)**

The deceleration of the current instruction is superimposed on the acceleration of the buffered instruction. Operation is executed in the same amount of time as for the deceleration of the current instruction, no matter what is specified as the acceleration for the buffered instruction. The superimposed area will apply no jerk even if jerk is specified.



The output variable *Done*, which indicates the end of a motion control instruction, will change to TRUE for *TMCornerSuperimpose* when the area of superimposition is completed.



Additional Information

The path linear velocity is constant if the following two conditions are met.

- The target velocities of the current instruction and the buffered instruction are the same.
- The deceleration rate of the current instruction and the acceleration rate of the buffered instruction are the same.

Combining Transition Modes and Buffer Modes

The following table shows the combinations of Transition Modes and Buffer Modes.

OK: Operation possible. ---: Generates an error and stops.

Transition Mode	Buffer Mode	Aborting	Buffered	Blending Low	Blending Previous	Blending Next	Blending High
Transition disabled (TMNone)		OK	OK	OK*	OK*	OK*	OK*
Superimpose corners (TMCornerSuperimpose)		---	---	OK	OK	OK	OK

* The combinations of Blending Modes when transition is disabled (TMNone) will operate in the same way as for Buffered Mode.

9-8 Other Functions

This section describes other functions of the MC Function Module.

9-8-1 Changing the Current Position

The command current position of a Servo axis can be changed to a specified value. The actual current position changes to a value that maintains the current following error with the command current position. For an encoder axis, you can change the actual current position. Use the MC_SetPosition instruction to specify the actual position you want to modify.

You can change the actual position even while an axis is in motion. If positioning to an absolute value is being executed, positioning will be performed to the target position using the new absolute coordinates. However, the travel distance will stay the same when you position to a relative value.



Precautions for Correct Use


- When the Count Mode is Rotary Mode, an instruction error will occur if you specify a position outside the ring counter range.
- After changing the current position the home will be undefined and you will not be able to use the following functions and instructions.

Software limits

High-speed homing

Interpolation instructions (linear and circular interpolation)

● Timing Chart for Execution While Axis Is Stopped



Additional Information

You can change the actual position while home is defined by specifying a zero position preset for the MC_Home instruction.

For details on the MC_SetPosition instruction, refer to the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-8-2 Torque Limit

The output torque is limited by enabling and disabling the torque limit function of the Servo Drive and by setting the torque limit value.

Different limits can be specified for the positive torque limit and negative torque limit.

For details, refer to the MC_SetTorqueLimit instruction in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).


9-8-3 Latching

Latching is used to control positioning based on the position where a trigger signal occurs, such as a signal from a sensor input. The position of the axis is recorded (i.e., latched) when the trigger signal occurs. You can set up to two trigger signals for each axis. Use the MC_TouchProbe (Enable External Latch) instruction to specify the trigger input condition, a window, and the stop method for the axis you want to latch. In addition to signals that connect to the Servo Drive, you can also specify variables in the user program to use as a trigger. Use the MC_AbortTrigger (Disable External Latch) instruction to abort latching. You can use latching only with a Servo Drive that support latching (touch probe), such as the G5-series Servo Drives, or a GX-EC0211/EC0241 Encoder Input Terminal.

Use *WindowOnly* to detect only trigger signals within a specific start point and end point. The following chart shows the ranges for different Count Modes.

● Linear Mode


- The *FirstPosition* must be less than or equal to the *LastPosition*.
- An instruction error will occur if the *FirstPosition* is greater than the *LastPosition*.
- An instruction error will occur if a position beyond the position range of Linear Mode is specified.



● Rotary Mode

- The *FirstPosition* can be less than, equal to, or greater than the *LastPosition*. If the *FirstPosition* is greater than the *LastPosition*, the setting will straddle the modulo minimum position setting value.
- An instruction error will occur if a position beyond the upper and lower limits of the ring counter is specified.

	First Position ≤ Last Position	First Position > Last Position
Valid range	FirstPosition to LastPosition	LastPosition to FirstPosition



For details on latching, refer to the MC_TouchProbe (Enable External Latch) and MC_AbortTrigger (Disable External Latch) instructions in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-8-4 Zone Monitoring

This function detects whether the command position or actual position of an axis is in the specified range (zone). Use the MC_ZoneSwitch (Zone Monitor) instruction to specify the first position and last position of the zone to check. The *InZone* output variable for the Zone Monitor instruction will change to TRUE when the position of the axis enters the specified zone. You can also specify multiple zones for a single axis. Zones can overlap.

For details on zone monitoring, refer to the MC_ZoneSwitch (Zone Monitor) instruction in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).


9-8 Other Functions

9

9-8-4 Zone Monitoring

9-8-5 Software Limits

Actual positions can be monitored in the MC Function Module software. This function is separate from the hardware-based limit input signals. Set the range to monitor by setting the software limits in the Positive Software Limit and Negative Software Limit axis parameters. During normal positioning, motion is possible within the range of these software limits. Set software limits to prevent potential damage to machinery caused by mistakes in the user program or improper operation.



● Axis Parameters That Are Related to Software Limits

Parameter name	Function	Setting range	Default
Software Limits	Select the software limit function. 0: Disabled 1: Deceleration stop for command position 2: Immediate stop for command position 3: Deceleration stop for actual position 4: Immediate stop for actual position	0 to 4	0: Disabled
Positive Software Limit	Set the software limit in the positive direction. The unit is command units.	Long reals	2,147,483,647
Negative Software Limit	Set the software limit in the negative direction. The unit is command units.		-2,147,483,648

You can set the above axis parameters from the Sysmac Studio or by using the MC_Write (Write MC Setting) instruction. If any setting values are changed for an axis or axes group in operation, those settings are enabled when the next operation begins.

Software limits function in the following two cases based on the axis operation state and the motion control instruction that is used.

● Executing Motion Instructions

- When the Actual Position Is within the Software Limits
An instruction error will occur if the target position is outside the software limit range.
- When the Actual Position Is outside the Software Limits
Motion is allowed only toward the software limit range. As long as the motion is toward the range, the target position does not need to be within the software limit range.

● During Axis Motion

When the axis is in discrete motion, synchronized motion, continuous motion, or coordinated motion:

- An axis error will occur if the software limits are enabled for the command position and the command position leaves the range.
- An axis error will occur if the software limits are enabled for the actual position and the actual position leaves the range.



Additional Information

Software limits can be enabled when the Count Mode is set to Linear Mode and home is defined. Software limits are disabled in the following situations no matter what axis parameters have been set.

- When Count Mode is set to Rotary Mode.
- When home is not defined.
- During homing.

For details on writing MC settings, refer to the MC_Write (Write MC Setting) instruction in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-8-6 Following Error Monitoring

Following error is the difference between the command position and the actual position of an axis. The MC Function Module monitors the following error every motion control period.

If the value of the following error exceeds the Following Error Over Value that is set in the axes parameters, Following Error Limit Exceeded minor fault level error occurs. If it exceeds the Following Error Warning Value, a Following Error Warning observation occurs. Monitoring the following error is disabled during execution of the holding operation for homing.

● Axis Parameters That Are Related to Monitoring the Following Error

You can set the check values for monitoring the following error by setting the appropriate axis parameters. Set the Following Error Warning Value so that it is less than the Following Error Over Value.

Set the axis parameters from the Sysmac Studio.

Parameter name	Function	Setting range	Default
Following Error Over Value	Set the excessive following error check value. Set 0 to disable the excessive following error check. (Unit: command units)	Non-negative long reals	0
Following Error Warning Value	Set the following error warning check value. Set 0 to disable the following error warning check. (Unit: command units)	Non-negative long reals that are less than or equal to the Following Error Over Value	0

9-8-7 Following Error Counter Reset

Resetting the following error counter resets the following error to 0.

Use the MC_ResetFollowingError instruction in the user program to reset the following error counter. You can use the MC_ResetFollowingError instruction for each axis during positioning or during homing. If you execute a following error counter reset while the axis is in motion, the current motion control instruction will be aborted and the command position will be set to the same value as the actual position.

The home will remain defined even after executing a following error counter reset.

For details on resetting the following error counter, refer to the MC_ResetFollowingError instruction in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

● Axis Parameters That Are Related to Resetting the Following Error Counter

You can choose to reset the following error counter on an immediate stop, on a limit input stop, or after homing is completed by setting the appropriate axis parameters. Set the axis parameters from the Sysmac Studio.

Parameter name	Function	Setting range	Default
Immediate Stop Input Stop Method	Set the stopping method in the MC Function Module when the immediate stop input is enabled. 0: Immediate stop 2: Immediate stop and error reset 3: Immediate stop and Servo OFF	0, 2, or 3	0
Limit Input Stop Method	Set the stopping method in the MC Function Module when the positive limit input or negative limit input is enabled. 0: Immediate stop 1: Deceleration stop 2: Immediate stop and error reset 3: Immediate stop and Servo OFF	0 to 3	0

9-8-8 Axis Following Error Monitoring

You can monitor the amount of following error for the command position or the actual position between two axes. Use the MC_AxesObserve (Monitor Axis Following Error) instruction to specify the permitted following error and the two axes to monitor. If the permitted following error is exceeded, the *Invalid* output variable for the Monitor Axis Following Error instruction will change to TRUE.

You can use this monitoring function to program the actions to take when the following error between axes grows too large for gantry control and other devices where both axes perform the same operation.




Precautions for Correct Use

Even if the permitted following error between axes is exceeded, no error will occur in the MC Function Module. Check the *Invalid* output variable to stop axis operation or to take some other action as appropriate in the user program.

For details on axis following error monitoring, refer to the MC_AxesObserve (Monitor Axis Following Error) instruction in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-8-9 In-position Check

You can check to see if the actual current position has reached the specified range for the target position during positioning or homing. After command output of the target position is completed, positioning is considered to be finished when the difference between the target position and the actual current position is within the in-position range. An instruction error occurs if the position is not within the in-position within the in-position check time.



● Axis Parameters That Are Related to In-position Checks

You can set the check conditions for the in-position check by setting the appropriate axis parameters. Set the in-position check time if you want to start any of the following operations only after confirming that axes are in position.

Parameter name	Function	Setting range	Default
In-position Range	Set the in-position width. (Unit: command units)	Non-negative long reals	10
In-position Check Time	Set the in-position check time in milliseconds. Set 0 to check for the end of positioning only when you define the home position during homing and not check positioning at other times. (Unit: ms)	0 to 10,000	0



Additional Information

Do not set an in-position check time if you want to start the next operation as quickly as possible without waiting for positioning to finish.

Set the parameters from the Sysmac Studio. You can use the MC_Write (Write MC Setting) instruction to change the in-position check time.



Additional Information

The value set from the Sysmac Studio is restored if power to the CPU Unit is cycled or the user program is downloaded with the Synchronization menu command of the Sysmac Studio. Use the MC_Write (Write MC Setting) instruction only when you need to temporarily change the in-position check time.

● Monitor Information That Is Related to In-position Checks

You can read Axis Variables from the user program to monitor when positioning finishes.

Variable name	Data type	Meaning	Function
_MC_AX[0-63].Details.Idle	BOOL	Idle	TRUE when processing is not currently performed for the command value, except when waiting for in-position state.* <i>Idle</i> and <i>InPosWaiting</i> are mutually exclusive. They cannot both be TRUE at the same time.
_MC_AX[0-63].Details.InPosWaiting	BOOL	In-position Waiting	TRUE when waiting for in-position state. The in-position check is performed when positioning for the in-position check.

* This also includes states where processing is performed while in motion at velocity 0, during following error counter resets, during synchronized control, and during coordinated motion.

You can read Axes Group Variables from the user program to monitor when positioning finishes for the axes group.

Variable name	Data type	Meaning	Function
_MC_GRP[0-31].Details.Idle	BOOL	Standstill	TRUE when processing is not currently performed for the command value, except when waiting for in-position state.*1 <i>Idle</i> and <i>InPosWaiting</i> are mutually exclusive. They cannot both be TRUE at the same time.
_MC_GRP[0-31].Details.InposWaiting	BOOL	In-position Waiting	TRUE when waiting for in-position state for any composition axis.*2 The in-position check is performed when positioning for the in-position check.

*1 This also includes states where processing is performed while in motion at a velocity of 0.

*2 This variable is FALSE when all composition axes in the axes group are within the in-position ranges set in the axis parameters.

For details on writing MC settings, refer to the MC_Write (Write MC Setting) instruction in the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Sample Programming

This section describes basic application methods for homing, error monitoring, and other functions, and provides programming samples for absolute positioning, cam operation, and other axis operations.

10-1 Overview of Sample Programming	10-2
10-1-1 Devices	10-2
10-1-2 Installation and Wiring	10-2
10-1-3 Setup	10-3
10-2 Basic Programming Samples	10-4
10-2-1 Monitoring EtherCAT Communications and Turning ON Servos	10-4
10-2-2 Interlocking Axis Operation with Master Control Instructions	10-6
10-2-3 Error Monitoring and Error Resetting for Single-axis Operation and Synchronized Operation	10-8
10-2-4 Error Monitoring and Error Resetting for Multi-axes Coordinated Operation	10-10
10-2-5 Monitoring for Instruction Errors	10-16
10-2-6 Checking to See If Errors Are Reset	10-18
10-2-7 Stopping Axes during Single-axis Operation	10-20
10-2-8 Stopping an Axes Group in Coordinated Motion	10-24
10-2-9 Homing and Absolute Positioning	10-30
10-2-10 Changing the Target Position by Re-execution of an Instruction	10-35
10-2-11 Interrupt Feeding	10-41
10-2-12 Changing the Cam Table by Re-execution of an Instruction	10-45
10-2-13 Using a Cam Profile Curve to Correct the Sync Start Position	10-54
10-2-14 Shifting the Phase of a Master Axis in Cam Motion	10-64
10-2-15 Changing the Actual Position during Velocity Control	10-72
10-2-16 Changing a Cam Data Variable and Saving the Cam Table	10-78
10-2-17 Temporarily Changing Axis Parameters	10-87
10-2-18 Updating the Cam Table End Point Index	10-90

10-1 Overview of Sample Programming

This section provides information that applies to all of the sample programming.



Precautions for Correct Use

- The sample programming that is provided includes only programming that uses the MC Function Module.
- When programming actual applications, also program device interlocks, I/O with other devices, and other control procedures.
- Create a user program that will produce the intended device operation.
- Check the user program for proper execution before you use it for actual operation.

10-1-1 Devices

The following devices are used in the sample programming.

Device	Servo configuration example
CPU Unit	NJ501-1□00 (unit version 1.0)
Power Supply Unit	NJ-Px3001
Servo Drive	R88D-KN□-ECT (version 2.1)
Servomotor	R88M-K□
Encoder Input Terminal	GX-EC0211 (version 1.1)

10-1-2 Installation and Wiring

Refer to the following manual for details on installing and wiring the devices.

Device	Manual
CPU Unit and Power Supply Unit	NJ-series CPU Unit Hardware User's Manual (Cat. No. W500)
Servo Drive and Servomotor	OMRON G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications User's Manual (Cat. No. I576)
Encoder Input Terminal	GX-series EtherCAT Slave User's Manual (Cat. No. W488)
EtherCAT communications cables	GX-series EtherCAT Slave User's Manual (Cat. No. W488)

10-1-3 Setup

Refer to the following manual for details on settings.

Setup	Manual
Controller Setup	NJ-series CPU Unit Software User's Manual (Cat. No. W501)
Motion Control Setup	<i>3-2 Axis Setting Procedure, 5-2 Axis Parameters, and A-1 Connecting the Servo Drive</i> in this manual.
Servo parameters	OMRON G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications User's Manual (Cat. No. I576)

10-2 Basic Programming Samples

This section provides programming samples for the basic functions of the MC Function Module.



Precautions for Correct Use

- When you use these programming samples for reference, be sure to add programming for suitable interlocks that suit the operating conditions of the devices.
- Enter the variables that are used in the programming samples from the Programming Layer in the Edit Pane of the Sysmac Studio.

10-2-1 Monitoring EtherCAT Communications and Turning ON Servos

In this sample, the MC_Power (Power Servo) instruction is executed to turn ON the Servo for the Servo Drive when EtherCAT process data communications are established with the Servo Drive.


Samples are provided for both ladder diagram and ST programming.

Main Variables Used in the Programming Samples


Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF	---	This is the Axis Variable for axis 0.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
MC_Axis000.Cfg.NodeAddress	UINT	---	This is the node address.
_EC_PDslavTbl[N]	BOOL	FALSE	TRUE when EtherCAT process data communications for node address N are in Operational state.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.

Ladder Diagram


When *StartPg* is TRUE, the status of process data communications is checked to see if communications are active and normal.



The Servo for axis 0 is turned ON if process data communications are active and normal.



If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.



ST Programming

```
// When StartPg is TRUE, the Servo is turned ON for axis 0 if process data communications are active and normal.
IF (StartPg=TRUE)
```

```
  AND (_EC_PDslavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
  AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
    Pwr_En:=TRUE;
  ELSE
    Pwr_En:=FALSE;
  END_IF;
```

```
// If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed.
// Program the FaultHandler according to the device.
IF MC_Axis000.MFaultLvl.Active=TRUE THEN
  FaultHandler();
END_IF;
```

```
// MC_Power
PWR(
  Axis    := MC_Axis000,
  Enable  := Pwr_En,
  Status  => Pwr_Status,
  Busy    => Pwr_Bsy,
  Error   => Pwr_Err,
  ErrorID => Pwr_ErrID
);
```

10-2-2 Interlocking Axis Operation with Master Control Instructions


You can place the MC_Power (Power Servo) instruction between the MC (Master Control Start) and MCR (Master Control End) instructions in ladder diagrams to interlock axis operation. When *Mc_On* is FALSE in this sample, the MC_Power (Power Servo) instruction between the MC and MCR instructions is disabled to turn OFF the Servo. The *CommandAborted* output variable from the current motion control instruction changes to TRUE at the same time, and axis motion stops.

You cannot use the MC instruction in ST. Therefore, a sample is provided only for a ladder diagram.

Main Variables Used in the Programming Samples


Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF	---	This is the Axis Variable for axis 0.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
Mc_On	BOOL	FALSE	This variable enables and disables the MC instruction. Control programming is not given in this sample. In actual programming, program controls for the required device operation.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.

Timing Chart




Ladder Diagram


When *Mc_On* is TRUE, master control is started.




When *StartPg* is TRUE, the status of process data communications is checked to see if communications are active and normal.




The Servo for axis 0 is turned ON if process data communications are active and normal.



Master control is ended.



If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.



10-2-3 Error Monitoring and Error Resetting for Single-axis Operation and Synchronized Operation


You can monitor error status by monitoring the status of Axis Minor Fault Occurrence in the Axis Variable. If a minor fault level error occurs in this sample, the *Enable* input variable for the MC_Power instruction changes to FALSE to turn OFF the Servo. If the external button is ON and the command current velocity is zero, the error is reset with the MC_Reset (Reset Axis Error) instruction. Samples are provided for both ladder diagram and ST programming.

Main Variables Used in the Programming Samples


Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF	---	This is the Axis Variable for axis 0.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
MC_Axis000.Status.ErrorStop	BOOL	FALSE	TRUE while there is a minor fault level error for axis 0 and the axis is decelerating to a stop or stopped.
MC_Axis000.Details.Idle	BOOL	FALSE	TRUE when the command current velocity for axis 0 is zero, except when waiting for in-position state.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.
ResetON	BOOL	FALSE	This variable gives the status of the external button that is used to reset errors.

Ladder Diagram


When *StartPg* is TRUE, the status of process data communications is checked to see if communications are active and normal.




The Servo for axis 0 is turned ON if process data communications are active and normal.



If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.



If *ResetON* is TRUE (i.e., when the external button is ON) and the command current velocity is zero, the error is reset.



ST Programming

```
// When StartPg is TRUE, the status of process data communications is checked to see if communications are active and normal.
```

```
// The Servo is turned ON for axis 0 if process data communications for axis 0 are active and normal.
```

```
// If process data communications are not active, the Servo for axis 0 is turned OFF.
```

```
IF (StartPg=TRUE)
```

```
  AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
```

```
  AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
```

```
    Pwr_En:=TRUE;
```

```
ELSE
```

```
  Pwr_En:=FALSE;
```

```
END_IF;
```

```
// If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed.
```

```
// Program the FaultHandler according to the device.
```

```
IF MC_Axis000.MFaultLvl.Active=TRUE THEN
```

```
  FaultHandler();
```

```
END_IF;
```

```
// If ResetON is TRUE (i.e., when the external button is ON) and the command current velocity is zero, the error is reset.
```

```
IF (ResetOn=TRUE)
```

```
  AND (MC_Axis000.Status.ErrorStop=TRUE)
```

```
  AND (MC_Axis000.Details.Idle=TRUE) THEN
```

```
    Reset_Ex := TRUE;    // Minor fault is reset.
```

```
END_IF;
```

```
// MC_Power
```

```
PWR(
```

```
  Axis    := MC_Axis000,
```

```
  Enable  := Pwr_En,
```

```
  Status  => Pwr_Status,
```

```
  Busy    => Pwr_Bsy,
```

```
  Error   => Pwr_Err,
```

```
  ErrorID => Pwr_ErrID
```

```
);
```

```
// MC_Reset
```

```
RESET(
```

```
  Axis    := MC_Axis000,
```

```
  Execute := Reset_Ex,
```

```
  Done    => Reset_D,
```

```
  Busy    => Reset_Bsy,
```

```
  Failure => Reset_Fai,
```

```
  Error   => Reset_Err,
```

```
  ErrorID => Reset_ErrID
```

```
);
```

10-2-4 Error Monitoring and Error Resetting for Multi-axes Coordinated Operation

You can monitor error status by monitoring the status of Axis Minor Fault Occurrence in the Axis Variables and Axes Group Minor Fault Occurrence in the Axes Group Variable. If a minor fault level error occurs in this sample, the *Execute* input variable for the MC_GroupDisable (Disable Axes Group) instruction changes to TRUE to disable the axes group. If the external button is ON and the command current velocity for the axes group is zero, the error is reset with the MC_GroupReset (Reset Axes Group Error) instruction.


Samples are provided for both ladder diagram and ST programming.

Main Variables Used in the Programming Samples


Variable name	Data type	Default	Comment
MC_Group000	_sGROUP_REF	---	This is the Axes Group Variable for axes group 0.
MC_Group000.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axes group 0.
MC_Group000.Details.Idle	BOOL	FALSE	TRUE when the command interpolation velocity for axes group 0 is zero, except when waiting for in-position state.
MC_Axis000	_sAXIS_REF	---	This is the Axis Variable for axis 0.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 0.
MC_Axis001	_sAXIS_REF	---	This is the Axis Variable for axis 1.
MC_Axis001.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 1.
MC_Axis001.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
Pwr1_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
Pwr2_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR2 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.
ResetON	BOOL	FALSE	This variable gives the status of the external button that is used to reset errors.

Ladder Diagram


When *StartPg* is TRUE, the status of process data communications for axis 0 is checked to see if communications are active and normal.




When *StartPg* is TRUE, the status of process data communications for axis 1 is checked to see if communications are active and normal.




The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal.




The Servo for axis 1 is turned ON if process data communications for axis 1 are active and normal.




If a minor fault level error occurs for any of the composition axes in the axes group, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.




If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.




If the Servo is ON for axis 1 and home is not defined, the MC_Home instruction is executed.




The status of the axes group and the status of home for axis 0 and axis 1 are checked.




If home is defined for axis 0 and axis 1, the axes group is enabled.




If there is a minor fault level error for the axes group, the axes group is disabled.



If the external button is ON, the status of ResetON and the status of axes group motion is checked.



If ResetON is TRUE and the axes group is stopped, the error is



ST Programming

```

// When StartPg is TRUE, the status of process data communications is checked to see if communications are
// active and normal.
// The Servo is turned ON for axis 0 if process data communications for axis 0 are active and normal.
// If process data communications are not active, the Servo for axis 0 is turned OFF.
IF (StartPg =TRUE)
AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
    Pwr1_En:=TRUE;           // Turn ON the Servo for axis 0.
ELSE
    Pwr1_En:=FALSE;        // Turn OFF the Servo for axis 0.
END_IF;

// When StartPg is TRUE, the status of process data communications is checked to see if communications are
// active and normal.
// The Servo is turned ON for axis 1 if process data communications for axis 1 are active and normal.
// If process data communications are not active, the Servo for axis 1 is turned OFF.
IF (StartPg =TRUE)
AND (_EC_PDSlavTbl[MC_Axis001.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis001.Cfg.NodeAddress]=FALSE) THEN
    Pwr2_En:=TRUE;           // Turn ON the Servo for axis 1.
ELSE
    Pwr2_En:=FALSE;        // Turn OFF the Servo for axis 1.
END_IF;

// If there is a minor fault level error for a composition axis in the axes group.
// execute the error handler (FaultHandler).
IF (MC_Axis000.MFaultLvl.Active=TRUE)
OR (MC_Axis001.MFaultLvl.Active=TRUE)
OR (MC_Group000.MFaultLvl.Active=TRUE) THEN
    FaultHandler();         // Program the FaultHandler according to the device.
END_IF;

// If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.
IF (Pwr1_Status=TRUE)
AND (MC_Axis000.Details.Homed=FALSE) THEN
    Hm1_Ex:= TRUE;
END_IF;

// If the Servo is ON for axis 1 and home is not defined, the MC_Home instruction is executed.
IF (Pwr2_Status=TRUE)
AND (MC_Axis001.Details.Homed=FALSE) THEN
    Hm2_Ex:= TRUE;
END_IF;

// If the axes group is disabled and home is defined for axis 0 and axis 1, the axes group is enabled.
IF (MC_Group000.Status.Disabled=TRUE)
AND (Hm1_D=TRUE) AND (Hm2_D=TRUE) THEN
    Grp_En_Ex:= TRUE;
END_IF;

// If there is a minor fault level error for the axes group, the axes group is disabled.
IF MC_Group000.MFaultLvl.Active=TRUE THEN
    Grp_Dis_Ex:=TRUE;
END_IF;

// If ResetON is TRUE (i.e., if the external button is ON) and the axes group is stopped, the error is reset.
IF (ResetON=TRUE)
AND (MC_Group000.Status.ErrorStop=TRUE)
AND (MC_Group000.Details.Idle=TRUE) THEN
    Grp_Reset_Ex := TRUE;
END_IF;

```

```

//MC_Power1
PWR1(
    Axis      := MC_Axis000,
    Enable    := Pwr1_En,
    Status    => Pwr1_Status,
    Busy      => Pwr1_Bsy,
    Error     => Pwr1_Err,
    ErrorID   => Pwr1_ErrID
);

//MC_Power2
PWR2(
    Axis      := MC_Axis001,
    Enable    := Pwr2_En,
    Status    => Pwr2_Status,
    Busy      => Pwr2_Bsy,
    Error     => Pwr2_Err,
    ErrorID   => Pwr2_ErrID
);

// MC_Home1
HM1(
    Axis              := MC_Axis000,
    Execute           := Hm1_Ex,
    Done              => Hm1_D,
    Busy              => Hm1_Bsy,
    CommandAborted   => Hm1_Ca,
    Error             => Hm1_Err,
    ErrorID           => Hm1_ErrID
);

// MC_Home2
HM2(
    Axis              := MC_Axis001,
    Execute           := Hm2_Ex,
    Done              => Hm2_D,
    Busy              => Hm2_Bsy,
    CommandAborted   => Hm2_Ca,
    Error             => Hm2_Err,
    ErrorID           => Hm2_ErrID
);

//MC_GroupEnable
GRP_EN(
    AxesGroup        := MC_Group000,
    Execute          := Grp_En_Ex,
    Done             => Grp_En_D,
    Busy             => Grp_En_Bsy,
    CommandAborted   => Grp_En_Ca,
    Error            => Grp_En_Err,
    ErrorID          => Grp_En_ErrID
);

//MC_GroupDisable
GRP_DIS(
    AxesGroup        := MC_Group000,
    Execute          := Grp_Dis_Ex,
    Done             => Grp_Dis_D,
    Busy             => Grp_Dis_Bsy,
    CommandAborted   => Grp_Dis_Ca,
    Error            => Grp_Dis_Err,
    ErrorID          => Grp_Dis_ErrID
);

```



```
//MC_GroupReset
GRP_RESET(
  AxesGroup      := MC_Group000,
  Execute        := Grp_Reset_Ex,
  Done           => Grp_Reset_D,
  Busy           => Grp_Reset_Bsy,
  Failure        => Grp_Reset_Fai,
  Error          => Grp_Reset_Err,
  ErrorID       => Grp_Reset_ErrID
);
```

10-2-5 Monitoring for Instruction Errors

In this sample, further processing is not performed if there is an error when the MC_Power (Power Servo) instruction is executed. Whether further processing is possible is indicated by the *UpgOn* variable.


Samples are provided for both ladder diagram and ST programming.

Main Variables Used in the Programming Samples


Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF	---	This is the Axis Variable for axis 0.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. It is TRUE when the Servo is ON.
Pwr_Bsy	BOOL	FALSE	This variable is assigned to the <i>Busy</i> output variable from the PWR instance of the MC_Power instruction. It is TRUE when the Servo is ON.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.
UpgOn	BOOL	FALSE	TRUE if further program execution is performed.

Ladder Diagram


When *StartPg* is TRUE, the status of process data communications is checked to see if communications are active and normal.



The Servo for axis 0 is turned ON if process data communications are active and normal.



A check is made to see if any errors occurred when MC_Power was executed before execution of further processing.



ST Programming

```

// When StartPg is TRUE, the Servo is turned ON for axis 0 if process data communications are active and normal.
// If process data communications are not active, the Servo is turned OFF.
IF (StartPg=TRUE)
  AND (_EC_PDslavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
  AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
    Pwr_En:=TRUE;
ELSE
  Pwr_En:=FALSE;
END_IF;

IF (Pwr_Status=TRUE)
OR (Pwr_Bsy=TRUE) THEN
  UpgOn := TRUE;           // Further processing executed.
ELSE
  UpgOn := FALSE;        // Further processing not executed.
END_IF;

// MC_Power
PWR(
  Axis    := MC_Axis000,
  Enable  := Pwr_En,
  Status  => Pwr_Status,
  Busy    => Pwr_Bsy,
  Error   => Pwr_Err,
  ErrorID => Pwr_ErrID
);

```

10-2-6 Checking to See If Errors Are Reset

In this sample, the MC_Reset (Reset Axis Error) instruction is executed if an external button turns ON while there is a minor fault level error. Further normal processing is not executed until the *Done* output variable from the MC_Reset instruction changes to TRUE.

If the *Failure* output variable changes to TRUE, the axis decelerated to a stop or an MC common error has occurred. The cause that made the *Failure* output variable from the MC_Reset instruction turn ON is read.


Samples are provided for both ladder diagram and ST programming.

Main Variables Used in the Programming Samples


Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF	---	This is the Axis Variable for axis 0.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. It is TRUE when the Servo is ON.
ResetON	BOOL	FALSE	This variable gives the status of the external button that is used to reset errors.
GetFaultFactor	---	---	This is the process to read the cause of the error. Program it according to the device.
RegularProcess	---	---	This is the normal processing. Program it according to the device.

Ladder Diagram


In this sample, the MC_Reset (Reset Axis Error) instruction is executed if an external button turns ON (i.e., if *ResetOn* changes to TRUE) while there is a minor fault level error.



If the *Failure* output variable from the MC_Reset instruction changes to TRUE, processing is performed to read the cause of the device error with GetFaultFactor. Program GetFaultFactor according to the device.



If a minor fault level error did not occur or was reset, normal device processing (RegularProcess) is performed. Program GetFaultFactor according to the device.



ST Programming

```

// If the external button is ON (i.e., if ResetOn changes to TRUE) while there is a minor fault level error,
// the MC_Reset (Reset Axis Error) instruction is executed.
IF (MC_Axis000.MFaultLvl.Active=TRUE)
AND (ResetOn=TRUE) THEN
    Reset_Ex := TRUE;      // Minor fault is reset.
ELSE
    Reset_Ex := FALSE;
END_IF;

// If the Failure output variable from the MC_Reset instruction changes to TRUE,
// processing is performed to read the cause of the error with GetFaultFactor.
// Program GetFaultFactor according to the device.
IF (MC_Axis000.MFaultLvl.Active=TRUE)
AND (Reset_Fail=TRUE) THEN
    GetFaultFactor();
END_IF;

// If a minor fault level error did not occur or was reset,
// normal device processing (RegularProcess) is performed.
// Program GetFaultFactor according to the device.
IF MC_Axis000.MFaultLvl.Active=FALSE THEN
    RegularProcess();
END_IF;

// MC_Reset
RESET(
    Axis      := MC_Axis000,
    Execute   := Reset_Ex,
    Done      => Reset_D,
    Busy      => Reset_Bsy,
    Failure   => Reset_Fail,
    Error     => Reset_Err,
    ErrorID   => Reset_ErrID
);

```

10-2-7 Stopping Axes during Single-axis Operation

In this sample, the MC_Stop instruction is executed to decelerate to a stop if an external button turns ON during execution of the MC_MoveAbsolute (Absolute Positioning) instruction. If there is a minor fault level error, the *CommandAborted* output variable from the MC_Stop instruction changes to TRUE. In that case, the MC_ImmediateStop instruction is executed to stop immediately. If for any reason the *Error* output variable from the MC_Stop instruction changes to TRUE, the MC_ImmediateStop instruction is executed to stop immediately. If the MC_ImmediateStop instruction is executed, the axis status is Error Deceleration Stopping.


Samples are provided for both ladder diagram and ST programming.

Main Variables Used in the Programming Samples


Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF	---	This is the Axis Variable for axis 0.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 0.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. It is TRUE when the Servo is ON.
Stp_Ca	BOOL	FALSE	This variable is assigned to the <i>Command-Aborted</i> output variable from the STP instance of the MC_Stop instruction.
Stp_Err	BOOL	FALSE	This variable is assigned to the <i>Error</i> output variable from the STP instance of the MC_Stop instruction.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.
StopOn	BOOL	FALSE	This variable gives the status of the external button that is used to stop. The MC_Stop instruction is executed to stop the axis if this variable is TRUE.

Ladder Diagram


When *StartPg* is TRUE, the status of process data communications of axis 0 is checked to see if communications are active and normal.




The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal.




If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.




If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed for axis 0.




After homing is completed for axis 0, the MC_MoveAbsolute (Absolute Positioning) instruction is executed.



If StopOn is TRUE, the MC_Stop instruction is executed.



If the Error or CommandAborted output variable from the MC_Stop instruction changes to TRUE, the MC_ImmediateStop instruction is executed to stop immediately.



ST Programming

```

// If the input parameters for absolute positioning and stopping are not set, the target values and other parameters
// are set.
IF InitFlag=FALSE THEN
    // The input parameters for the MC_MoveAbsolute (Absolute Positioning) instruction are set.
    Mv_Abs_Pos    := LREAL#10000.0;
    Mv_Abs_Vel    := LREAL#500.0;
    Mv_Abs_Acc    := LREAL#500.0;
    Mv_Abs_Dec    := LREAL#500.0;
    Mv_Abs_Dir    := _eMC_DIRECTION#_mcPositiveDirection;

    // The input parameters for the MC_Stop instruction are set.
    Stp_Dec:=LREAL#5000.0;

    // The input parameters for the MC_Immediate Stop instruction are set.
    Imd_Stp_SM :=_eMC_STOP_MODE#_mcFreeRunStop;

    // The Input Parameter Initialization Completed Flag is changed to TRUE.
    InitFlag := TRUE;
END_IF;

// When StartPg is TRUE, the Servo is turned ON for axis 0 if process data communications are active and normal.
IF (StartPg=TRUE)
    AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
    AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
    Pwr_En:=TRUE;
ELSE
    Pwr_En:=FALSE;
END_IF;

// If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed.
// Program the FaultHandler according to the device.
IF MC_Axis000.MFaultLvl.Active=TRUE THEN
    FaultHandler();
END_IF;

// If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.
IF (Pwr_Status=TRUE)
    AND (MC_Axis000.Details.Homed=FALSE) THEN
    Hm_Ex:=TRUE;
END_IF;

// If homing is completed, absolute positioning is executed.
IF Hm_D=TRUE THEN
    Mv_Abs_Ex := TRUE;
END_IF;

// If StopOn is TRUE, stopping is executed.
IF StopOn=TRUE THEN
    Stp_Ex:=TRUE;
END_IF;

// If the Error or CommandAborted output variable from the MC_Stop instruction changes to TRUE, the
// MC_ImmediateStop instruction is executed to stop immediately.
IF (Stp_Err=TRUE)
    OR (Stp_Ca=TRUE) THEN
    Imd_Stp_Ex:=TRUE;
END_IF;

//MC_Power
PWR(

```



```

        Axis      := MC_Axis000,
        Enable    := Pwr_En,
        Status    => Pwr_Status,
        Busy      => Pwr_Bsy,
        Error     => Pwr_Err,
        ErrorID   => Pwr_ErrID
    );

//MC_Home
HM(
    Axis      := MC_Axis000,
    Execute   := Hm_Ex,
    Done      => Hm_D,
    Busy      => Hm_Bsy,
    CommandAborted := Hm_Ca,
    Error     => Hm_Err,
    ErrorID   => Hm_ErrID
);

//MC_MoveAbsolute
MV_ABS(
    Axis      := MC_Axis000,
    Execute   := Mv_Abs_Ex,
    Position  := Mv_Abs_Pos,
    Velocity  := Mv_Abs_Vel,
    Acceleration := Mv_Abs_Acc,
    Deceleration := Mv_Abs_Dec,
    Direction := Mv_Abs_Dir,
    Done      => Mv_Abs_D,
    Busy      => Mv_Abs_Bsy,
    Active    => Mv_Abs_Act,
    CommandAborted := Mv_Abs_Ca,
    Error     => Mv_Abs_Err,
    ErrorID   => Mv_Abs_ErrID
);

//MC_Stop
STP(
    Axis      := MC_Axis000,
    Execute   := Stp_Ex,
    Deceleration := Stp_Dec,
    Done      => Stp_D,
    Busy      => Stp_Bsy,
    Active    => Stp_Act,
    CommandAborted := Stp_Ca,
    Error     => Stp_Err,
    ErrorID   => Stp_ErrID
);

//MC_ImmediateStop
IMD_STP(
    Axis      := MC_Axis000,
    Execute   := Imd_Stp_Ex,
    StopMode  := Imd_Stp_SM,
    Done      => Imd_Stp_D,
    Busy      => Imd_Stp_Bsy,
    CommandAborted := Imd_Stp_Ca,
    Error     => Imd_Stp_Err,
    ErrorID   => Imd_Stp_ErrID
);

```

10-2-8 Stopping an Axes Group in Coordinated Motion


In this sample, the MC_GroupStop instruction is executed to decelerate to a stop if an external button turns ON during execution of the MC_MoveLinearAbsolute (Absolute Linear Interpolation) instruction. If there is a minor fault level error, the *CommandAborted* output variable from the MC_GroupStop instruction changes to TRUE. In that case, the MC_GroupImmediateStop instruction is executed to stop immediately. If for any reason the *Error* output variable from the MC_GroupStop instruction changes to TRUE, the MC_GroupImmediateStop instruction is executed to stop immediately. If the MC_GroupImmediateStop instruction is executed, the axes group status is Error Deceleration Stopping.

Main Variables Used in the Programming Samples


Variable name	Data type	Default	Comment
MC_Group000	_sGROUP_REF	---	This is the Axes Group Variable for axes group 0.
MC_Group000.Status.Disabled	BOOL	FALSE	TRUE when axes group 0 is disabled.
MC_Group000.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axes group 0.
MC_Axis000	_sAXIS_REF	---	This is the Axis Variable for axis 0.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 0.
MC_Axis001	_sAXIS_REF	---	This is the Axis Variable for axis 1.
MC_Axis001.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 1.
MC_Axis001.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
Pwr1_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
Pwr2_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR2 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
Grp_Stp_Ca	BOOL	FALSE	This variable is assigned to the <i>CommandAborted</i> output variable from the GRP_EN instance of the MC_GroupStop instruction.
Grp_Stp_Err	BOOL	FALSE	This variable is assigned to the <i>Error</i> output variable from the GRP_EN instance of the MC_GroupStop instruction.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.
StopOn	BOOL	FALSE	This variable gives the status of the external button that is used to stop. The MC_GroupStop instruction is executed to stop the axes group if this variable is TRUE.
InitFlag	BOOL	FALSE	TRUE if the input parameters are set for the MC_MoveLinearAbsolute and MC_GroupStop instructions.
Grp_En_Ex	BOOL	FALSE	This variable is used to execute the GRP_EN instance of the MC_GroupEnable instruction. It is used in ST programming.
Mv_Lin_Abs_Ex	BOOL	FALSE	This variable is used to execute the MV_LIN_ABS instance of the MC_MoveLinear instruction. It is used in ST programming.
Grp_Stp_Ex	BOOL	FALSE	This variable is used to execute the GRP_STP instance of the MC_GroupStop instruction. It is used in ST programming.
Grp_Imd_Stp_Ex	BOOL	FALSE	This variable is used to execute the GRP_IMD_STP instance of the MC_GroupImmediateStop instruction. It is used in ST programming.

Ladder Diagram


When *StartPg* is TRUE, the status of process data communications of axis 0 is checked to see if communications are active and normal.




When *StartPg* is TRUE, the status of process data communications of axis 1 is checked to see if communications are active and normal.




The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal.




The Servo for axis 1 is turned ON if process data communications for axis 1 are active and normal.




If a minor fault level error occurs for the axes group, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.




If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.




If the Servo is ON for axis 1 and home is not defined, the MC_Home instruction is executed.




After home is defined for axis 0 and axis 1, the axes group is enabled.




The input parameters for the MC_MoveLinearAbsolute and MC_GroupStop instructions are set.




If the axes group is enabled, linear interpolation is executed.



If the external button turns ON (i.e., StopOn changes to TRUE) during execution of linear interpolation, the MC_GroupStop instruction is executed to decelerate the axes to a stop.



If the Error or CommandAborted output variable of the MC_GroupStop instruction is TRUE, the MC_GroupImmediateStop instruction is executed to stop immediately.



ST Programming

// If the input parameters for absolute linear interpolation and stopping the axes group are not set, the target values and other parameters are set.

IF InitFlag=FALSE THEN

// The input parameters for the MC_MoveLinearAbsolute (Absolute Linear Interpolation) instruction are set.

```
Mv_Lin_Abs_Pos[0] := LREAL#3000.0;
Mv_Lin_Abs_Pos[1] := LREAL#3000.0;
Mv_Lin_Abs_Vel   := LREAL#1000.0;
Mv_Lin_Abs_Acc   := LREAL#1000.0;
Mv_Lin_Abs_Dec   := LREAL#1000.0;
Mv_Lin_Abs_Jrk   := LREAL#1000.0;
```

// The input parameters for the MC_GroupStop instruction are set.

```
Grp_Stp_Dec := LREAL#1000.0;
Grp_Stp_Jrk := LREAL#1000.0;
```

// The Input Parameter Initialization Completed Flag is changed to TRUE.

```
InitFlag := TRUE;
```

END_IF;

// When StartPg is TRUE, the Servo is turned ON for axis 0 if process data communications are active and normal.

// If process data communications are not active, the Servo is turned OFF.

IF (StartPg =TRUE)

AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)

AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN

```
Pwr1_En:=TRUE; // Turn ON the Servo for axis 0.
```

ELSE

```
Pwr1_En:=FALSE; // Turn OFF the Servo for axis 0.
```

END_IF;

// When StartPg is TRUE, the Servo is turned ON for axis 1 if process data communications are active and normal.

// If process data communications are not active, the Servo is turned OFF.

IF (StartPg =TRUE)

AND (_EC_PDSlavTbl[MC_Axis001.Cfg.NodeAddress]=TRUE) THEN

```
Pwr2_En:=TRUE; // Turn ON the Servo for axis 1.
```

ELSE

```
Pwr2_En:=FALSE; // Turn OFF the Servo for axis 1.
```

END_IF;

// If a minor fault level error occurs, the error handler for the device (FaultHandler) is executed.

```
IF (MC_Axis000.MFaultLvl.Active=TRUE)
```

```
OR (MC_Axis001.MFaultLvl.Active=TRUE)
```

```
OR (MC_Group000.MFaultLvl.Active=TRUE) THEN
```

```
FaultHandler();
```

END_IF;

// If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed for axis 0.

```
IF (Pwr1_Status=TRUE)
```

```
AND (MC_Axis000.Details.Homed=FALSE) THEN
```

```
Hm1_Ex:=TRUE;
```

END_IF;

// If the Servo is ON for axis 1 and home is not defined, the MC_Home instruction is executed for axis 1.

```
IF (Pwr2_Status=TRUE)
```

```
AND (MC_Axis001.Details.Homed=FALSE) THEN
```

```
Hm2_Ex:=TRUE;
```

END_IF;

```

// If home is defined for axis 0 and axis 1 and the axes group is disabled, the axes group is enabled.
IF (MC_Group000.Status.Disabled=TRUE)
AND (Hm1_D=TRUE) AND (Hm2_D=TRUE) THEN
  Grp_En_Ex:= TRUE;
END_IF;

// If the axes group is enabled, absolute linear interpolation is executed.
IF MC_Group000.Status.Ready=TRUE THEN
  Mv_Lin_Abs_Ex:=TRUE;
END_IF;

// If the external button turns ON (i.e., StopOn changes to TRUE) during execution of absolute linear interpolation,
the axes group is stopped.
IF (MC_Group000.Status.Moving=TRUE)
AND (StopOn=TRUE) THEN
  Grp_Stp_Ex := TRUE;
END_IF;

// If the CommandAborted or Error output variable from the Group Stop instruction are TRUE, the axes group is
stopped immediately.
IF (Grp_Stp_Ca=TRUE)
OR (Grp_Stp_Err=TRUE) THEN
  Grp_Imd_Stp_Ex:=TRUE;
END_IF;

//MC_Power
PWR1(
  Axis      := MC_Axis000,
  Enable    := Pwr1_En,
  Status    => Pwr1_Status,
  Busy      => Pwr1_Bsy,
  Error     => Pwr1_Err,
  ErrorID   => Pwr1_ErrID
);

PWR2(
  Axis      := MC_Axis001,
  Enable    := Pwr2_En,
  Status    => Pwr2_Status,
  Busy      => Pwr2_Bsy,
  Error     => Pwr2_Err,
  ErrorID   => Pwr2_ErrID
);

//MC_Home
HM1(
  Axis              := MC_Axis000,
  Execute           := Hm1_Ex,
  Done              => Hm1_D,
  Busy              => Hm1_Bsy,
  CommandAborted   => Hm1_Ca,
  Error             => Hm1_Err,
  ErrorID          => Hm1_ErrID
);

HM2(
  Axis              := MC_Axis001,
  Execute           := Hm2_Ex,
  Done              => Hm2_D,
  Busy              => Hm2_Bsy,
  CommandAborted   => Hm2_Ca,
  Error             => Hm2_Err,
  ErrorID          => Hm2_ErrID
);

```

```

//MC_GroupEnable
GRP_EN(
    AxesGroup           := MC_Group000,
    Execute             := Grp_En_Ex,
    Done                => Grp_En_D,
    Busy                => Grp_En_Bsy,
    CommandAborted     => Grp_En_Ca,
    Error               => Grp_En_Err,
    ErrorID             => Grp_En_ErrID
);

//MC_MoveLinearAbsolute
MV_LIN_ABS(
    AxesGroup           := MC_Group000,
    Execute             := Mv_Lin_Abs_Ex,
    Position            := Mv_Lin_Abs_Pos,
    Velocity            := Mv_Lin_Abs_Vel,
    Acceleration        := Mv_Lin_Abs_Acc,
    Deceleration        := Mv_Lin_Abs_Dec,
    Jerk                := Mv_Lin_Abs_Jrk,
    Done                => Mv_Lin_Abs_D,
    Busy                => Mv_Lin_Abs_Bsy,
    Active              => Mv_Lin_Abs_Act,
    CommandAborted     => Mv_Lin_Abs_Ca,
    Error               => Mv_Lin_Abs_Err,
    ErrorID             => Mv_Lin_Abs_ErrID
);


//MC_GroupStop
GRP_STP(
    AxesGroup           := MC_Group000,
    Execute             := Grp_Stp_Ex,
    Deceleration        := Grp_Stp_Dec,
    Done                => Grp_Stp_D,
    Busy                => Grp_Stp_Bsy,
    Active              => Grp_Stp_Act,
    CommandAborted     => Grp_Stp_Ca,
    Error               => Grp_Stp_Err,
    ErrorID             => Grp_Stp_ErrID
);

//MC_GroupImmediateStop
GRP_IMD_STP(
    AxesGroup           := MC_Group000,
    Execute             := Grp_Imd_Stp_Ex,
    Done                => Grp_Imd_Stp_D,
    Busy                => Grp_Imd_Stp_Bsy,
    CommandAborted     => Grp_Imd_Stp_Ca,
    Error               => Grp_Imd_Stp_Err,
    ErrorID             => Grp_Imd_Stp_ErrID
);

```

10-2-9 Homing and Absolute Positioning

In this sample, the starting point for homing is assumed to be where the home proximity input is ON. The Homing Method is set to *home proximity input OFF*. After homing is completed to define home, absolute positioning is executed.



Samples are provided for both ladder diagram and ST programming.

Axis Parameter Settings That Are Related to Homing

Parameter name	Setting	Description
Homing Method	4: Home proximity input OFF	Home is defined where the home proximity input turns OFF.
Operation Selection at Positive Limit Input	1: Reverse turn/immediate stop	The positive limit input is not used, so the default setting is used for this parameter.
Operation Selection at Negative Limit Input	2: Reverse turn/deceleration stop	The axis decelerates to a stop and reverses direction when the negative limit input is detected.
Homing Start Direction	2: Negative direction	When homing is performed, the axis starts moving in the negative direction.
Home Input Detection Direction	1: Positive direction	Home is detected while the axis moves in the positive direction.


Main Variables Used in the Programming Samples

Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF	---	This is the Axis Variable for axis 0.
MC_Axis000.Status.StandStill	BOOL	FALSE	TRUE while the Servo is OFF for axis 0.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 0.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. It is TRUE when the Servo is ON.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.
Hm_Ex	BOOL	FALSE	This variable is used to execute the MC_Home instruction. It is used in ST programming.


Variable name	Data type	Default	Comment
Mv_Abs_Ex	BOOL	FALSE	This variable is used to execute the MC_MoveAbsolute (Absolute Positioning) instruction. It is used in ST programming.

Timing Chart

● Ladder Diagram




● ST Programming




Ladder Diagram


When *StartPg* is TRUE, the status of process data communications of axis 0 is checked to see if communications are active and normal.




The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal.




If a minor fault level error occurs for axis 0, the error handler for the device (*FaultHandler*) is executed. Program the *FaultHandler* according to the device.



If the Servo is ON for axis 0 and home is not defined, the *MC_Home* instruction is executed.



If the Servo is ON and home is defined, absolute positioning is executed.



ST Programming

```

// If the input parameters for absolute positioning are not set, the target values and other parameters are set.
IF InitFlag=FALSE THEN
    // The input parameters for the MC_MoveAbsolute (Absolute Positioning) instruction are set.
    Mv_Abs_Pos      := LREAL#50000.0;
    Mv_Abs_Vel      := LREAL#10000.0;
    Mv_Abs_Acc      := LREAL#1000.0;
    Mv_Abs_Dec      := LREAL#1000.0;
    Mv_Abs_Dir      := _eMC_DIRECTION#_mcShortestWay;

    // The Input Parameter Initialization Completed Flag is changed to TRUE.
    InitFlag := TRUE;
END_IF;

// When StartPg is TRUE, the Servo is turned ON for axis 0 if process data communications are active and normal.
IF (StartPg=TRUE)
    AND (_EC_PDslavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
    AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
        Pwr_En:=TRUE;
    ELSE
        Pwr_En:=FALSE;
    END_IF;

// If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed.
// Program the FaultHandler according to the device.
IF MC_Axis000.MFaultLvl.Active=TRUE THEN
    FaultHandler();
END_IF;

// If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.
IF (Pwr_Status=TRUE)
    AND (MC_Axis000.Details.Homed=FALSE) THEN
        Hm_Ex:=TRUE;
    ELSE
        Hm_Ex:=FALSE;
    END_IF;

// If the Servo is ON and home is defined, absolute positioning is executed.
IF (Pwr_Status=TRUE)
    AND (Hm_D=TRUE) THEN
        Mv_Abs_Ex:=TRUE;
    END_IF;

//MC_Power
PWR(
    Axis      := MC_Axis000,
    Enable    := Pwr_En,
    Status    => Pwr_Status,
    Busy      => Pwr_Bsy,
    Error     => Pwr_Err,
    ErrorID   => Pwr_ErrID
);

//MC_Home
HM(
    Axis              := MC_Axis000,
    Execute           := Hm_Ex,
    Done              => Hm_D,
    Busy              => Hm_Bsy,
    CommandAborted   => Hm_Ca,
    Error             => Hm_Err,
    ErrorID           => Hm_ErrID

```

```
);  
  
//MC_MoveAbsolute  
MV_ABS(  
    Axis           := MC_Axis000,  
    Execute        := Mv_Abs_Ex,  
    Position       := Mv_Abs_Pos,  
    Velocity       := Mv_Abs_Vel,  
    Acceleration   := Mv_Abs_Acc,  
    Deceleration   := Mv_Abs_Dec,  
    Direction      := Mv_Abs_Dir,  
    Done           => Mv_Abs_D,  
    Busy           => Mv_Abs_Bsy,  
    Active         => Mv_Abs_Act,  
    CommandAborted => Mv_Abs_Ca,  
    Error          => Mv_Abs_Err,  
    ErrorID       => Mv_Abs_ErrID  
);
```

10-2-10 Changing the Target Position by Re-execution of an Instruction


This sample starts absolute positioning to a target position of 1000 and then uses the same instance of the absolute positioning instruction to change the target position to 2000.

Main Variables Used in the Programming Samples


Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF	---	This is the Axis Variable for axis 0.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 0.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. It is TRUE when the Servo is ON.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.
ReExeSw	BOOL	FALSE	This variable is used to re-execute the instruction.
Mv_Abs_Ex	BOOL	FALSE	This variable is used to execute the MC_MoveAbsolute (Absolute Positioning) instruction. It is used in ST programming.
Hm_Ex	BOOL	FALSE	This variable is used to execute the MC_Home instruction. It is used in ST programming.

Timing Chart

● Ladder Diagram




● ST Programming




Ladder Diagram


When StartPg is TRUE, the status of process data communications of axis 0 is checked to see if communications are active and normal.




The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal.



If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.




If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.




After home is defined for axis 0, absolute positioning is executed if it is not already in progress.



When ReExeSw changes to TRUE, the absolute positioning instruction is re-executed to change the target position to 2000.



Absolute positioning is executed according to the status of Mv_Abs_Ex.



ST Programming

```

// If the input parameters for absolute positioning are not set, the target values and other parameters are set.
IF InitFlag = FALSE THEN
    // Parameters for MC_MoveAbsolute
    Mv_Abs_Pos    := LREAL#1000.0;
    Mv_Abs_Vel    := LREAL#500.0;
    Mv_Abs_Acc    := LREAL#500.0;
    Mv_Abs_Dec    := LREAL#500.0;
    Mv_Abs_Dir    := _eMC_DIRECTION#_mcPositiveDirection;

    // The Input Parameter Initialization Completed Flag is changed to TRUE.
    InitFlag:=TRUE;
END_IF;

// When StartPg is TRUE, the Servo is turned ON for axis 0 if process data communications are active and normal.
IF (StartPg=TRUE)
    AND (_EC_PDslavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
    AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
        Pwr_En:=TRUE;
    ELSE
        Pwr_En:=FALSE;
    END_IF;

// If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed.
// Program the FaultHandler according to the device.
IF MC_Axis000.MFaultLvl.Active=TRUE THEN
    FaultHandler();
END_IF;

// If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.
IF (Pwr_Status=TRUE)
    AND (MC_Axis000.Details.Homed=FALSE) THEN
        Hm_Ex:=TRUE;
    END_IF;

// After homing is completed for axis 0, absolute positioning is executed if it is not already in progress.
IF (Hm_D=TRUE)
    AND (Mv_Abs_Act=FALSE) THEN
        Mv_Abs_Ex := TRUE;
    ELSE
        Mv_Abs_Ex := FALSE;
    END_IF;

// When ReExeSw changes to TRUE, the absolute positioning instruction is re-executed to change the target
// position to 2000.
IF ReExeSw=TRUE THEN
    Mv_Abs_Pos    :=LREAL#2000.0;
    Mv_Abs_Ex     := TRUE;
END_IF;

//MC_Power
PWR(
    Axis    := MC_Axis000,
    Enable  := Pwr_En,
    Status  => Pwr_Status,
    Busy    => Pwr_Bsy,
    Error   => Pwr_Err,

```

```

        ErrorID => Pwr_ErrID
    );

//MC_Home
HM(
    Axis           := MC_Axis000,
    Execute        := Hm_Ex,
    Done           => Hm_D,
    Busy           => Hm_Bsy,
    CommandAborted => Hm_Ca,
    Error          => Hm_Err,
    ErrorID        => Hm_ErrID
);

//MC_MoveAbsolute
MV_ABS(
    Axis           := MC_Axis000,
    Execute        := Mv_Abs_Ex,
    Position       := Mv_Abs_Pos,
    Velocity       := Mv_Abs_Vel,
    Acceleration   := Mv_Abs_Acc,
    Deceleration   := Mv_Abs_Dec,
    Direction      := Mv_Abs_Dir,
    Done           => Mv_Abs_D,
    Busy           => Mv_Abs_Bsy,
    Active         => Mv_Abs_Act,
    CommandAborted => Mv_Abs_Ca,
    Error          => Mv_Abs_Err,
    ErrorID        => Mv_Abs_ErrID
);


```

10-2-11 Interrupt Feeding

This sample performs interrupt feeding when an interrupt occurs during velocity control. One of the following is specified for the *Direction* variable when velocity control is performed in Rotary Mode.

- *_mcPositiveDirection*
- *_mcNegativeDirection*
- *_mcCurrentDirection*

This sample uses *_mcCurrentDirection*. A positive value is specified for the *FeedDistance* input variable to perform feeding in the same direction as the motion before the interrupt input. A negative value is specified for the *FeedDistance* input variable to perform feeding in the opposite direction as the motion before the interrupt input. For example, if a positive value is specified for the *FeedDistance* input variable when the motion was in the negative direction before the interrupt input, feeding is performed in the negative direction. If a negative value is specified for the *FeedDistance* input variable, feeding is performed in the positive direction.



Axis Parameter Settings

Parameter name	Setting	Description
Count Mode	Rotary Mode	Rotary Mode is set as the count mode for the position.
Modulo Maximum Position Setting Value	360	The Modulo Maximum Position is set to 360.
Modulo Minimum Position Setting Value	0	The Modulo Minimum Position is set to 0.
Homing Method	Zero position preset	A zero position preset is performed to define home.


Main Variables Used in the Programming Samples

Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF	---	This is the Axis Variable for axis 0.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 0.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. It is TRUE when the Servo is ON.
TrigRef	_sTRIGGER_REF	---	This parameter specifies the trigger input condition to use for the interrupt input. Latch 1 of the Servo Drive is used in this sample.
Hm_Ex	BOOL	FALSE	This variable is used to execute the MC_Home instruction. It is used in ST programming.


Variable name	Data type	Default	Comment
Mv_Feed_Ex	BOOL	FALSE	This variable is used to execute the MC_MoveFeed (Interrupt Feeding) instruction. It is used in ST programming.
InitFlag	BOOL	FALSE	TRUE if the input parameters are set for the MC_MoveFeed instruction.

Ladder Diagram


When *StartPg* is TRUE, the status of process data communications of axis 0 is checked to see if communications are active and normal.




The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal.




If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.




If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.



The input parameters for interrupt feeding are set.



If homing is completed, interrupt feeding is executed.



ST Programming

// If the input parameters for interrupt feeding are not set, the target values and other parameters are set.

IF InitFlag=FALSE THEN

// Parameters for MC_MoveFeed

```
Mv_Feed_TriggerRef.Mode      := _eMC_TRIGGER_MODE#_mcDrive;
Mv_Feed_TriggerRef.LatchID   := _eMC_TRIGGER_LATCH_ID#_mcLatch1;
Mv_Feed_TriggerRef.InputDrive := _eMC_TRIGGER_INPUT_DRIVE#_mcEncoderMark;
Mv_Feed_TriggerVar           := FALSE;
Mv_Feed_Pos                  := LREAL#2000.0;
Mv_Feed_Vel                  := LREAL#1000.0;
Mv_Feed_Acc                  := LREAL#10000.0;
Mv_Feed_Dec                  := LREAL#10000.0;
Mv_Feed_Dir                  := _eMC_DIRECTION#_mcCurrentDirection;
Mv_Feed_Mm                   := _eMC_MOVE_MODE#_mcVelocity;
Mv_Feed_FeedDis              := LREAL#500.0;
Mv_Feed_FeedVel              := LREAL#500.0;
```

// The Input Parameter Initialization Completed Flag is changed to TRUE.

InitFlag := TRUE;

END_IF;

// When StartPg is TRUE, the Servo is turned ON for axis 0 if process data communications are active and normal.

IF (StartPg=TRUE)

AND (_EC_PDslavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)

AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN

Pwr_En:=TRUE;

ELSE

Pwr_En:=FALSE;

END_IF;

// If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed.

// Program the FaultHandler according to the device.

IF MC_Axis000.MFaultLvl.Active=TRUE THEN

FaultHandler();

END_IF;

```
// If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.
IF (Pwr_Status=TRUE)
AND (MC_Axis000.Details.Homed=FALSE) THEN
  Hm_Ex:=TRUE;
END_IF;
```

```
// If homing is defined, interrupt feeding is executed.
IF Hm_D=TRUE THEN
  Mv_Feed_Ex:=TRUE;
END_IF;
```

```
// MC_Power
PWR(
  Axis      := MC_Axis000,
  Enable    := Pwr_En,
  Status    => Pwr_Status,
  Busy      => Pwr_Bsy,
  Error     => Pwr_Err,
  ErrorID   => Pwr_ErrID
);
```

```
// MC_Home
HM(
  Axis          := MC_Axis000,
  Execute       := Hm_Ex,
  Done          => Hm_D,
  Busy          => Hm_Bsy,
  CommandAborted => Hm_Ca,
  Error         => Hm_Err,
  ErrorID       => Hm_ErrID
);
```

```
//MC_MoveFeed
MV_FEED(
  Axis          := MC_Axis000,
  TriggerInput  := Mv_Feed_TrigRef,
  TriggerVariable := Mv_Feed_TrigVar,
  Execute       := Mv_Feed_Ex,
  Position      := Mv_Feed_Pos,
  Velocity      := Mv_Feed_Vel,
  Acceleration  := Mv_Feed_Acc,
  Deceleration  := Mv_Feed_Dec,
  Direction     := Mv_Feed_Dir,
  MoveMode      := Mv_Feed_Mm,
  FeedDistance  := Mv_Feed_FeedDis,
  FeedVelocity  := Mv_Feed_FeedVel,
  Done          => Mv_Feed_D,
  InFeed       => Mv_Feed_InFeed,
  Busy         => Mv_Feed_Bsy,
  Active        => Mv_Feed_Act,
  CommandAborted => Mv_Feed_Ca,
  Error         => Mv_Feed_Err,
  ErrorID       => Mv_Feed_ErrID
);
```

10-2-12 Changing the Cam Table by Re-execution of an Instruction

This sample changes the cam table during cam motion. *CamProfile0* is used when the command position for axis 0 is 5000 or less and *CamProfile1* is used when it is over 5000.


Main Variables Used in the Programming Samples

Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF	---	This is the Axis Variable for axis 0.
MC_Axis001	_sAXIS_REF	---	This is the Axis Variable for axis 1.
CamProfile0	ARRAY[0..100] OF _sMC_CAM_REF	---	This is the cam data variable.*
CamProfile1	ARRAY[0..10] OF _sMC_CAM_REF	---	This is the cam data variable.*
Pwr1_S	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
Pwr2_S	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR2 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
CamTable0	BOOL	FALSE	TRUE when <i>CamProfile0</i> is used for the cam table.
CamTable1	BOOL	FALSE	TRUE when <i>CamProfile1</i> is used for the cam table.
Camin_InCam0	BOOL	FALSE	This variable is assigned to the <i>InCam</i> output variable from the CAMIN instance of the MC_CamIn instruction. It is TRUE during cam motion for <i>CamProfile0</i> . After this variable changes to TRUE, it remains TRUE until the operation is completed or canceled.
Camin_InCam1	BOOL	FALSE	This variable is assigned to the <i>InCam</i> output variable from the CAMIN instance of the MC_CamIn instruction. It is TRUE during cam motion for <i>CamProfile1</i> . After this variable changes to TRUE, it remains TRUE until the operation is completed or canceled.
Mv_Abs_Act	BOOL	FALSE	This variable is assigned to the <i>Active</i> output variable from the MV_ABS instance of the MC_MoveAbsolute instruction.
Hm1_Ex	BOOL	FALSE	This variable is used to re-execute the MC_Home instruction for axis 0.
Hm2_Ex	BOOL	FALSE	This variable is used to re-execute the MC_Home instruction for axis 1.
Mv_Abs_Ex	BOOL	FALSE	This variable is used to execute the MC_MoveAbsolute (Absolute Positioning) instruction.
Camin_Ex	BOOL	FALSE	This variable is used to execute the MC_CamIn (Start Cam) instruction. It is used in ST programming.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.


* The array elements ARRAY[0..N] are set with the Cam Editor in the Sysmac Studio. The range of the array is 0 to 109 in this sample.

Timing Chart

● Ladder Diagram




● ST Programming




Ladder Diagram

To change from one cam table to another, two instances of the MC_CamIn (Start Cam Operation) instruction with the same instance name are used. A different output parameter is assigned to the *InCam* (Cam Motion) output variable from each instance. An error will occur if you assign the same output parameter. In this sample, a JMP (Jump) instruction is used so that both instances are not executed at the same time.


When *StartPg* is TRUE, the status of process data communications of axis 0 is checked to see if communications are active and normal.




When *StartPg* is TRUE, the status of process data communications of axis 1 is checked to see if communications are active and normal.




The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal.




The Servo for axis 1 is turned ON if process data communications for axis 1 are active and normal.




If a minor fault level error occurs for axis 0 or axis 1, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.




If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.




If the Servo is ON for axis 1 and home is not defined, the MC_Home instruction is executed.



If homing is completed for axis 0, absolute positioning is executed.





If the command position for axis 0 is 5000 or less, *CamTable0* is changed to TRUE and *CamTable1* is changed to FALSE. If it is over 5000, *CamTable0* is changed to FALSE and *CamTable1* is changed to TRUE.



If *CamTable0* is TRUE during absolute positioning, then the instance that uses *CamProfile0* for the cam table is executed.



If *InCam* is TRUE, then *Execute* is changed to FALSE.






If *CamTable1* is TRUE during absolute positioning, then the instance that uses *CamProfile1* for the cam table is executed.

SkipCamTable0



SkipCamTable1



ST Programming

// If the input parameters for absolute positioning and starting cam operation are not set, the target values and other parameters are set.

```
IF InitFlag=FALSE THEN
  // The input parameters for the MC_MoveAbsolute (Absolute Positioning) instruction are set.
  Mv_Abs_Pos    := LREAL#10000.0;
  Mv_Abs_Vel    := LREAL#2000.0;
  Mv_Abs_Acc    := LREAL#2000.0;
  Mv_Abs_Dec    := LREAL#2000.0;
  // The input parameters for the MC_CamIn (Start Cam Operation) instruction are set.
  Camin_EM      := TRUE;
  Camin_StMode  := _eMC_START_MODE#_mcAbsolutePosition;
  Camin_StPos   := LREAL#1.0;
  Camin_MStDis  := LREAL#1.0;
  Camin_MSc     := LREAL#1.0;
  Camin_SSc     := LREAL#1.0;
  Camin_MO      := LREAL#0.0;
  Camin_SO      := LREAL#0.0;
  Camin_RT      := _eMC_REFERENCE_TYPE#_mcCommand;
  Camin_Dir     := _eMC_DIRECTION#_mcNoDirection;
  // The cam table is selected.
  CamTable0     := BOOL#TRUE;
  CamTable1     := BOOL#FALSE;
```

// The Input Parameter Initialization Completed Flag is changed to TRUE.

InitFlag := TRUE;

END_IF;

// When *StartPg* is TRUE, the Servo is turned ON for axis 0 if process data communications are active and normal.

```
IF (StartPg=TRUE)
  AND (_EC_PDslavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
  AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
  Pwr_En:=TRUE;
ELSE
  Pwr_En:=FALSE;
END_IF;
```

// When *StartPg* is TRUE, the Servo is turned ON for axis 1 if process data communications are active and normal.

```
IF (StartPg=TRUE)
  AND (_EC_PDslavTbl[MC_Axis001.Cfg.NodeAddress]=TRUE)
  AND (_EC_CommErrTbl[MC_Axis001.Cfg.NodeAddress]=FALSE) THEN
  Pwr2_En:=TRUE;
ELSE
  Pwr2_En:=FALSE;
END_IF;
```

// If a minor fault level error occurs for axis 0 or axis 1, the error handler for the device (FaultHandler) is executed.

// Program the FaultHandler according to the device.

```
IF (MC_Axis000.MFaultLvl.Active=TRUE)
  OR (MC_Axis001.MFaultLvl.Active=TRUE) THEN
  FaultHandler();
END_IF;
```

// If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.

```
IF (Pwr1_S=TRUE)
  AND (MC_Axis000.Details.Homed=FALSE) THEN
  Hm1_Ex:=TRUE;
END_IF;
```

// If the Servo is ON for axis 1 and home is not defined, the MC_Home instruction is executed.

```

IF (Pwr2_S=TRUE)
AND (MC_Axis001.Details.Homed=FALSE) THEN
    Hm2_Ex:=TRUE;
END_IF;

// If homing is completed for axis 0, absolute positioning is executed.
IF Hm1_D=TRUE THEN
    Mv_Abs_Ex := TRUE;
END_IF;

// If the command position for axis 0 is 5000 or less, CamTable0 is changed to TRUE and CamTable1 is changed to FALSE.
// If it exceeds 5000, CamTable0 is changed to FALSE and CamTable1 is changed to TRUE.
IF MC_Axis000.Cmd.Pos<=LREAL#5000.0 THEN
    CamTable0    :=BOOL#TRUE;
    CamTable1    :=BOOL#FALSE;
ELSE
    CamTable0    :=BOOL#FALSE;
    CamTable1    :=BOOL#TRUE;
END_IF;

// If CamTable0 is TRUE during absolute positioning,
// then the instance that uses CamProfile0 for the cam table is executed.
// If InCam is TRUE, Execute is changed to FALSE.
IF (Mv_Abs_Act=TRUE)
AND (CamTable0=TRUE)
AND (Camin_InCam0=FALSE) THEN
    Camin_Ex     := TRUE;
ELSE
    Camin_Ex     := FALSE;
END_IF;

// If CamTable1 is TRUE during absolute positioning,
// then the instance that uses CamProfile1 for the cam table is executed.
IF (Mv_Abs_Act=TRUE)
AND (CamTable1=TRUE) THEN
    Camin_Ex     := TRUE;
END_IF;

//MC_Camin
IF CamTable0=TRUE THEN
    CAMIN(
        Master           := MC_Axis000,
        Slave            := MC_Axis001,
        CamTable         := CamProfile0,
        Execute          := Camin_Ex,
        Periodic         := Camin_EM,
        StartMode        := Camin_StMode,
        StartPosition    := Camin_StPos,
        MasterStartDistance := Camin_MStDis,
        MasterScaling    := Camin_MSc,
        SlaveScaling     := Camin_SSc,
        MasterOffset     := Camin_MO,
        SlaveOffset      := Camin_SO,
        ReferenceType    := Camin_RT,
        Direction        := Camin_Dir,
        InCam             => Camin_InCam0,
        InSync           => Camin_InSync,
        EndOfProfile     => Camin_EOP,
        Index            => Camin_Index,
        Busy              => Camin_Bsy,
    )

```

```

        Active           => Camin_Act,
        CommandAborted  => Camin_Ca,
        Error           => Camin_Err,
        ErrorID         => Camin_ErrID
    );
END_IF;

IF CamTable1=TRUE THEN
    CAMIN(
        Master           := MC_Axis000,
        Slave           := MC_Axis001,
        CamTable        := CamProfile1,
        Execute         := Camin_Ex,
        Periodic        := Camin_EM,
        StartMode       := Camin_StMode,
        StartPosition   := Camin_StPos,
        MasterStartDistance := Camin_MStDis,
        MasterScaling   := Camin_MSc,
        SlaveScaling    := Camin_SSc,
        MasterOffset    := Camin_MO,
        SlaveOffset     := Camin_SO,
        ReferenceType   := Camin_RT,
        Direction       := Camin_Dir,
        InCam           => Camin_InCam1,
        InSync          => Camin_InSync,
        EndOfProfile    => Camin_EOP,
        Index           => Camin_Index,
        Busy            => Camin_Bsy,
        Active          => Camin_Act,
        CommandAborted  => Camin_Ca,
        Error           => Camin_Err,
        ErrorID         => Camin_ErrID
    );
END_IF;

// MC_Power for axis 0
PWR1(
    Axis      := MC_Axis000,
    Enable    := Pwr1_En,
    Status    => Pwr1_S,
    Busy      => Pwr1_Bsy,
    Error     => Pwr1_Err,
    ErrorID   => Pwr1_ErrID
);

// MC_Power for axis 1
PWR2(
    Axis      := MC_Axis001,
    Enable    := Pwr2_En,
    Status    => Pwr2_S,
    Busy      => Pwr2_Bsy,
    Error     => Pwr2_Err,
    ErrorID   => Pwr2_ErrID
);

// MC_Home for axis 0
HM1(
    Axis           := MC_Axis000,
    Execute        := Hm1_Ex,
    Done           => Hm1_D,
    Busy           => Hm1_Bsy,
    CommandAborted := Hm1_Ca,

```

```

        Error          => Hm1_Err,
        ErrorID       => Hm1_ErrID
    );

// MC_Home for axis 1
HM2(
    Axis              := MC_Axis001,
    Execute           := Hm2_Ex,
    Done              => Hm2_D,
    Busy              => Hm2_Bsy,
    CommandAborted   => Hm2_Ca,
    Error             => Hm2_Err,
    ErrorID          => Hm2_ErrID
);


//MC_MoveAbsolute
MV_ABS(
    Axis              := MC_Axis000,
    Execute           := Mv_Abs_Ex,
    Position          := Mv_Abs_Pos,
    Velocity          := Mv_Abs_Vel,
    Acceleration      := Mv_Abs_Acc,
    Deceleration      := Mv_Abs_Dec,
    Direction         := Mv_Abs_Dir,
    Done              => Mv_Abs_D,
    Busy              => Mv_Abs_Bsy,
    Active            => Mv_Abs_Act,
    CommandAborted   => Mv_Abs_Ca,
    Error             => Mv_Abs_Err,
    ErrorID          => Mv_Abs_ErrID
);

```

10-2-13 Using a Cam Profile Curve to Correct the Sync Start Position

This sample uses a cam profile curve to correct a slave axis in a gear motion. The slave axis for gear motion is *MC_Axis001*, a virtual Servo axis, and the slave axis for cam motion is *MC_Axis002*, also a virtual Servo axis. These slave axes are combined with *MC_CombineAxes* and the results is output to *MC_Axis003*, a Servo axis. The master axis is *MC_Axis000*, a Servo axis.

The processing flow is as follows:



● Axis Type Settings

The axes types are set in the axis parameters for each axis as given below.

Parameter name	Setting			
	Axis 1	Axis 2	Axis 3	Axis 4
Axes variable name	MC_Axis000	MC_Axis001	MC_Axis002	MC_Axis003
Axis type	Servo axis	Virtual servo axis	Virtual servo axis	Servo axis

Main Variables Used in the Programming Samples

Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF	---	This is the Axis Variable for axis 0.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 0.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
MC_Axis001	_sAXIS_REF	---	This is the Axis Variable for axis 1.
MC_Axis001.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 1.
MC_Axis002	_sAXIS_REF	---	This is the Axis Variable for axis 2.
MC_Axis002.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 2.
MC_Axis003	_sAXIS_REF	---	This is the Axis Variable for axis 3.
MC_Axis003.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 3.
MC_Axis003.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 3.
CamProfile0	ARRAY[0..109] OF _sMC_CAM_REF	---	This is the cam data variable.*1
Pwr1_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
Pwr4_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR4 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
Vel_InVel	BOOL	FALSE	TRUE when the target velocity for <i>MC_MoveVelocity</i> for axis 0 is reached.


Variable name	Data type	Default	Comment
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.
Gearin_Ex	BOOL	FALSE	This variable is used to execute the MC_GearIn (Start Gear Operation) instruction.*2
Camin_Ex	BOOL	FALSE	This variable is used to execute the MC_CamIn (Start Cam Operation) instruction.*2
Combine_Ex	BOOL	FALSE	This variable is used to execute the MC_CombineAxes (Combine Axes) instruction.*2

*1 The array elements ARRAY[0..N] are set with the Cam Editor in the Sysmac Studio. The range of the array is 0 to 109 in this sample.


*2 The variable is used in ST programming.

Timing Chart

● Ladder Diagram




● ST Programming




Ladder Diagram


When *StartPg* is TRUE, the status of process data communications of axis 0 is checked to see if communications are active and normal.




When *StartPg* is TRUE, the status of process data communications of axis 3 is checked to see if communications are active and normal.




The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal.




The Servo for axis 3 is turned ON if process data communications for axis 3 are active and normal.




If a minor fault level error occurs for any of the composition axes in the axes group, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.




If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.




If the Servo is ON for axis 3 and home is not defined, the MC_Home instruction is executed.




If homing is completed for axis 0, velocity control is executed.




If homing is completed for axis 0, gear operation is executed.



When axis 0 reaches the target velocity, cam operation is executed.



If both gear and cam operation are in progress, the Combine Axes instruction is executed.



ST Programming

// If the input parameters for the motion instructions are not set, the target values and other parameters are set.
 IF InitFlag=FALSE THEN

// The input parameters for the MC_MoveVelocity (Velocity Control) instruction are set.

```
Vel_Vel      := LREAL#100.0;
Vel_Acc      := LREAL#0.0;
Vel_Dec      := LREAL#0.0;
Vel_Dir      := _eMC_DIRECTION#_mcPositiveDirection;
```

// The input parameters for the MC_CamIn (Start Cam Operation) instruction are set.

```
Camin_Em     := TRUE;
Camin_Sm     := _eMC_START_MODE#_mcRelativePosition;
Camin_Sp     := LREAL#20.0;
Camin_Msd    := LREAL#40.0;
Camin_Ms     := LREAL#1.0;
Camin_Ss     := LREAL#1.0;
Camin_Mo     := LREAL#0.0;
Camin_So     := LREAL#0.0;
Camin_Rt     := _eMC_REFERENCE_TYPE#_mcCommand;
Camin_Dir    := _eMC_DIRECTION#_mcNoDirection;
```

// The input parameters for the MC_GearIn (Start Gear Operation) instruction are set.

```
Gearin_RatN  := UINT#10#1;
Gearin_RatD  := UINT#10#1;
Gearin_RefTyp := _eMC_REFERENCE_TYPE#_mcCommand;
Gearin_Acc   := LREAL#0.0;
Gearin_Dec   := LREAL#0.0;
```

// The input parameters for the MC_CombineAxes (Combine Axes) instruction are set.

```
Combine_Cm := _eMC_COMBINE_MODE#_mcAddAxes;
Combine_RefMas:= _eMC_REFERENCE_TYPE#_mcLatestCommand;
Combine_RefAux:= _eMC_REFERENCE_TYPE#_mcLatestCommand;
// The Input Parameter Initialization Completed Flag is changed to TRUE.
InitFlag := TRUE;
```

END_IF;

// When StartPg is TRUE, the Servo is turned ON for axis 0 if process data communications are active and normal.

```
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
    Pwr1_En:=TRUE;
ELSE
    Pwr1_En:=FALSE;
END_IF;
```

```

// When StartPg is TRUE, the Servo is turned ON for axis 3 if process data communications are active and normal.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis003.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis003.Cfg.NodeAddress]=FALSE) THEN
    Pwr4_En:=TRUE;
ELSE
    Pwr4_En:=FALSE;
END_IF;

// If a minor fault level error occurs for axis 0 to axis 3, the error handler for the device (FaultHandler) is executed.
// Program the FaultHandler according to the device.
IF (MC_Axis000.MFaultLvl.Active=TRUE)
OR (MC_Axis001.MFaultLvl.Active=TRUE)
OR (MC_Axis002.MFaultLvl.Active=TRUE)
OR (MC_Axis003.MFaultLvl.Active=TRUE) THEN
    FaultHandler();
END_IF;

// If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed for axis 0.
IF (Pwr1_Status=TRUE)
AND (MC_Axis000.Details.Homed=FALSE) THEN
    Hm1_Ex:=TRUE;
END_IF;

// If the Servo is ON for axis 3 and home is not defined, the MC_Home instruction is executed for axis 3.
IF (Pwr4_Status=TRUE)
AND (MC_Axis003.Details.Homed=FALSE) THEN
    Hm4_Ex:=TRUE;
END_IF;

// If homing is completed for axis 0, velocity control is executed.
IF Hm1_D=TRUE THEN
    Vel_Ex:=TRUE;
END_IF;

// When axis 0 reaches the target velocity, gear operation is executed.
IF Vel_InVel=TRUE THEN
    Gearin_Ex := TRUE;
END_IF;

// When axis 0 reaches the target velocity, cam operation is executed.
IF Vel_InVel=TRUE THEN
    Camin_Ex := TRUE;
END_IF;

// If both gear and cam operation are in progress, the Combine Axes instruction is executed.
IF (Gearin_Act=TRUE)
AND (Camin_Act=TRUE) THEN
    Combine_Ex:=TRUE;
END_IF;

// MC_Power for axis 0
PWR1(
    Axis    := MC_Axis000,
    Enable  := Pwr1_En,
    Status  => Pwr1_Status,
    Busy    => Pwr1_Bsy,
    Error   => Pwr1_Err,
    ErrorID => Pwr1_ErrID
);

```

```

// MC_Power for axis 3
PWR4(
    Axis      := MC_Axis003,
    Enable    := Pwr4_En,
    Status    => Pwr4_Status,
    Busy      => Pwr4_Bsy,
    Error     => Pwr4_Err,
    ErrorID   => Pwr4_ErrID
);

// MC_Home for axis 0
HM1(
    Axis           := MC_Axis000,
    Execute        := Hm1_Ex,
    Done           => Hm1_D,
    Busy           => Hm1_Bsy,
    CommandAborted => Hm1_Ca,
    Error          => Hm1_Err,
    ErrorID        => Hm1_ErrID
);

// MC_Home for axis 3
HM4(
    Axis           := MC_Axis003,
    Execute        := Hm4_Ex,
    Done           => Hm4_D,
    Busy           => Hm4_Bsy,
    CommandAborted => Hm4_Ca,
    Error          => Hm4_Err,
    ErrorID        => Hm4_ErrID
);

//MC_MoveVelocity
VEL(
    Axis           := MC_Axis000,
    Execute        := Vel_Ex,
    Velocity       := Vel_Vel,
    Acceleration   := Vel_Acc,
    Deceleration   := Vel_Dec,
    Direction      := Vel_Dir,
    InVelocity     => Vel_Invel,
    Busy           => Vel_Bsy,
    Active         => Vel_Act,
    CommandAborted => Vel_Ca,
    Error          => Vel_Err,
    ErrorID        => Vel_ErrID
);

//MC_CamIn
CAMIN(
    Master         := MC_Axis000,
    Slave          := MC_Axis002,
    CamTable       := CamProfile0,
    Execute        := Camin_Ex,
    Periodic       := Camin_Em,
    StartMode      := Camin_Sm,
    StartPosition  := Camin_Sp,
    MasterStartDistance := Camin_Msd,
    MasterScaling  := Camin_Ms,
    SlaveScaling   := Camin_Ss,
    MasterOffset   := Camin_Mo,
    SlaveOffset    := Camin_So,
    ReferenceType  := Camin_Rt,
    Direction      := Camin_Dir,
    InCam          => Camin_InCam,

```



```

    InSync                => Camin_InSync,
    EndOfProfile          => Camin_Eop,
    Index                 => Camin_Index,
    Busy                  => Camin_Bsy,
    Active                => Camin_Act,
    CommandAborted       => Camin_Ca,
    Error                 => Camin_Err,
    ErrorID               => Camin_ErrID
);

//MC_GearIn
GEARIN(
    Master                := MC_Axis000,
    Slave                 := MC_Axis001,
    Execute               := Gearin_Ex,
    RatioNumerator        := Gearin_RatN,
    RatioDenominator      := Gearin_RatD,
    ReferenceType         := Gearin_RefTyp,
    Acceleration          := Gearin_Acc,
    Deceleration          := Gearin_Dec,
    InGear                => Gearin_InGear,
    Busy                  => Gearin_Bsy,
    Active                => Gearin_Act,
    CommandAborted       => Gearin_Ca,
    Error                 => Gearin_Err,
    ErrorID               => Gearin_ErrID
);

//MC_CombineAxes
COMBINE(
    Master                := MC_Axis001,
    Auxiliary             := MC_Axis002,
    Slave                 := MC_Axis003,
    Execute               := Combine_Ex,
    CombineMode           := Combine_CM,
    ReferenceTypeMaster   := Combine_RefMas,
    ReferenceTypeAuxiliary := Combine_RefAux,
    InCombination        => Combine_InComb,
    Busy                  => Combine_Bsy,
    Active                => Combine_Act,
    CommandAborted       => Combine_Ca,
    Error                 => Combine_Err,
    ErrorID               => Combine_ErrID
);

```

10-2-14 Shifting the Phase of a Master Axis in Cam Motion

This sample synchronizes a slave axis in cam motion with a master axis in velocity control. If *StartOn* is TRUE, the phase of the master axis is shifted with the MC_Phasing (Shift Master Axis Phase) instruction. The slave axis is synchronized with the shifted phase.


Main Variables Used in the Programming Samples

Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF	---	This is the Axis Variable for axis 0.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 0.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
MC_Axis001	_sAXIS_REF	---	This is the Axis Variable for axis 1.
MC_Axis001.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
MC_Axis001.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 1.
CamProfile0	ARRAY[0..360] OF _sMC_CAM_REF	---	This is the cam data variable.
Pwr1_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
Pwr2_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR2 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
StartOn	BOOL	FALSE	This variable is used to start shifting the phase of the master axis.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.
Camin_Ex	BOOL	FALSE	This variable is used to execute the MC_CamIn (Start Cam) instruction. It is used in ST programming.
Vel_Ex	BOOL	FALSE	This variable is used to execute the MC_MoveVelocity (Velocity Control) instruction. It is used in ST programming.
Phasing_Ex	BOOL	FALSE	This variable is used to execute the MC_Phasing (Shift Master Axis Phase) instruction. It is used in ST programming.


* The array elements ARRAY[0..N] are set with the Cam Editor in the Sysmac Studio. The range of the array is 0 to 360 in this sample.

Timing Chart

● Ladder Diagram




● **ST Programming**




Ladder Diagram


When *StartPg* is TRUE, the status of process data communications of axis 0 is checked to see if communications are active and normal.




When *StartPg* is TRUE, the status of process data communications of axis 1 is checked to see if communications are active and normal.




The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal.




The Servo for axis 1 is turned ON if process data communications for axis 1 are active and normal.




If a minor fault level error occurs for any of the composition axes in the axes group, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.




If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.




If the Servo is ON for axis 1 and home is not defined, the MC_Home instruction is executed.




If homing is completed for axis 0, velocity control is executed.



When axis 0 reaches the target velocity, cam operation is executed.



If StartOn is TRUE and cam motion is in sync, shifting the phase of the master axis is started.



ST Programming

```

// If the input parameters for the motion instructions are not set, the target values and other parameters are set.
IF InitFlag=FALSE THEN
    // The input parameters for the MC_MoveVelocity (Velocity Control) instruction are set.
    Vel_Vel      := LREAL#1000.0;
    Vel_Acc      := LREAL#100000.0;
    Vel_Dec      := LREAL#100000.0;
    Vel_Dir      := _eMC_DIRECTION#_mcPositiveDirection;

    // The input parameters for the MC_Phasing (Shift Master Axis Phase) instruction are set.
    Phasing_Ps   := LREAL#500.0;
    Phasing_Vel  := LREAL#1000.0;
    Phasing_Acc  := LREAL#0.0;
    Phasing_Dec  := LREAL#0.0;

    // The input parameters for the MC_CamIn (Start Cam Operation) instruction are set.
    Camin_Em     := TRUE;
    Camin_Sm     := _eMC_START_MODE#_mcRelativePosition;
    Camin_Sp     := LREAL#20.0;
    Camin_Msd    := LREAL#40.0;
    Camin_Ms     := LREAL#1.0;
    Camin_Ss     := LREAL#1.0;
    Camin_Mo     := LREAL#0.0;
    Camin_So     := LREAL#0.0;
    Camin_Rt     := _eMC_REFERENCE_TYPE#_mcCommand;
    Camin_Dir    := _eMC_DIRECTION#_mcNoDirection;

    // The Input Parameter Initialization Completed Flag is changed to TRUE.
    InitFlag := TRUE;
END_IF;

// When StartPg is TRUE, the Servo is turned ON for axis 0 if process data communications are active and normal.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
    Pwr1_En:=TRUE;
ELSE
    Pwr1_En:=FALSE;
END_IF;

// When StartPg is TRUE, the Servo is turned ON for axis 1 if process data communications are active and normal.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis001.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis001.Cfg.NodeAddress]=FALSE) THEN
    Pwr2_En:=TRUE;
ELSE
    Pwr2_En:=FALSE;
END_IF;

// If a minor fault level error occurs for axis 0 or axis 1, the error handler for the device (FaultHandler) is executed.
// Program the FaultHandler according to the device.
IF (MC_Axis000.MFaultLvl.Active=TRUE)
OR (MC_Axis001.MFaultLvl.Active=TRUE) THEN
    FaultHandler();
END_IF;

// If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed for axis 0.
IF (Pwr1_Status=TRUE)
AND (MC_Axis000.Details.Homed=FALSE) THEN
    Hm1_Ex:=TRUE;
END_IF;
// If the Servo is ON for axis 1 and home is not defined, the MC_Home instruction is executed for axis 1.
IF (Pwr2_Status=TRUE)

```

```

AND (MC_Axis001.Details.Homed=FALSE) THEN
  Hm2_Ex:=TRUE;
END_IF;

// If homing is completed for axis 0, velocity control is executed.
IF Hm1_D=TRUE THEN
  Vel_Ex:=TRUE;
END_IF;

// When axis 0 reaches the target velocity and the home is defined for axis 1, cam operation is executed.
IF (Vel_InVel=TRUE)
AND (MC_Axis001.Details.Homed=TRUE) THEN
  Camin_Ex := TRUE;
END_IF;

// If StartOn is TRUE and cam motion is in sync, shifting the phase of the master axis is started.
IF (StartOn=TRUE)
AND (Camin_InSync=TRUE) THEN
  Phasing_Ex:=TRUE;
END_IF;

// MC_Power for axis 0
PWR1(
  Axis    := MC_Axis000,
  Enable  := Pwr1_En,
  Status  => Pwr1_Status,
  Busy    => Pwr1_Bsy,
  Error   => Pwr1_Err,
  ErrorID => Pwr1_ErrID
);

// MC_Power for axis 1
PWR2(
  Axis    := MC_Axis001,
  Enable  := Pwr2_En,
  Status  => Pwr2_Status,
  Busy    => Pwr2_Bsy,
  Error   => Pwr2_Err,
  ErrorID => Pwr2_ErrID
);

// MC_Home for axis 0
HM1(
  Axis           := MC_Axis000,
  Execute        := Hm1_Ex,
  Done           => Hm1_D,
  Busy           => Hm1_Bsy,
  CommandAborted => Hm1_Ca,
  Error          => Hm1_Err,
  ErrorID        => Hm1_ErrID
);

// MC_Home for axis 1
HM2(
  Axis           := MC_Axis001,
  Execute        := Hm2_Ex,
  Done           => Hm2_D,
  Busy           => Hm2_Bsy,
  CommandAborted => Hm2_Ca,
  Error          => Hm2_Err,
  ErrorID        => Hm2_ErrID
);

//MC_MoveVelocity

```



```

VEL(
    Axis                := MC_Axis000,
    Execute              := Vel_Ex,
    Velocity             := Vel_Vel,
    Acceleration         := Vel_Acc,
    Deceleration         := Vel_Dec,
    Direction            := Vel_Dir,
    InVelocity           => Vel_Invel,
    Busy                 => Vel_Bsy,
    Active               => Vel_Act,
    CommandAborted      => Vel_Ca,
    Error                => Vel_Err,
    ErrorID              => Vel_ErrID
);

//MC_Phasing
PHASING(
    Master                := MC_Axis000,
    Slave                := MC_Axis001,
    Execute              := Phasing_Ex,
    PhaseShift           := Phasing_Ps,
    Velocity             := Phasing_Vel,
    Acceleration         := Phasing_Acc,
    Deceleration         := Phasing_Dec,
    Done                 => Phasing_D,
    Busy                 => Phasing_Bsy,
    Active               => Phasing_Act,
    CommandAborted      => Phasing_Ca,
    Error                => Phasing_Err,
    ErrorID              => Phasing_ErrID
);

//MC_CamIn
CAMIN(
    Master                := MC_Axis000,
    Slave                := MC_Axis001,
    CamTable             := CamProfile0,
    Execute              := Camin_Ex,
    Periodic             := Camin_Em,
    StartMode            := Camin_Sm,
    StartPosition        := Camin_Sp,
    MasterStartDistance  := Camin_Msd,
    MasterScaling        := Camin_Ms,
    SlaveScaling         := Camin_Ss,
    MasterOffset         := Camin_Mo,
    SlaveOffset          := Camin_So,
    ReferenceType        := Camin_Rt,
    Direction            := Camin_Dir,
    InCam                => Camin_Incam,
    InSync               => Camin_Insync,
    EndOfProfile         => Camin_Eop,
    Index                => Camin_Index,
    Busy                 => Camin_Bsy,
    Active               => Camin_Act,
    CommandAborted      => Camin_Ca,
    Error                => Camin_Err,
    ErrorID              => Camin_ErrID
);

```

10-2-15 Changing the Actual Position during Velocity Control

This sample changes the absolute values of the command current position and the actual current position for an axis in velocity control.



Precautions for Correct Use

- When you use the MC_SetPosition instruction for an axis in motion, the travel distance between execution of the instruction and changing the actual position will remain as error.
- Home will become undefined when the MC_Set Position instruction is executed.

Axis Parameter Settings


Parameter name	Setting	Description
Count Mode	Rotary Mode	Rotary Mode is set as the count mode for the position.
Modulo Maximum Position Setting Value	360	The Modulo Maximum Position is set to 360.
Modulo Minimum Position Setting Value	0	The Modulo Minimum Position is set to 0.
Homing Method	Zero position preset	A zero position preset is performed to define home.

Main Variables Used in the Programming Samples


Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF	---	This is the Axis Variable for axis 0.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. It is TRUE when the Servo is ON.
StartSetPos	BOOL	FALSE	This variable gives the status of the external button that is used to change the actual position.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.
Vel_Ex	BOOL	FALSE	This variable is used to execute the MC_MoveVelocity (Velocity Control) instruction. It is used in ST programming.
SetPos_Ex	BOOL	FALSE	This variable is used to execute the MC_SetPosition instruction. It is used in ST programming.

Timing Chart

● Ladder Diagram




● **ST Programming**




Ladder Diagram


When *StartPg* is TRUE, the status of process data communications of axis 0 is checked to see if communications are active and normal.




The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal.




If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.



If the Servo is ON for axis 0, velocity control is executed.



If *StartSetPos* is TRUE while the Servo is ON, the Set Position instruction is executed.



ST Programming

```

// If the input parameters for the instructions are not set, the target values and other parameters are set.
IF InitFlag=FALSE THEN
  // The input parameters for the MC_MoveVelocity (Velocity Control) instruction are set.
  Vel_Vel      := LREAL#36.0;
  Vel_Acc      := LREAL#1000.0;
  Vel_Dec      := LREAL#1000.0;
  Vel_Jrk      := LREAL#100.0;

  // The input parameters for the MC_SetPosition instruction are set.
  Set_Pos_Pos  := LREAL#0.0;

  // The Input Parameter Initialization Completed Flag is changed to TRUE.
  InitFlag:=TRUE;
END_IF;

// When StartPg is TRUE, the Servo is turned ON for axis 0 if process data communications for axis 0 are active
and normal.
// If process data communications are not active, the Servo is turned OFF.
IF (StartPg=TRUE)
  AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
  AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
  Pwr_En:=TRUE;
ELSE
  Pwr_En:=FALSE;
END_IF;

// If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed.
// Program the FaultHandler according to the device.
IF MC_Axis000.MFaultLvl.Active=TRUE THEN
  FaultHandler();
END_IF;

// If the Servo is ON for axis 0, velocity control is executed for axis 0.
IF Pwr_Status=TRUE THEN
  Vel_Ex:=TRUE;
END_IF;

// If StartSetPos is TRUE while the Servo is ON, the Set Position instruction is executed.
IF (Pwr_Status=TRUE)
  AND (StartSetPos=TRUE) THEN
  Set_Pos_Ex:=TRUE;
END_IF;

//MC_Power
PWR(
  Axis      := MC_Axis000,
  Enable    := Pwr_En,
  Status    => Pwr_Status,
  Busy      => Pwr_Bsy,
  Error     => Pwr_Err,
  ErrorID   => Pwr_ErrID
);

//MC_MC_MoveVelocity
VEL(
  Axis      := MC_Axis000,
  Execute   := Vel_Ex,

```

```

Velocity           := Vel_Vel,
Acceleration       := Vel_Acc,
Deceleration       := Vel_Dec,
Jerk               := Vel_Jrk,
InVelocity         => Vel_InVel,
Busy               => Vel_Bsy,
Active             => Vel_Act,
CommandAborted    => Vel_Ca,
Error              => Vel_Err,
ErrorID           => Vel_ErrID
);

//MC_SetPosition
SET_POS(
  Axis             := MC_Axis000,
  Execute          := Set_Pos_Ex,
  Position         := Set_Pos_Pos,
  Done             => Set_Pos_D,
  Busy             => Set_Pos_Bsy,
  CommandAborted  => Set_Pos_Ca,
  Error            => Set_Pos_Err,
  ErrorID         => Set_Pos_ErrID
);

```

10-2-16 Changing a Cam Data Variable and Saving the Cam Table

This sample uses the user program to change a cam data variable that was created on Cam Editor of the Sysmac Studio. The displacements for phases of 0° to 180° are multiplied by 2 and the displacements for phases of 181° to 360° are multiplied by 0.5.

If the changes to the cam data are completed, the motion control instruction MC_SaveCamTable is used to save the cam data variable to non-volatile memory in the CPU Unit. When saving the data is completed, the MC_CamIn (Start Cam Operation) instruction is executed to start cam motion.



Precautions for Correct Use

- If the phases are not in ascending order, an error occurs when the MC_CamIn (Start Cam Operation) instruction is executed. The order of the phases are not checked in this sample. To check the order of the phases, execute the MC_SetCamTableProperty (Set Cam Table Properties) instruction.
- There is a limit to the number of times that you can write non-volatile memory in the CPU Unit. Save cam table data only when necessary.
- If the power supply to the Controller is turned OFF before the data is saved with the MC_SaveCamTable instruction, the cam data variable will revert to the contents from before it was changed by the user program.


Main Variables Used in the Programming Samples

Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF	---	This is the Axis Variable for axis 0.
MC_Axis001	_sAXIS_REF	---	This is the Axis Variable for axis 1.
CamProfile0	ARRAY[0..360] OF _sMC_CAM_REF	---	This is the cam data variable.*
Pwr1_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
Pwr2_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR2 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.
WriteCamdata	BOOL	FALSE	This variable is used to start changing the cam data. It is changed to TRUE to start editing.
WriteDone	BOOL	FALSE	This variable is used to indicate that the changes to the cam data are completed. It is changed to TRUE when the changes to the cam data are completed.
SaveCamtable	BOOL	FALSE	This variable is used to execution the Save Cam Table instruction.
_MC_COM.Status. CamTableBusy	BOOL	FALSE	This system-defined variable is TRUE while cam table data is being saved.
Sv_Cam_Ex	BOOL	FALSE	This variable is used to execute the MC_SaveCamTable instruction.
CamIn_Ex	BOOL	FALSE	This variable is used to execute the MC_CamIn (Start Cam) instruction. It is used in ST programming.


* The array elements ARRAY[0..N] are set with the Cam Editor in the Sysmac Studio. The range of the array is 0 to 360 in this sample.

Timing Chart

● Ladder Diagram




● ST Programming




Ladder Diagram


When *StartPg* is TRUE, the status of process data communications of axis 0 is checked to see if communications are active and normal.




When *StartPg* is TRUE, the status of process data communications of axis 1 is checked to see if communications are active and normal.




The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal.




The Servo for axis 1 is turned ON if process data communications for axis 1 are active and normal.




If a minor fault level error occurs in the MC Common Error Status Variable or for any of the axes, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.




If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.




If the Servo is ON for axis 1 and home is not defined, the MC_Home instruction is executed.




If *WriteCamData* is TRUE and a cam table file is not being saved, the values in the cam data variable are changed. The displacements for phases from 0° to 180° are multiplied by 2 and the displacements for phases from 181° to 360° are multiplied by 0.5. When the changes to the displacements are completed, *WriteDone* is changed to TRUE.




If the changes to the cam data variable are completed, *SaveCamtable* is TRUE, and a cam table file save operation is not in progress, *Sv_Cam_Ex* is changed to TRUE.




If *Sv_Ca_TimeUp* is TRUE, *Sv_Cam_Ex* is changed to FALSE. If *Sv_Cam_Ex* changes to FALSE, *Sv_Ca_TimeUp* changes to FALSE and *Sv_Cam_Ex* changes to TRUE. The MC_SaveCamTable instruction is executed again.




If *Sv_Cam_Ex* changes to TRUE, the MC_SaveCamTable instruction is executed.




If *Sv_Ca_CountUp* is FALSE, a Cannot Execute Save Cam Table error occurs and *Sv_Cam_Disable* is changed to TRUE.




One second after a Cannot Execute Save Cam Table error occurs, *Sv_Ca_TimeUp* is changed to TRUE. When *Sv_Ca_TimeUp* changes to TRUE, *Sv_Cam_Ex* changes to FALSE.




Sv_Ca_CountLoad changes to TRUE for one period when the cam table is saved. If *Sv_Ca_CountLoad* is TRUE, the retry counter is reset.




If a Cannot Execute Save Cam Table error occurs three times, *Sv_Ca_CountUp* is changed to TRUE. When *Sv_Ca_CountUp* changes to TRUE, *Sv_Cam_Disable* is changed to FALSE. Retry processing for the MC_SaveCamTable instruction is completed.



If homing is completed for axis 0, velocity control is executed.



If the changes to the cam data variable and saving the cam table are completed and axis 0 is at the target velocity, the cam operation is executed.



ST Programming

```

// If the input parameters for the instructions are not set, the target values and other parameters are set.
IF InitFlag=FALSE THEN
    // The input parameters for the MC_MoveVelocity (Velocity Control) instruction are set.
    Vel_Vel      := LREAL#1000.0;
    Vel_Acc      := LREAL#0.0;
    Vel_Dec      := LREAL#0.0;
    Vel_Dir      := _eMC_DIRECTION#_mcPositiveDirection;

    // The input parameters for the MC_CamIn (Start Cam Operation) instruction are set.
    Camin_Em     := TRUE;
    Camin_Sm     := _eMC_START_MODE#_mcRelativePosition;
    Camin_Sp     := LREAL#0.0;
    Camin_Msd    := LREAL#0.0;
    Camin_Ms     := LREAL#1.0;
    Camin_Ss     := LREAL#1.0;
    Camin_Mo     := LREAL#0.0;
    Camin_So     := LREAL#0.0;
    Camin_Rt     := _eMC_REFERENCE_TYPE#_mcCommand;
    Camin_Dir    := _eMC_DIRECTION#_mcNoDirection;

    // The Input Parameter Initialization Completed Flag is changed to TRUE.
    InitFlag:=TRUE;
END_IF;

// When StartPg is TRUE, the Servo is turned ON for axis 0 if process data communications for axis 0 are active
and normal.
// If process data communications are not active, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN
    Pwr1_En:=TRUE;
ELSE
    Pwr1_En:=FALSE;
END_IF;

// When StartPg is TRUE, the Servo is turned ON for axis 1 if process data communications for axis 1 are active
and normal.
// If process data communications are not active, the Servo is turned OFF.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis001.Cfg.NodeAddress]=TRUE)
AND (_EC_CommErrTbl[MC_Axis001.Cfg.NodeAddress]=FALSE) THEN
    Pwr2_En:=TRUE;
ELSE
    Pwr2_En:=FALSE;
END_IF;

// If a minor fault level error occurs in the MC Common Error Status Variable or for any of the axes, the error handler
for the device (FaultHandler) is executed.
// Program the FaultHandler according to the device.
IF (MC_Axis000.MFaultLvl.Active=TRUE)
OR (MC_Axis001.MFaultLvl.Active=TRUE)
OR (_MC_COM.MFaultLvl.Active=TRUE) THEN
    FaultHandler();
END_IF;

// If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed for axis 0.
IF (Pwr1_Status=TRUE)
AND (MC_Axis000.Details.Homed=FALSE) THEN

```

```

        Hm1_Ex:=TRUE;
    END_IF;

    // If the Servo is ON for axis 1 and home is not defined, the MC_Home instruction is executed for axis 1.
    IF (Pwr2_Status=TRUE)
    AND (MC_Axis001.Details.Homed=FALSE) THEN
        Hm2_Ex:=TRUE;
    END_IF;

    // If WriteCamData is TRUE and a cam table file is not being saved, the values in the cam data variable are
    // changed.
    // The displacements for phases of 0° to 180° are multiplied by 2 and the displacements for phases of 181° to 360°
    // are multiplied by 0.5.
    // When the changes are completed, WriteDone is changed to TRUE.
    IF (WriteCamdata=TRUE)
    AND (_MC_COM.Status.CamTableBusy=FALSE) THEN
        FOR Index := UINT#10#0 TO UINT#10#360 DO
            IF Index<UINT#10#180 THEN
                CamProfile0[Index].Distance:=CamProfile0[Index].Distance*REAL#2.0;
            ELSE
                CamProfile0[Index].Distance:=CamProfile0[Index].Distance*REAL#0.5;
            END_IF;
        END_FOR;
        WriteDone:=TRUE;
        WriteCamdata:=FALSE;
    END_IF;

    // If homing is completed for axis 0, velocity control is executed.
    IF Hm1_D=TRUE THEN
        Vel_Ex:=TRUE;
    END_IF;

    // If the changes to the cam data variable are completed, SaveCamtable is TRUE, and a cam table file save opera-
    // tion is not in progress,
    // Sv_Cam_Ex is changed to TRUE.
    // If Sv_Cam_Ex is TRUE, the MC_SaveCamTable instruction is executed.
    IF (WriteDone=TRUE)
    AND (SaveCamtable=TRUE)
    AND (_MC_COM.Status.CamTableBusy=FALSE) THEN
        Sv_Cam_Ex := TRUE;
    END_IF;

    // If Sv_Ca_TimeUp is TRUE, Sv_Cam_Ex is changed to FALSE.
    // If Sv_Cam_Ex is FALSE, Sv_Ca_TimeUp changes to FALSE and Sv_Cam_Ex changes to TRUE.
    // The MC_SaveCamTable instruction is executed again.
    IF (Sv_Cam_Ex=TRUE)
    AND (Sv_Ca_TimeUp=FALSE) THEN
        Sv_Cam_Ex := TRUE;
    ELSE
        Sv_Cam_Ex := FALSE;
    END_IF;

    // If Sv_Ca_CountUp is FALSE and a Cannot Execute Save Cam Table error occurs,
    // Sv_Cam_Disable is changed to TRUE.
    IF (Sv_Ca_CountUP=FALSE)
    AND (Sv_Cam_Ca=TRUE) THEN
        Sv_Cam_Disable := TRUE;
    ELSE
        Sv_Cam_Disable := FALSE;
    END_IF;

```

```

// One second after the Cannot Execute Save Cam Table error occurs, Sv_Ca_TimeUp is changed to TRUE.
// If Sv_Ca_TimeUp changes to TRUE, Sv_Cam_Ex is changed to FALSE.
Sv_Ca_TON(
    In      := Sv_Cam_Disable ,
    PT     := T#1s ,
    Q      => Sv_Ca_TimeUp
);

// Sv_Ca_CountLoad is changed to TRUE for one period when the cam table is saved.
// If Sv_Ca_CountLoad changes to TRUE, the retry counter is reset.
R_TRIG1(SaveCamtable, Sv_Ca_CountLoad);

// If a Cannot Execute Save Cam Table error occurs three times, Sv_Ca_CountUP is changed to TRUE.
// If Sv_Ca_CountUP changes to TRUE, Sv_Cam_Disable is changed to FALSE.
// Retry processing for the MC_SaveCamTable instruction is completed.
Sv_Ca_CTD(
    CD     := Sv_Cam_Disable ,
    LOAD  := Sv_Ca_CountLoad ,
    PV    := INT#3 ,
    Q     => Sv_Ca_CountUP
);

// If the changes to the cam data variable and saving the cam table are completed and axis 0 is at the target
// velocity, the cam operation is executed.
IF (Vel_InVel=TRUE)
AND (WriteDone=TRUE)
AND (Sv_Cam_D=TRUE) THEN
    Camin_Ex:=TRUE;
END_IF;

//MC_SaveCamTable
SV_CAM(
    CamTable      :=CamProfile0,
    Execute       := Sv_Cam_Ex,
    Done          => Sv_Cam_D,
    Busy          => Sv_Cam_Bsy,
    CommandAborted => Sv_Cam_Ca,
    Error         => Sv_Cam_Err,
    ErrorID      => Sv_Cam_ErrID
);

CAMIN(
    Master        := MC_Axis000,
    Slave        := MC_Axis001,
    CamTable     := CamProfile0,
    Execute      := Camin_Ex,
    Periodic     := Camin_Em,
    StartMode    := Camin_Sm,
    StartPosition := Camin_Sp,
    MasterStartDistance := Camin_Msd,
    MasterScaling := Camin_Ms,
    SlaveScaling := Camin_Ss,
    MasterOffset  := Camin_Mo,
    SlaveOffset  := Camin_So,
    ReferenceType := Camin_Rt,
    Direction    := Camin_Dir,
    InCam        => Camin_InCam,
    InSync       => Camin_InSync,
    EndOfProfile => Camin_Eop,
    Index        => Camin_Index,
    Busy         => Camin_Bsy,
    Active       => Camin_Act,
    CommandAborted => Camin_Ca,

```

```

        Error           => Camin_Err,
        ErrorID        => Camin_ErrID
    );

// MC_Power for axis 0
PWR1(
    Axis       := MC_Axis000,
    Enable     := Pwr1_En,
    Status     => Pwr1_Status,
    Busy       => Pwr1_Bsy,
    Error      => Pwr1_Err,
    ErrorID    => Pwr1_ErrID
);

// MC_Power for axis 1
PWR2(
    Axis       := MC_Axis001,
    Enable     := Pwr2_En,
    Status     => Pwr2_Status,
    Busy       => Pwr2_Bsy,
    Error      => Pwr2_Err,
    ErrorID    => Pwr2_ErrID
);

// MC_Home for axis 0
HM1(
    Axis           := MC_Axis000,
    Execute        := Hm1_Ex,
    Done           => Hm1_D,
    Busy           => Hm1_Bsy,
    CommandAborted => Hm1_Ca,
    Error          => Hm1_Err,
    ErrorID        => Hm1_ErrID
);

// MC_Home for axis 1
HM2(
    Axis           := MC_Axis001,
    Execute        := Hm2_Ex,
    Done           => Hm2_D,
    Busy           => Hm2_Bsy,
    CommandAborted => Hm2_Ca,
    Error          => Hm2_Err,
    ErrorID        => Hm2_ErrID
);

//MC_MoveVelocity
VEL(
    Axis           := MC_Axis000,
    Execute        := Vel_Ex,
    Velocity       := Vel_Vel,
    Acceleration   := Vel_Acc,
    Deceleration   := Vel_Dec,
    Direction      := Vel_Dir,
    InVelocity     => Vel_InVel,
    Busy           => Vel_Bsy,
    Active         => Vel_Act,
    CommandAborted => Vel_Ca,
    Error          => Vel_Err,
    ErrorID        => Vel_ErrID
);

```


10-2-17 Temporarily Changing Axis Parameters


This sample uses the MC_Write (Write MC Setting) instruction to change the settings of the In-Position Check Time, Positive Software Limit, and Negative Software Limit.

Main Variables Used in the Programming Samples


Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF	---	This is the Axis Variable for axis 0.
InitFlag	BOOL	FALSE	This variable indicates the status of parameter settings. FALSE while parameters are changed. TRUE after the changes to the parameters are completed.
StartPg	BOOL	FALSE	This variable is used to execute the MC_Write instruction.

Ladder Diagram


The axis parameters are set. When setting the parameters is completed, *InitFlag* is changed to TRUE.




If *StartPg* is TRUE, the setting of the In-position Check Time is changed.



If changing the setting of the In-Position Check Time is completed, the setting of the Positive Software Limit is changed.



If changing the setting of the Positive Software Limit is completed, the setting of the Negative Software Limit is changed.



ST Programming

// The axis parameters are set. When setting the parameters is completed, *InitFlag* is changed to TRUE.

```
IF InitFlag=FALSE THEN
  // In-position Check Time
  Write1_Sv := UINT#10#10;
  Write1_Pn := _eMC_PARAMETER_NUMBER#_mcInPosTime;
  // Positive Software Limit
  Write2_Sv := LREAL#10000.0;
  Write2_Pn := _eMC_PARAMETER_NUMBER#_mcPosiSwLmt;
  // Negative Software Limit
  Write3_Sv := LREAL#-10000.0;
  Write3_Pn := _eMC_PARAMETER_NUMBER#_mcNegaSwLmt;
```

// The Input Parameter Initialization Completed Flag is changed to TRUE.

```
InitFlag := TRUE;
END_IF;
```

// If *StartPg* is TRUE, the setting of the In-position Check Time is changed.

```
IF StartPg =TRUE THEN
  Write1_Ex := TRUE;
END_IF;
```

// If changing the setting of the In-Position Check Time is completed, the setting of the Positive Software Limit is changed.

```
IF Write1_D = TRUE THEN
  Write2_Ex := TRUE;
END_IF;
```

// If changing the setting of the Positive Software Limit is completed, the setting of the Negative Software Limit is changed.

```
IF Write2_D = TRUE THEN
  Write3_Ex := TRUE;
END_IF;
```

// MC_Write

```
WRITE1(
  Target           := MC_Axis000,
  SettingValue     := Write1_Sv,
  Execute         := Write1_Ex,
  ParameterNumber := Write1_Pn,
  Done            => Write1_D,
  Busy            => Write1_Bsy,
  CommandAborted => Write1_Ca,
  Error           => Write1_Err,
  ErrorID        => Write1_ErrID
);
```

```

WRITE2(
    Target           := MC_Axis000,
    SettingValue    := Write2_Sv,
    Execute         := Write2_Ex,
    ParameterNumber := Write2_Pn,
    Done           => Write2_D,
    Busy          => Write2_Bsy,
    CommandAborted := Write2_Ca,
    Error         => Write2_Err,
    ErrorID       => Write2_ErrID
);

WRITE3(
    Target           := MC_Axis000,
    SettingValue    := Write3_Sv,
    Execute         := Write3_Ex,
    ParameterNumber := Write3_Pn,
    Done           => Write3_D,
    Busy          => Write3_Bsy,
    CommandAborted := Write3_Ca,
    Error         => Write3_Err,
    ErrorID       => Write3_ErrID
);

```

10-2-18 Updating the Cam Table End Point Index

This sample increases the valid number of data points by 10 in a cam table with a maximum number of data points of 110 and a valid number of data points of 100. It also updates the end point index.


Main Variables Used in the Programming Samples

Variable name	Data type	Default	Comment
CamProfile0	ARRAY[0..109] OF _sMC_CAM_REF	---	This is a cam data variable with a maximum number of data points of 110.* It contains 100 valid cam data points and 10 null cam data points.
WriteCamdata	BOOL	FALSE	This variable is used to start changing the cam data. It is changed to TRUE to start editing.
WriteDone	BOOL	FALSE	This variable is used to indicate when the changes to the cam data are completed. It changes to TRUE when the changes to the cam data are completed.


* The array elements ARRAY[0..N] are set with the Cam Editor in the Sysmac Studio. The range of the array is 0 to 109 in this sample.

Ladder Diagram


The axis parameters are set. When setting the parameters is completed, *InitFlag* is changed to TRUE.




If a minor fault level error occurs in the MC Common Error Status Variable, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.



If *StartPg* and *WriteCamData* are TRUE, the values in the cam data variable are changed. Phases and displacements are set for *CamProfile[100]* to *CamProfile[109]*. When the changes to the cam data variable are completed, *WriteDone* is changed to TRUE.



If the changes to the cam data variable are completed, the Set Cam Table Properties instruction is executed.



ST Programming

```
// The axis parameters are set. When setting the parameters is completed, InitFlag is changed to TRUE.
IF InitFlag=FALSE THEN
    // The phases and displacements for null cam data are set.
    PhaseData:=REAL#99.0;
    DistanceData:=REAL#250.0;

    // The Initialization Completed Flag is changed to TRUE.
    InitFlag := TRUE;
END_IF;

// If a minor fault level error occurs in the MC Common Error Status Variable, the error handler for the device is
// executed.
// Program the FaultHandler according to the device.
IF _MC_COM.MFaultLvl.Active=TRUE THEN
    FaultHandler();
END_IF;

// If StartPg and WriteCamData are TRUE, the values in the cam data variable are changed.
// The phases and displacements are set in CamProfile[100] to CamProfile[109].
// When the changes to the cam data variable are completed, WriteDone is changed to TRUE.
IF StartPg=TRUE
AND WriteCamData=TRUE THEN
    FOR Index := UINT#10#100 TO UINT#10#109 DO
        PhaseData                :=PhaseData+REAL#1.0;
        DistanceData              :=DistanceData+REAL#3.0;
        CamProfile0[Index].Phase  :=PhaseData;
        CamProfile0[Index].Distance :=DistanceData;
    END_FOR;
    WriteDone:=TRUE;
END_IF;

// If the changes to the cam data variable are completed, the Set Cam Table Properties instruction is executed.
IF WriteDone=TRUE THEN
    Set_Cam_Ex := TRUE;
END_IF;

//MC_SetCamTableProperty
SET_CAM(
    CamTable           := CamProfile0,
    Execute            := Set_Cam_Ex,
    Done               => Set_Cam_D,
    EndPointIndex      => Set_Cam_Epi,
    MaxDataNumber      => Set_Cam_Mdn,
    Busy               => Set_Cam_B,
    CommandAborted     => Set_Cam_Ca,
    Error              => Set_Cam_Err,
    ErrorID            => Set_Cam_ErrID
);
```


11

Troubleshooting


This section describes the items to check when problems occur in the MC Function Module. It includes error diagnosis and countermeasures for error indications, and error diagnosis and countermeasures for operating conditions.

11-1 Overview of Errors	11-2
11-1-1 How to Check for Errors	11-3
11-1-2 Errors Related to the Motion Control Function Module	11-5
11-2 Troubleshooting	11-10
11-2-1 Error Table	11-10
11-2-2 Error Descriptions	11-19
11-2-3 Error Causes and Remedies	11-53

11-1 Overview of Errors

You manage all of the errors that occur on the NJ-series Controller as events. The same methods are used for all events. This allows you to see what errors have occurred and find corrections for them with the same methods for the entire range of errors that is managed (i.e., CPU Unit, EtherCAT slaves,* and CJ-series Units).

* The EtherCAT slaves must support NJ-series error management.



You can use the troubleshooting functions of the Sysmac Studio or the Troubleshooter on an NS-series PT to quickly check for errors that have occurred and find corrections for them.

This manual describes the errors that originate in the Motion Control Function Module. Refer to the *NJ-series Troubleshooting Manual* (Cat. No. W503) for specific corrections when errors occur and for troubleshooting information on the entire NJ-series Controller. For information on errors that occur when motion control instructions are executed, refer to each instruction in the *NJ-series Motion Control Instruction Reference Manual* (Cat. No. W508).

11-1-1 How to Check for Errors

You can check to see if an error has occurred with the following methods.

Checking method	What you can check
Checking the indicators	CPU Unit operating status
Troubleshooter of the Sysmac Studio	You can check for current Controller errors, a log of past Controller errors, error sources, error causes, and corrections.
Checking with the Troubleshooter of an NS-series PT	You can check for current Controller errors, a log of past Controller errors, error sources, causes, and corrections.
Checking with instructions that read function module error status	You can check the highest-level status and highest-level event code in the current Controller errors.
Checking with System-defined Variables	You can check the current Controller error status for each function module.

This section describes the above checking methods.

Checking the Indicators

You can use the PWR indicator on the Power Supply Unit and the RUN and ERROR indicators on the CPU Unit to determine the event level for an error. The following table shows the relationship between the Controller's indicators and the event level.

Indicator			CPU Unit operating status	Error confirmation with the Sysmac Studio or an NS-series PT
PWR	RUN	ERROR		
Not lit	Not lit	Not lit	Power Supply Error	Not possible: Refer to the <i>NJ-series Troubleshooting Manual</i> (Cat. No. W503).
Lit	Not lit	Not lit	CPU Unit Reset*1	
Lit	Flashing	Lit	Incorrect Power Supply Unit Connected	
Lit	Not lit	Lit	CPU Unit Watchdog Timer Error*2	
Lit	Not lit	Lit	Major fault level*2	Possible: Connect the Sysmac Studio or an NS-series PT and check the cause of and correction for the error in the troubleshooting functions of the Sysmac Studio or the Troubleshooter of the NS-series PT.
Lit	Lit	Flashing	Partial fault level	
Lit	Lit	Flashing	Minor fault level	
Lit	Lit	Not lit	Observation	
Lit	Lit	Not lit	Normal operation in RUN mode	
Lit	Not lit	Not lit	Normal operation in PROGRAM mode*1	---
Lit	Flashing	Not lit	Normal operation in startup state	---

*1 If you can go online with the CPU Unit from the Sysmac Studio with a direct USB connection, the CPU Unit is in PROGRAM mode. If you cannot go online, the CPU Unit is being reset.

*2 If you can go online with the CPU Unit from the Sysmac Studio with a direct USB connection, a major fault level error has occurred. If you cannot go online, a watchdog timer error has occurred in the CPU Unit.

*3 If you cannot go online with the CPU Unit from the Sysmac Studio, it is also possible that the USB cable is faulty or that the network type on the Sysmac Studio is not set for a direct USB connection. Refer to the *NJ-series Troubleshooting Manual* (Cat. No. W503) if you cannot go online with the CPU Unit.

Checking with the Troubleshooting Function of Sysmac Studio

When an error occurs, you can connect the Sysmac Studio online to the Controller to check current Controller errors and the log of past Controller errors. You can also check the cause of the error and corrections.

Refer to the *NJ-series Troubleshooting Manual* (Cat. No. W503) for the procedures to check for errors with the Sysmac Studio.

Checking with the Troubleshooter of an NS-series PT

If you can connect communications between an NS-series PT and the Controller when an error occurs, you can check for current Controller errors and the log of past Controller errors. You can also check the cause of the error and corrections.

Refer to the *NJ-series Troubleshooting Manual* (Cat. No. W503) for the procedures to check for errors with an NS-series PT.

Checking with Instructions That Read Error Status

You can use instructions in the user program to check the error status of each function module. The following table gives the instruction that is used to get error information for the Motion Control Function Module.

Instruction	Name	Outline of function
GetMCError	Get Motion Control Error Status	The GetMCError instruction gets the highest level status (partial fault or minor fault) and highest level event code of the current Controller errors in the Motion Control Function Module.

For details on the instructions that get error status, refer to the *NJ-series Instructions Reference Manual* (Cat. No. W502).

Checking with System-defined Variables

You can use the error status variables in the system-defined variables and the system-defined variables for motion control to check for errors that have occurred in the Motion Control Function Module.

● Error Status Variables

You can check for errors in each function module of the NJ-series Controller with error status variables. The following variables show the error status of the Motion Control Function Module.

Variable name	Data type	Meaning	Function
_MC_ErrSta	WORD	MC Error Status	Gives the collective error status of all error status for the Motion Control Function Module.
_MC_ComErrSta	WORD	MC Common Error Status	Gives the collective error status of all errors that occur for common processing in the Motion Control Function Module.
_MC_AX_ErrSta	ARRAY[0..63] OF WORD	Axis Error Status	Gives the collective error status of all error status for each axis.
_MC_GRP_ErrSta	ARRAY[0..31] OF WORD	Axes Group Error Status	Gives the collective error status of all error status for each axes group.

The meanings of the individual bits in the above error status variables are given below.

Bit	Name	Description	Value	Meaning
15	Master Detection*1	This bit indicates whether the master detected an error in the slaves that it manages.	TRUE	Error
			FALSE	No error
14	Slave Summary*2	Gives the collective error status of all error status for EtherCAT slaves that are assigned to axes in the Motion Control Function Module.	TRUE	Error
			FALSE	No error
8 to 13	Not used.			
7	Major Fault	Indicates if there is a major fault level error.	TRUE	Error
			FALSE	No error
6	Partial Fault	Indicates if there is a partial fault level error.	TRUE	Error
			FALSE	No error
5	Minor Fault	Indicates if there is a minor fault level error.	TRUE	Error
			FALSE	No error
4	Observation	Indicates if there is an observation level error.	TRUE	Error
			FALSE	No error
0 to 3	Not used.			

*1 This bit is not used in the error status variables for the Motion Control Function Module.

*2 For the Motion Control Function Module, only `_MC_ErrSta` (MC Error Status) is used.

● System-defined Variables for Motion Control

You can monitor the MC Common Variable, Axes Variables, and Axes Group Variables of the system-defined variables for motion control to see if errors have occurred in the Motion Control Function Module.

Refer to 6-6 *System-defined Variables for Motion Control* for information on system-defined variables for motion control.


11-1-2 Errors Related to the Motion Control Function Module

This section describes the errors that are related to the Motion Control Function Module.

Sources of Errors Related to the Motion Control Function Module

Errors can occur internally in the Motion Control Function Module, or they can occur in EtherCAT communications, which are used to connect to the Servo Drives and other slaves.

- Inside MC Function Module
- EtherCAT Master Function Module
- Built-in EtherCAT communications port hardware
- EtherCAT slaves



You can check the sources and causes of the errors in the system-defined variables or from the Sysmac Studio or an NS-series PT.

Classifications

There are the following three sources of errors in the Motion Control Function Module.

Classification	Description
MC Common Errors	If an error is detected in the common portion of the Motion Control Function Module, the corresponding bit in the MC Common Error Status variable shows the error.
Axis Error	If an error is detected for an axis, the corresponding bit in the Axis Error Status variable shows the error.*
Axes Group Errors	If an error is detected for an axes group, the corresponding bit in the Axes Group Error Status variable shows the error.

* If an axis error with a minor fault level or higher level occurs, operation is also not possible for an axes group that contains the axis as a composition axis.

Event Levels

This section describes the operation of the Motion Control Function Module for each event level.

Event level of the error	Operation
Major fault	All NJ-series Controller control operations stop for errors in this event level.
Partial fault	All control operations for one of the function modules in the NJ-series Controller stop for errors in this event level. If a partial fault level error occurs in the Motion Control Function Module, all function of the Motion Control Function Module, such as axis operation, stop.
Minor fault	Some of the control operations for one of the function modules in the NJ-series Controller stop for errors in this event level. If a minor fault level error occurs in the Motion Control Function Module, the relevant axis or axes group stops.
Observation	Errors in the observation level do not affect NJ-series Controller control operations. Observations are reported in order to prevent them from developing into errors at the minor fault level or higher.
Information	Events that are classified as information provide information that do not indicate errors.

MC Function Module Errors by Source

The following tables list the errors in each event level that can occur for each source.

● MC Common Errors

Level	Error name
Major fault	<ul style="list-style-type: none"> • None
Partial fault	<ul style="list-style-type: none"> • Motion Control Parameter Setting Error • Cam Data Read Error • Required Process Data Object Not Set • Axis Slave Disabled • Network Configuration Information Missing for Axis Slave • Motion Control Initialization Error • Motion Control Period Exceeded Error • Absolute Encoder Home Offset Read Error
Minor fault	<ul style="list-style-type: none"> • Cam Table Save Error • Other execution errors for motion control instructions
Observation	<ul style="list-style-type: none"> • Cannot Execute Save Cam Table Instruction
Information	<ul style="list-style-type: none"> • Error Clear from MC Test Run Tab Page

● Axis Errors

Level	Error name
Major fault	<ul style="list-style-type: none"> • None
Partial fault	<ul style="list-style-type: none"> • None
Minor fault	<ul style="list-style-type: none"> • Cam Table Data Error during Cam Motion • Immediate Stop Instruction Executed • Positive Software Limit Exceeded • Negative Software Limit Exceeded • In-position Check Time Exceeded • Following Error Limit Exceeded • Immediate Stop Input • Positive Limit Input Detected • Negative Limit Input Detected • Illegal Following Error • Servo OFF Error • Absolute Encoder Current Position Calculation Failed • Servo Main Circuit Power OFF • Interrupt Feeding Interrupt Signal Missing • Homing Opposite Direction Limit Input Detected • Homing Direction Limit Input Detected • Homing Limit Inputs Detected in Both Directions • Home Proximity/Homing Opposite Direction Limit Input Detected • Home Proximity/Homing Direction Limit Input Detected • Home Input/Homing Opposite Direction Limit Input Detected • Home Input/Homing Direction Limit Input Detected • Invalid Home Input Mask Distance • No Home Input • No Home Proximity Input • Slave Error Detected • MC Common Error Occurrence • Latch Position Overflow • Latch Position Underflow • Master Sync Direction Error • Slave Disconnection during Servo ON • Feed Distance Overflow • Error in Changing Servo Drive Control Mode • Master Axis Position Read Error • Auxiliary Axis Position Read Error • EtherCAT Slave Communications Error • Other execution errors for motion control instructions

Level	Error name
Observation	<ul style="list-style-type: none"> • Following Error Warning • Velocity Warning • Acceleration Warning • Deceleration Warning • Positive Torque Warning • Negative Torque Warning • Command Position Overflow • Command Position Underflow • Actual Position Overflow • Actual Position Underflow • Slave Observation Detected • Notice of Insufficient Travel Distance to Achieve Blending Transit Velocity
Information	<ul style="list-style-type: none"> • Slave Error Code Report

● Axes Group Errors

Level	Error name
Major fault	<ul style="list-style-type: none"> • None
Partial fault	<ul style="list-style-type: none"> • None
Minor fault	<ul style="list-style-type: none"> • Axes Group Immediate Stop Instruction Executed • Home Undefined during Coordinated Motion • Axes Group Composition Axis Error • Other execution errors for motion control instructions
Observation	<ul style="list-style-type: none"> • Velocity Warning • Acceleration Warning • Deceleration Warning • Notice of Insufficient Travel Distance to Achieve Blending Transit Velocity
Information	<ul style="list-style-type: none"> • None

● Errors without Source Classifications

Level	Error name
Major Fault	<ul style="list-style-type: none"> • User Program/Controller Configurations and Setup Transfer Error
Partial Fault	<ul style="list-style-type: none"> • None
Minor Fault	<ul style="list-style-type: none"> • None
Observation	<ul style="list-style-type: none"> • None
Information	<ul style="list-style-type: none"> • None

EtherCAT Communications and EtherCAT Slave Errors

The following Motion Control Function Module error can occur due to errors in EtherCAT communications or EtherCAT slaves.

Error name	Event code	Cause	Operation for error
EtherCAT Slave Communications Error	8440 0000 hex	A communications error occurred for the EtherCAT slave that is allocated to an axis in the Motion Control Function Module.*1	The Servo is turned OFF for the axis with an error and operations other than error resets are not acknowledged.*2
Slave Error Detected	742F 0000 hex	An error was detected in an EtherCAT slave that is allocated to an axis in the Motion Control Function Module.	The Servo is turned OFF for the axis with an error and operations other than error resets are not acknowledged.

*1 When an error occurs in communications with an EtherCAT slave, an error also occurs in the EtherCAT Master Function Module.

*2 When an error occurs in slave communications, home becomes undefined for the axis.

Servo Drive Errors

This section describes the notification that is provided for errors that occur in OMRON G5-series Servo Drives.

There is a difference between the timing of when the Motion Control Function Module detects the error in the Servo Drive and when the error code is obtained from the Servo Drive. The Motion Control Function Module therefore reports different events for the error in the Servo Drive and the error code.

● Error Notification

When the Motion Control Function Module detects an error, a Slave Error Detected minor fault level error (742F0000 hex) occurs. At this point, the Motion Control Function Module performs the error operation (i.e., it turns OFF the Servo).

● Error Code Notification

When the Servo Drive reports the error code, the Motion Control Function Module generates a Slave Error Code Report information event (94220000 hex). The error code from the Servo Drive is included in the attached information of the Slave Error Code Report event.

You must change the settings to receive notification of the Slave Error Code Report event. Map object 603F hex (Error Code) in the PDO Edit Pane.

11-2 Troubleshooting

This section describes the errors that can occur and the corrections for them.

11-2-1 Error Table

The errors (i.e., events) that can occur in the Motion Control Function Module are given on the following pages.

Event levels are given in the table as follows:

Maj: Major fault level

Par: Partial fault level

Min: Minor fault level

Obs: Observation

Info: Information

The upper four digits of the event codes that are given in the following table are output as the error codes to the system-defined variable for motion control. Refer to the *NJ-series Troubleshooting Manual* (Cat. No. W503) for all of the event codes that may occur for an NJ-series Controller.

Event code	Event name	Meaning	Assumed cause	Level					Reference
				Maj	Prt	Min	Obs	Info	
1020000 hex	User Program/Controller Configurations and Setup Transfer Error	The user program or Controller Configurations and Setup were not transferred correctly.	<ul style="list-style-type: none"> The user program or Controller Configurations and Setup are not correct because the power supply to the Controller was interrupted or communications with the Sysmac Studio were disconnected during a download of the user program or the Controller Configurations and Setup. The user program or Controller Configurations and Setup are not correct because the power supply to the Controller was interrupted during online editing. The user program or Controller Configurations and Setup are not correct because the power supply to the Controller was interrupted during a Clear All Memory operation. Non-volatile memory failed. 	√					page 11-20
1460000 hex	Absolute Encoder Home Offset Read Error	The absolute encoder current position that is retained during power interruptions was lost.	<ul style="list-style-type: none"> The life of the Battery in the CPU Unit has expired. Backup memory failure 		√				page 11-21
1461000 hex	Motion Control Parameter Setting Error	The MC parameters that were saved in non-volatile memory are missing.	<ul style="list-style-type: none"> The power supply to the Controller was interrupted or communications with the Sysmac Studio were disconnected while downloading the motion control parameter settings or clearing memory. Non-volatile memory failure 		√				page 11-21

Event code	Event name	Meaning	Assumed cause	Level					Reference
				Maj	Prt	Min	Obs	Info	
14620000 hex	Cam Data Read Error	The cam data that was saved in non-volatile memory is missing.	<ul style="list-style-type: none"> Power was interrupted during save processing for cam data Non-volatile memory failure 		√				page 11-22
34600000 hex	Required Process Data Object Not Set	The object that is required for the axis type is not allocated to PDO.	<ul style="list-style-type: none"> The required PDOs are not mapped when the axis type is set to a servo axis or encoder axis. Non-volatile memory failure 		√				page 11-22
34630000 hex	Axis Slave Disabled	The slave to which the axis is assigned is disabled.	<ul style="list-style-type: none"> The slave to which the axis is assigned is disabled. 		√				page 11-23
34640000 hex	Network Configuration Information Missing for Axis Slave	The network configuration information is not registered for the slave to which the axis is assigned.	<ul style="list-style-type: none"> The EtherCAT network configuration information is not registered for the slave to which the axis is assigned. 		√				page 11-23
44200000 hex	Motion Control Initialization Error	A fatal error occurred in the system and prevented initialization of the Motion Control Function Module.	<ul style="list-style-type: none"> Hardware has failed. 		√				page 11-24
74200000 hex	Motion Control Period Exceeded	Processing for the primary periodic task was not finished within two control periods.	<ul style="list-style-type: none"> The processing load in the primary periodic task is too heavy. 		√				page 11-24
14630000 hex	Cam Table Save Error	Saving a cam table to a file failed.	<ul style="list-style-type: none"> Saving a cam table to a file failed. 				√		page 11-25
54770000 hex	Cam Table Data Error during Cam Motion	The phases are not in ascending order in the cam table.	<ul style="list-style-type: none"> Data containing cam table phases that are not in ascending order was detected during cam motion. The phase and displacement of the start point in the cam table were not 0 during cam operation. The phase of the end point in the cam table when converted to pulses was not 1 pulse or greater during cam operation. 			√			page 11-25
54850000 hex	Immediate Stop Instruction Executed	An Immediate Stop (MC_ImmediateStop) instruction was executed.	<ul style="list-style-type: none"> An Immediate Stop instruction was executed. 			√			page 11-26
54860000 hex	Axes Group Immediate Stop Instruction Executed	An Axes Group Immediate Stop (MC_GroupImmediateStop) instruction was executed.	<ul style="list-style-type: none"> A Group Immediate Stop instruction was executed. 			√			page 11-26
64450000 hex	Positive Software Limit Exceeded	The position exceeded the positive software limit while the axis is in motion.	<ul style="list-style-type: none"> The position exceeded the positive software limit. 			√			page 11-27
64460000 hex	Negative Software Limit Exceeded	The position exceeded the negative software limit while the axis is in motion.	<ul style="list-style-type: none"> The position exceeded the negative software limit. 			√			page 11-27

Event code	Event name	Meaning	Assumed cause	Level					Reference
				Maj	Prt	Min	Obs	Info	
64470000 hex	In-position Check Time Exceeded	The in-position check was not completed within the monitoring time.	<ul style="list-style-type: none"> Time is required to complete positioning. 			√			page 11-28
64480000 hex	Following Error Limit Exceeded	The error between the command current position and actual current value exceeded the Following Error Over Limit Value.	<ul style="list-style-type: none"> The positioning operation has poor following performance and the actual motion is slower than the command. 			√			page 11-28
64490000 hex	Immediate Stop Input	The immediate stop input turned ON.	<ul style="list-style-type: none"> An immediate stop input signal was detected. The immediate stop input signal is not connected correctly or the logic setting for the immediate stop input is wrong. 			√			page 11-29
644A0000 hex	Positive Limit Input Detected	The positive limit input turned ON.	<ul style="list-style-type: none"> A positive limit input signal was detected. The positive limit input signal is not connected correctly or the logic setting for the positive limit input is wrong. 			√			page 11-29
644B0000 hex	Negative Limit Input Detected	The negative limit input turned ON.	<ul style="list-style-type: none"> A negative limit input signal was detected. The negative limit input signal is not connected correctly or the logic setting for the negative limit input is wrong. 			√			page 11-30
64560000 hex	Illegal Following Error	The difference between the command position and the actual current position exceeds the range of 30-bit data when converted to pulses.	<ul style="list-style-type: none"> The command current position was restricted so that the axis velocity of the slave axis would not exceed the axis maximum velocity for the specified travel distance. Performance of slave axis positioning operation is poor and the actual motion is slower than the command. 			√			page 11-30
64570000 hex	Servo OFF Error	The Servo was turned OFF for an axis due to an axes group error.	<ul style="list-style-type: none"> The Servo was turned OFF for an axis due to an axes group error. 			√			page 11-31
64580000 hex	Absolute Encoder Current Position Calculation Failed	It was not possible to correctly restore the current position from the absolute encoder information that was saved when power was interrupted.	<ul style="list-style-type: none"> The ring counter setting in the Controller or the ring counter setting in the Servo Drive settings was changed. The position to restore when converted to pulses exceeded the range of signed 40-bit data. 			√			page 11-31

Event code	Event name	Meaning	Assumed cause	Level					Reference
				Maj	Prt	Min	Obs	Info	
64590000 hex	Home Undefined during Coordinated Motion	Home of the logical axis became undefined during axes group motion or while decelerating to a stop.	<ul style="list-style-type: none"> The command position or actual position overflowed or underflowed for a logical axis in an axes group motion or a logical axis that was decelerating to a stop and the home definition was lost. A slave communications error occurred for a logical axis and home became undefined during axes group motion or while decelerating to a stop. A slave for a logical axis left the network and home became undefined during axes group motion or while decelerating to a stop. 			√			page 11-32
74210000 hex	Servo Main Circuit Power OFF	The main circuit power of the Servo Drive turned OFF while the Servo was ON.	<ul style="list-style-type: none"> The main circuit power of the Servo Drive was interrupted while the Servo was ON. 			√			page 11-32
74230000 hex	Interrupt Feeding Interrupt Signal Missing	An interrupt input was not received during execution of an MC_MoveFeed (Interrupt Feeding) instruction.	<ul style="list-style-type: none"> The latch enabled range specification is invalid. There is a problem with the wiring of the interrupt signal. The sensor that outputs the interrupt signal has failed. 			√			page 11-33
74240000 hex	Homing Opposite Direction Limit Input Detected	The limit signal in the direction opposite to the homing direction was detected during a homing operation.	<ul style="list-style-type: none"> The Operation Selection at Negative Limit Input or Operation Selection at Positive Limit Input parameter is set to <i>No reverse turn</i>. The location of the homing input signal sensors, homing settings, and homing start position cause a limit input to be reached. The input signal sensor wiring is incorrect or the sensor is faulty. 			√			page 11-33
74250000 hex	Homing Direction Limit Input Detected	The limit signal in the homing direction was detected during a homing operation.	<ul style="list-style-type: none"> The Operation Selection at Negative Limit Input or Operation Selection at Positive Limit Input parameter is set to <i>No reverse turn</i>. The location of the homing input signal sensors, homing settings, and homing start position cause a limit input to be reached. The input signal sensor wiring is incorrect or the sensor is faulty. 			√			page 11-34
74260000 hex	Homing Limit Inputs Detected in Both Directions	The limit signals in both directions were detected during a homing operation.	<ul style="list-style-type: none"> The wiring of the limit signal is incorrect. The limit sensor is installed in the wrong location. The contact logic of the limit signal is not correct. The limit sensor failed. 			√			page 11-34

Event code	Event name	Meaning	Assumed cause	Level					Reference
				Maj	Prt	Min	Obs	Info	
74270000 hex	Home Proximity/Homing Opposite Direction Limit Input Detected	The home proximity input and the limit signal in the direction opposite to the homing direction were detected during a homing operation.	<ul style="list-style-type: none"> The wiring of the home proximity signal or limit signal is incorrect. The home proximity sensor or limit sensor is installed in the wrong location. The contact logic of the home proximity signal or limit signal is not correct. The home proximity sensor or limit sensor failed. 			√			page 11-35
74280000 hex	Home Proximity/Homing Direction Limit Input Detected	The home proximity input and the limit signal in the homing direction were detected at the same time during a homing operation.	<ul style="list-style-type: none"> The wiring of the home proximity signal or limit signal is incorrect. The home proximity sensor or limit sensor is installed in the wrong location. The contact logic of the home proximity signal or limit signal is not correct. The home proximity sensor or limit sensor failed. 			√			page 11-36
74290000 hex	Home Input/Homing Opposite Direction Limit Input Detected	The home input and the limit signal in the direction opposite to the homing direction were detected at the same time during a homing operation.	<ul style="list-style-type: none"> The wiring of the home input signal or limit signal is incorrect. The home input sensor or limit sensor is installed in the wrong location. The contact logic of the home input signal or limit signal is not correct. The home input signal output device or limit sensor failed. 			√			page 11-36
742A0000 hex	Home Input/Homing Direction Limit Input Detected	The home input and the limit signal in the homing direction were detected at the same time during a homing operation.	<ul style="list-style-type: none"> The wiring of the home input signal or limit signal is incorrect. The home input sensor or limit sensor is installed in the wrong location. The contact logic of the home input signal or limit signal is not correct. The home input signal output device or limit sensor failed. 			√			page 11-37
742B0000 hex	Invalid Home Input Mask Distance	The setting of the home input mask distance is not suitable for the MC_Home instruction.	<ul style="list-style-type: none"> The set value of the home input mask distance when the operating mode of the MC_Home instruction is set to <i>Proximity Reverse Turn/Home Input Mask Distance</i> is insufficient to decelerate from the homing velocity to the homing approach velocity. 			√			page 11-37
742C0000 hex	No Home Input	There was no home signal input during the homing operation. Or, a limit signal was detected before there was a home input.	<ul style="list-style-type: none"> There was no home signal input during the homing operation. A limit signal was detected before there was a home input. 			√			page 11-38
742D0000 hex	No Home Proximity Input	There was no home proximity signal input during the homing operation.	<ul style="list-style-type: none"> There was no home proximity signal input during the homing operation when a home proximity input signal was specified. 			√			page 11-38

Event code	Event name	Meaning	Assumed cause	Level					Reference
				Maj	Prt	Min	Obs	Info	
742F0000 hex	Slave Error Detected	An alarm was detected for the EtherCAT slave that is allocated to an axis.	<ul style="list-style-type: none"> An error was detected for the EtherCAT slave that is allocated to the axis. 			√			page 11-39
74300000 hex	Axes Group Composition Axis Error	An error occurred for an axis in an axes group.	<ul style="list-style-type: none"> An error occurred for an axis in an axes group that was in motion. 			√			page 11-39
74330000 hex	MC Common Error Occurrence	An MC common error occurred.	<ul style="list-style-type: none"> Partial fault level MC common error occurred. 			√			page 11-39
74340000 hex	Latch Position Overflow	An overflow occurred for the latched position for the MC_TouchProbe (Enable External Latch) instruction.	<ul style="list-style-type: none"> An overflow occurred for the latched position for the MC_TouchProbe (Enable External Latch) instruction. 			√			page 11-40
74350000 hex	Latch Position Underflow	An underflow occurred for the latched position for the MC_TouchProbe (Enable External Latch) instruction.	<ul style="list-style-type: none"> An underflow occurred for the latched position for the MC_TouchProbe (Enable External Latch) instruction. 			√			page 11-40
74360000 hex	Master Sync Direction Error	The master axis continued to move in the direction opposite to the sync direction.	<ul style="list-style-type: none"> The master axis continued to move in the direction opposite to the sync direction of the master and slave axes, resulting in an overflow. 			√			page 11-40
74370000 hex	Slave Disconnection during Servo ON	An EtherCAT slave that is allocated to an axis was disconnected while the servo was ON.	<ul style="list-style-type: none"> An EtherCAT slave that is allocated to an axis was disconnected or replaced while the Servo was ON. 			√			page 11-41
74380000 hex	Feed Distance Overflow	The target position after the interrupt input was received for the MC_MoveFeed (Interrupt Feeding) instruction overflowed or underflowed.	<ul style="list-style-type: none"> The target position after the interrupt input was received for the MC_MoveFeed (Interrupt Feeding) instruction exceeded the range of signed 40-bit data when converted to pulses. 			√			page 11-41

Event code	Event name	Meaning	Assumed cause	Level					Reference
				Maj	Prt	Min	Obs	Info	
74390000 hex	Error in Changing Servo Drive Control Mode	Changing the Control Mode was not completed within the specified time.	<ul style="list-style-type: none"> When the MC_SyncMoveVelocity instruction was stopped, the actual current velocity was not reduced to 10% or less of the maximum velocity within 10 seconds for three consecutive periods after a command velocity of 0 was output. For an OMRON G5-series Servo Drive, the actual current velocity was not reduced to 10% or less of the maximum velocity within 10 seconds for three consecutive periods when the MC_TorqueControl instruction was stopped. Changing the Control Mode of the Servo Drive between CSP, CSV, and CST was not completed within one second after the command was executed. 			√			page 11-41
743A0000 hex	Master Axis Position Read Error	The synchronized instruction was not executed because an error occurred in the position of the master axis of the synchronized instruction.	<ul style="list-style-type: none"> EtherCAT process data communications are not established for the master axis of the synchronized instruction. The slave of the master axis for the synchronized instruction was disconnected. An Absolute Encoder Current Position Calculation Failed error (6458000 hex) was detected for the master axis of a synchronized instruction. 			√			page 11-43
743B0000 hex	Auxiliary Axis Position Read Error	The synchronized instruction was not executed because an error occurred in the position of the auxiliary axis of the synchronized instruction.	<ul style="list-style-type: none"> EtherCAT process data communications are not established for the auxiliary axis of the synchronized instruction. The slave of the auxiliary axis for the synchronized instruction was disconnected. An Absolute Encoder Current Position Calculation Failed error (6458000 hex) was detected for the auxiliary axis of a synchronized instruction. 			√			page 11-44
84400000 hex	EtherCAT Slave Communications Error	A communications error occurred for the EtherCAT slave that is allocated to an axis.	<ul style="list-style-type: none"> A communications error occurred for the EtherCAT slave that is allocated to an axis. 			√			page 11-44
644C0000 hex	Following Error Warning	The following error exceeded the Following Error Warning Value.	<ul style="list-style-type: none"> Performance of positioning operation is poor and the actual motion is slower than the command. 				√		page 11-45
644D0000 hex	Velocity Warning	The command velocity exceeded the velocity warning value.	<ul style="list-style-type: none"> The command velocity exceeded the velocity warning value. 				√		page 11-45
644E0000 hex	Acceleration Warning	The command acceleration exceeded the acceleration warning value.	<ul style="list-style-type: none"> The command acceleration rate exceeded the acceleration warning value. 				√		page 11-46

Event code	Event name	Meaning	Assumed cause	Level					Reference
				Maj	Prt	Min	Obs	Info	
644F0000 hex	Deceleration Warning	The command deceleration exceeded the deceleration warning value.	<ul style="list-style-type: none"> The command deceleration rate exceeded the deceleration warning value. 				√		page 11-46
64500000 hex	Positive Torque Warning	The torque command value exceeded the positive torque warning value.	<ul style="list-style-type: none"> The torque command value exceeded the positive torque warning value. 				√		page 11-47
64510000 hex	Negative Torque Warning	The torque command value exceeded the negative torque warning value.	<ul style="list-style-type: none"> The torque command value exceeded the negative torque warning value. 				√		page 11-47
64520000 hex	Command Position Overflow	The number of pulses for the command position overflowed.	<ul style="list-style-type: none"> In Linear Mode, the command position when converted to pulses exceeded the upper limit of signed 40-bit data. 				√		page 11-48
64530000 hex	Command Position Underflow	The number of pulses for the command position exceeded the valid range. (It underflowed.)	<ul style="list-style-type: none"> In Linear Mode, the command position when converted to pulses exceeded the lower limit of signed 40-bit data. 				√		page 11-48
64540000 hex	Actual Position Overflow	The number of pulses for the actual position overflowed.	<ul style="list-style-type: none"> The actual position when converted to pulses exceeded the upper limit of signed 40-bit data. 				√		page 11-49
64550000 hex	Actual Position Underflow	The number of pulses for the actual position underflowed.	<ul style="list-style-type: none"> The actual position when converted to pulses exceeded the lower limit of signed 40-bit data. 				√		page 11-49
74320000 hex	Slave Observation Detected	A warning has been detected for an EtherCAT slave.	<ul style="list-style-type: none"> A warning was detected for the EtherCAT slave that is allocated to the axis. 				√		page 11-50
743C0000 hex	Cannot Execute Save Cam Table Instruction	You cannot save a cam table to a file when non-volatile memory is being accessed by another operation.	<ul style="list-style-type: none"> An attempt was made to execute the MC_SaveCamTable instruction when another operation was accessing the non-volatile memory (e.g., transfer or data trace operation from the Sysmac Studio). 				√		page 11-50

Event code	Event name	Meaning	Assumed cause	Level					Reference
				Maj	Prt	Min	Obs	Info	
94200000 hex	Notice of Insufficient Travel Distance to Achieve Blending Transit Velocity	There is not sufficient travel distance to accelerate or decelerate to the transit velocity during blending operation.	<ul style="list-style-type: none"> When the Acceleration/Deceleration Over parameter was set to <i>Use rapid acceleration/deceleration (Blending is changed to Buffered)</i>, the results of profile creation caused the acceleration/deceleration rate to be exceeded when blending was specified, so buffered was used. Blending was specified, but the target position was already reached, so it was changed to Buffered because the profile could not be created. <i>Blending</i> was specified for an interpolation instruction, but based on the results of profile creation, this was changed to <i>Buffered</i> because the execution time of the instruction before the transition was four control periods or less. 				√		page 11-51
94210000 hex	Error Clear from MC Test Run Tab Page	An error was cleared from the MC Test Run Pane of the Sysmac Studio.	<ul style="list-style-type: none"> An error was cleared from the MC Test Run Pane of the Sysmac Studio. 					√	page 11-51
94220000 hex	Slave Error Code Report	The error code was reported by the slave when a Slave Error Detected error occurred.	<ul style="list-style-type: none"> The error code was reported by the slave when a Slave Error Detected error (742F0000 hex) occurred. 					√	page 11-52

11-2-2 Error Descriptions

This section describes the information that is given for individual errors.

Controller Error Descriptions

The items that are used to describe individual errors (events) are described in the following copy of an error table.

Event name	Gives the name of the error.			Event code	Gives the code of the error.	
Meaning	Gives a short description of the error.					
Source	Gives the source of the error.		Source details	Gives details on the source of the error.	Detection timing	Tells when the error is detected.
Error attributes	Level	Tells the level of influence on control.*1	Recovery	Gives the recovery method.*2	Log category	Tells which log the error is saved in.*3
Effects	User program	Tells what will happen to execution of the user program.*4	Operation	Provides special information on the operation that results from the error.		
Indicators	Gives the status of the built-in EtherNet/IP port and built-in EtherCAT port indicators. Indicator status is given only for errors in the EtherCAT Master Function Module and the EtherNet/IP Function Module.					
System-defined variables	Variable	Data type		Name		
	Lists the variable names, data types, and meanings for system-defined variables that provide direct error notification, that are directly affected by the error, or that contain settings that cause the error.					
Cause and correction	Assumed cause		Correction		Prevention	
	Lists the possible causes, corrections, and preventive measures for the error.					
Attached information	This is the attached information that is displayed by the Sysmac Studio or an NS-series PT.					
Precautions/Remarks	Provides precautions, restrictions, and supplemental information.					

*1 One of the following:

Major fault: Major fault level
 Partial fault: Partial fault level
 Minor fault: Minor fault level
 Observation
 Information

*2 One of the following:

Automatic recovery: Normal status is restored automatically when the cause of the error is removed.
 Error reset: Normal status is restored when the error is reset after the cause of the error is removed.
 Cycle the power supply: Normal status is restored when the power supply to the Controller is turned OFF and then back ON after the cause of the error is removed.
 Controller reset: Normal status is restored when the Controller is reset after the cause of the error is removed.
 Depends on cause: The recovery method depends on the cause of the error.

*3 One of the following:

System: System event log
 Access: Access event log

*4 One of the following:

Continues: Execution of the user program will continue.
 Stops: Execution of the user program stops.
 Starts: Execution of the user program starts.

Error Descriptions

Event name	User Program/Controller Configurations and Setup Transfer Error		Event code	10200000 hex		
Meaning	The user program or Controller Configurations and Setup were not transferred correctly.					
Source	PLC Function Module Motion Control Function Module EtherCAT Master Function Module EtherNet/IP Function Module		Source details	None	Detection timing	At power ON or Controller reset
Error attributes	Level	Major fault	Recovery	Cycle the power supply or reset the Controller.	Log category	System
Effects	User program	Stops.	Operation	All outputs are stopped.		
System-defined variables	Variable		Data type		Name	
	None		---		---	
Cause and correction	Assumed cause		Correction		Prevention	
	The user program or Controller Configurations and Setup are not correct because the power supply to the Controller was interrupted or communications with the Sysmac Studio were disconnected during a download of the user program or the Controller Configurations and Setup.		Clear all of memory and then download the project from the Sysmac Studio. If attached information is registered, cycle the power supply to the Controller and then implement the above correction.		Do not turn OFF the power supply to the Controller or disconnect communications with the Sysmac Studio during a download of the user program or the Controller Configurations and Setup.	
	The user program or Controller Configurations and Setup are not correct because the power supply to the Controller was interrupted during online editing.				Do not interrupt the power supply to the Controller during online editing.	
	The user program or Controller Configurations and Setup are not correct because the power supply to the Controller was interrupted during a Clear All Memory operation.				Do not interrupt the power supply to the Controller during a Clear All Memory operation.	
Non-volatile memory failed.		If the error persists even after you make the above correction, replace the CPU Unit.		None		
Attached information	Attached Information 1: Cause Details None: Power was interrupted or communications were disconnected during a download or power was interrupted during online editing. Downloading/Pre-downloading: For other causes, the timing of error occurrence (during download or during download preparations) is given.					
Precautions/Remarks	None					

Event name	Absolute Encoder Home Offset Read Error			Event code	14600000 hex	
Meaning	The absolute encoder current position that is retained during power interruptions was lost.					
Source	Motion Control Function Module		Source details	MC Common	Detection timing	At power ON, at Controller reset, or when down-loading
Error attributes	Level	Partial fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	It will not be possible to perform axis control.		
System-defined variables	Variable		Data type		Name	
	_MC_COM.PFaultLvl.Active		BOOL		MC Common Partial Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The life of the Battery in the CPU Unit has expired.		Replace the Battery in the CPU Unit, reset the error, and perform homing to define home.		Periodically replace the Battery in the CPU Unit. Refer to the <i>NJ-series CPU Unit Hardware User's Manual</i> (Cat. No. W500) for information on the Battery life.	
	Backup memory failure		If the error occurs even after the above correction is performed, CPU backup memory has failed. Replace the CPU Unit and perform homing to define home.		None	
Attached information	None					
Precautions/Remarks	None					

Event name	Motion Control Parameter Setting Error			Event code	14610000 hex	
Meaning	The MC parameters that were saved in non-volatile memory are missing.					
Source	Motion Control Function Module		Source details	MC common	Detection timing	At power ON, at Controller reset, or when down-loading
Error attributes	Level	Partial fault	Recovery	Cycle the power supply or reset the Controller.	Log category	System
Effects	User program	Continues.	Operation	It will not be possible to perform axis control.		
System-defined variables	Variable		Data type		Name	
	_MC_COM.PFaultLvl.Active		BOOL		MC Common Partial Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The power supply to the Controller was interrupted or communications with the Sysmac Studio were disconnected while downloading the motion control parameter settings or clearing memory.		Download the MC parameters from the Sysmac Studio.		Do not turn OFF the power supply during save processing for the parameters.	
	Non-volatile memory failure		If the error occurs even after the above correction is performed, non-volatile memory has failed. After you replace the CPU Unit, download all settings including the Axis Settings from the Sysmac Studio.		None	
Attached information	None					
Precautions/Remarks	None					

Event name	Cam Data Read Error			Event code	14620000 hex	
Meaning	The cam data that was saved in non-volatile memory is missing.					
Source	Motion Control Function Module		Source details	MC Common	Detection timing	At power ON, at Controller reset, or when downloading
Error attributes	Level	Partial fault	Recovery	Cycle the power supply or reset the Controller.	Log category	System
Effects	User program	Continues.	Operation	It will not be possible to perform axis control.		
System-defined variables	Variable		Data type		Name	
	_MC_COM.PFaultLvl.Active		BOOL		MC Common Partial Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	Power was interrupted during save processing for cam data		Download the cam data from the Sysmac Studio.		Do not turn OFF the power supply during save processing for the cam data.	
	Non-volatile memory failure		If the error occurs even after the above correction is performed, non-volatile memory has failed. After you replace the CPU Unit, download all settings including the Axis Settings from the Sysmac Studio.		None	
Attached information	None					
Precautions/Remarks	None					

Event name	Required Process Data Object Not Set			Event code	34600000 hex	
Meaning	The object that is required for the axis type is not allocated to PDO.					
Source	Motion Control Function Module		Source details	MC Common	Detection timing	At power ON, at Controller reset, or when downloading
Error attributes	Level	Partial fault	Recovery	Cycle the power supply or reset the Controller.	Log category	System
Effects	User program	Continues.	Operation	It will not be possible to perform axis control.		
System-defined variables	Variable		Data type		Name	
	_MC_COM.PFaultLvl.Active		BOOL		MC Common Partial Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The required PDOs are not mapped when the axis type is set to a servo axis or encoder axis.		Map the PDOs that are required for the relevant axis type. Refer to <i>A-1-2 Servo Drive Settings</i> for the required PDOs.		Map the PDOs that are required for the axis types that are used. Refer to <i>A-1-2 Servo Drive Settings</i> for the required PDOs.	
	Non-volatile memory failure		If the error occurs even after the above correction is performed, non-volatile memory has failed. After you replace the CPU Unit, download all settings including the Axis Parameter Settings from the Sysmac Studio.		None	
Attached information	None					
Precautions/Remarks	None					

Event name	Axis Slave Disabled			Event code	34630000 hex	
Meaning	The slave to which the axis is assigned is disabled.					
Source	Motion Control Function Module		Source details	MC Common	Detection timing	At power ON, at Controller reset, or when down-loading
Error attributes	Level	Partial fault	Recovery	Cycle the power supply or reset the Controller.	Log category	System
Effects	User program	Continues.	Operation	It will not be possible to perform axis control.		
System-defined variables	Variable		Data type		Name	
	_MC_COM.PFaultLvl.Active		BOOL		MC Common Partial Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The slave to which the axis is assigned is disabled.		Enable the slave to which the axis is assigned in the EtherCAT settings. If there is no slave, set the axis type to a virtual axis.		Enable the slaves to which axes are assigned in the EtherCAT settings. If there are no slaves, set the axis type to a virtual axis when using an axis in the program.	
Attached information	None					
Precautions/Remarks	None					

Event name	Network Configuration Information Missing for Axis Slave			Event code	34640000 hex	
Meaning	The network configuration information is not registered for the slave to which the axis is assigned.					
Source	Motion Control Function Module		Source details	MC Common	Detection timing	At power ON, at Controller reset, or when down-loading
Error attributes	Level	Partial fault	Recovery	Cycle the power supply or reset the Controller.	Log category	System
Effects	User program	Continues.	Operation	It will not be possible to perform axis control.		
System-defined variables	Variable		Data type		Name	
	_MC_COM.PFaultLvl.Active		BOOL		MC Common Partial Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The EtherCAT network configuration information is not registered for the slave to which the axis is assigned.		Register the EtherCAT network configuration information for the slave to which the axis is assigned. Or, set the axis type to a virtual axis.		Register the network configuration information for the slaves to which axes are assigned.	
Attached information	None					
Precautions/Remarks	None					

Event name	Motion Control Initialization Error			Event code	44200000 hex	
Meaning	A fatal error occurred in the system and prevented initialization of the Motion Control Function Module.					
Source	Motion Control Function Module		Source details	MC Common	Detection timing	At power ON, at Controller reset, or when downloading
Error attributes	Level	Partial fault	Recovery	Cycle the power supply.	Log category	System
Effects	User program	Continues.	Operation	It will not be possible to perform axis control. It will not be possible to execute motion control instructions.		
System-defined variables	Variable		Data type		Name	
	_MC_COM.PFaultLvl.Active		BOOL		MC Common Partial Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	Hardware has failed.		Replace the CPU Unit.		None	
Attached information	Attached information 1: Controller information					
Precautions/Remarks	None					

Event name	Motion Control Period Exceeded			Event code	74200000 hex	
Meaning	Processing for the primary periodic task was not finished within two control periods.					
Source	Motion Control Function Module		Source details	MC Common	Detection timing	Continuously
Error attributes	Level	Partial fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	Operation is not possible for all axes. Axes in motion stop immediately.		
System-defined variables	Variable		Data type		Name	
	_MC_COM.PFaultLvl.Active		BOOL		MC Common Partial Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The processing load in the primary periodic task is too heavy.		Reduce the amount of processing in the primary periodic task or set the control period to a value that is long enough not to cause operation problems. Check the task period in the Task Period Monitor of the Sysmac Studio.		Write the programs for the primary periodic task so that they perform only the processes required in the specified period. Or, set the period of the primary periodic task to be long enough to complete all required processing.	
Attached information	None					
Precautions/Remarks	None					

Event name	Cam Table Save Error		Event code	14630000 hex		
Meaning	Saving a cam table to a file failed.					
Source	Motion Control Function Module		Source details	MC Common	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset or cycling power supply	Log category	System
Effects	User program	Continues.	Operation	This error may occur when you read a cam table because the cam data in non-volatile memory may be corrupted.		
System-defined variables	Variable		Data type		Name	
	_MC_COM.MFaultLvl.Active		BOOL		MC Common Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	Saving a cam table to a file failed.		Save the file again. If the problem still occurs, non-volatile memory has failed. Replace the CPU Unit.		None	
Attached information	None					
Precautions/Remarks	None					

Event name	Cam Table Data Error during Cam Motion		Event code	54770000 hex		
Meaning	The phases are not in ascending order in the cam table.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	Operation is not possible for relevant axes. Relevant axis decelerates to a stop if it is in motion.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	Data containing cam table phases that are not in ascending order was detected during cam motion.		Correct the cam table data so that the phases are in ascending order.		Place the phase data into ascending order in the cam table data.	
	The phase and displacement of the start point in the cam table were not 0 during cam operation.		Correct the cam table data so that the phase and displacement of the start point are 0.		Set the cam table data so that the phase and displacement of the start point are 0.	
	The phase of the end point in the cam table when converted to pulses was not 1 pulse or greater during cam operation.		Correct the cam table data so that the phase of the end point is 1 pulse or greater when converted to pulses.		Set the cam table data so that the phase of the end point is 1 pulse or greater when converted to pulses.	
Attached information	None					
Precautions/Remarks	None					

Event name	Immediate Stop Instruction Executed		Event code	54850000 hex		
Meaning	An Immediate Stop (MC_ImmediateStop) instruction was executed.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	An immediate stop is performed according to the Stop Mode that is set in the <i>StopMode</i> input variable to the MC_ImmediateStop instruction. If the axis is part of an axes group in motion, all other axes will act according to the Axes Group Stop Mode Selection.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	An Immediate Stop instruction was executed.		---		---	
Attached information	None					
Precautions/Remarks	None					

Event name	Axes Group Immediate Stop Instruction Executed		Event code	54860000 hex		
Meaning	An Axes Group Immediate Stop (MC_GroupImmediateStop) instruction was executed.					
Source	Motion Control Function Module		Source details	Axes group	Detection timing	At instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	An immediate stop is performed for all axes in the axes group according to the Immediate Stop Input Stop Method axis parameter.		
System-defined variables	Variable		Data type		Name	
	_MC_GRP[*].MFaultLvl.Active		BOOL		Axes Group Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	A Group Immediate Stop instruction was executed.		---		---	
Attached information	None					
Precautions/Remarks	None					

Event name	Positive Software Limit Exceeded			Event code	64450000 hex	
Meaning	The position exceeded the positive software limit while the axis is in motion.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	Follows the setting of the Software Limit Function Selection.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The position exceeded the positive software limit.		Find the reason that the software limit was exceeded and make suitable corrections.		(The goal is to enable detecting the software limits when they are exceeded due to unanticipated causes. Preventative measures are not required.)	
Attached information	None					
Precautions/Remarks	Whenever you change the positive software limit setting, make sure that the new setting is safe.					

Event name	Negative Software Limit Exceeded			Event code	64460000 hex	
Meaning	The position exceeded the negative software limit while the axis is in motion.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	Follows the setting of the Software Limit Function Selection.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The position exceeded the negative software limit.		Find the reason that the software limit was exceeded and make suitable corrections.		(The goal is to enable detecting the software limits when they are exceeded due to unanticipated causes. Preventative measures are not required.)	
Attached information	None					
Precautions/Remarks	Whenever you change negative software limit settings, make sure that the new setting is safe.					

Event name	In-position Check Time Exceeded		Event code	64470000 hex		
Meaning	The in-position check was not completed within the monitoring time.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	Operation is not possible for relevant axis. Relevant axis decelerates to a stop if it is in motion.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	Time is required to complete positioning.		Determine the cause of the slow positioning and remove the cause of the error. Or, adjust the Servo Drive or adjust the In-position Check Time or In-position Range. Increase the loop gain if you adjust the Servo Drive. However, make sure that you keep the loop gain low enough so that the control does not oscillate.		Remove the cause of poor following performance or oscillation/vibration in the positioning operation as much as possible.	
Attached information	None					
Precautions/Remarks	None					

Event name	Following Error Limit Exceeded		Event code	64480000 hex		
Meaning	The error between the command current position and actual current value exceeded the Following Error Over Limit Value.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	Operation is not possible for relevant axis. Relevant axis decelerates to a stop if it is in motion.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The positioning operation has poor following performance and the actual motion is slower than the command.		Remove the cause of poor following performance in the positioning operation. Or increase the Following Error Over Limit Value within the range that will not create problems.		Remove the cause of poor following performance in the positioning operation as best you can.	
Attached information	None					
Precautions/Remarks	None					

Event name	Immediate Stop Input			Event code	64490000 hex	
Meaning	The immediate stop input turned ON.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	According to the Immediate Stop Input Stop Method.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFAultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	An immediate stop input signal was detected.		Turn OFF the immediate stop input signal.		(The goal is to detect the immediate stop input. Preventative measures are not required.)	
	The immediate stop input signal is not connected correctly or the logic setting for the immediate stop input is wrong.		If the error occurs even when the immediate stop input signal is OFF, correct the immediate stop signal connection and logic setting for the immediate stop input.		Make sure that the immediate stop signal connection and logic setting for the immediate stop input are correct.	
Attached information	None					
Precautions/Remarks	You must turn OFF the immediate stop input signal before you reset the error.					

Event name	Positive Limit Input Detected			Event code	644A0000 hex	
Meaning	The positive limit input turned ON.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	According to the Limit Input Stop Method.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFAultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	A positive limit input signal was detected.		Reset the error and move the axis back in the negative direction before it exceeds the limit in the positive direction. Find the reason the limit was exceeded and make suitable corrections.		The goal is to detect the positive limit input. Preventative measures are not required. However, be sure not to exceed the positive limit input when making programs.	
	The positive limit input signal is not connected correctly or the logic setting for the positive limit input is wrong.		If a positive limit input signal does not occur, correct the connection of the positive limit signal and the logic setting for the positive limit input.		Make sure that the positive limit signal connection and logic setting for the positive limit input are correct.	
Attached information	None					
Precautions/Remarks	None					

Event name	Negative Limit Input Detected			Event code	644B0000 hex	
Meaning	The negative limit input turned ON.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	According to the Limit Input Stop Method.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFAultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	A negative limit input signal was detected.		Reset the error and move the axis back in the positive direction before it exceeds the limit in the negative direction. Find the reason the limit was exceeded and make suitable corrections.		The goal is to detect the negative limit input. Preventative measures are not required. However, be sure not to exceed the negative limit input when making programs.	
	The negative limit input signal is not connected correctly or the logic setting for the negative limit input is wrong.		If a negative limit input signal does not occur, correct the connection of the negative limit signal and the logic setting for the negative limit input.		Make sure that the negative limit signal connection and logic setting for the negative limit input are correct.	
Attached information	None					
Precautions/Remarks	None					

Event name	Illegal Following Error			Event code	64560000 hex	
Meaning	The difference between the command position and the actual current position exceeds the range of 30-bit data when converted to pulses.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The Servo for the axis turns OFF.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFAultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The command current position was restricted so that the axis velocity of the slave axis would not exceed the axis maximum velocity for the specified travel distance.		Correct the program or correct the electronic gear ratio so that the slave axis does not exceed the maximum velocity.		Write the program or set the electronic gear ratio so that the slave axis does not exceed the maximum velocity.	
	Performance of slave axis positioning operation is poor and the actual motion is slower than the command.		Remove the cause of poor slave axis following performance in the positioning operation.		Remove the cause of poor slave axis following performance in the positioning operation as best you can.	
Attached information	None					
Precautions/Remarks	None					

Event name	Servo OFF Error		Event code	64570000 hex		
Meaning	The Servo was turned OFF for an axis due to an axes group error.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The Servo for the axis turns OFF.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The Servo was turned OFF for an axis due to an axes group error.		Find the cause of the error and take suitable measures.		None	
Attached information	None					
Precautions/Remarks	This error occurs for axes for which the Servos are turned OFF for an axes group error to interlock the axes so that the Servos cannot be turned ON with the MC_Power (Power Servo) instruction. This error occurs only when an immediate stop of the command value and turning OFF Servo at same time (free-run stop) is specified for the Axes Group Stop Method Selection.					

Event name	Absolute Encoder Current Position Calculation Failed		Event code	64580000 hex		
Meaning	It was not possible to correctly restore the current position from the absolute encoder information that was saved when power was interrupted.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	Operation is not possible for relevant axes.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	<ul style="list-style-type: none"> The ring counter setting in the Controller or the ring counter setting in the Servo Drive settings was changed. The position to restore when converted to pulses exceeded the range of signed 40-bit data. 		Reset the error and perform homing. Perform homing near the position where the absolute encoder is set up so that the position to restore does not exceed the range of signed 40-bit data.		Perform homing again if you changed any parameters related to position, such as the modulo maximum position setting value. Perform homing near the position where the absolute encoder is set up so that the position to restore does not exceed the range of signed 40-bit data. Also, do not execute the MC_Power (Power Servo) instruction or cycle the power supply when the encoder position exceeds the range of signed 40-bit data.	
Attached information	None					
Precautions/Remarks	None					

Event name	Home Undefined during Coordinated Motion			Event code	64590000 hex	
Meaning	Home of the logical axis became undefined during axes group motion or while decelerating to a stop.					
Source	Motion Control Function Module		Source details	Axes group	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The axes group decelerates to a stop.		
System-defined variables	Variable		Data type		Name	
	_MC_GRP[*].MFAultLvl.Active		BOOL		Axes Group Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The command position or actual position overflowed or underflowed for a logical axis in an axes group motion or a logical axis that was decelerating to a stop and the home definition was lost.		Correct the program so that the axis operates within ranges that do not cause overflows or underflows in the command position or actual position.		Write the program so that the axis operates within ranges that do not cause overflows or underflows in the command position or actual position.	
	A slave communications error occurred for a logical axis and home became undefined during axes group motion or while decelerating to a stop.		Correct the slave communications error and define home.		None	
	A slave for a logical axis left the network and home became undefined during axes group motion or while decelerating to a stop.		Connect the disconnected Slave to the network again and define home.		Do not disconnect slaves for logical axes from the network during axes group motions or while decelerating to a stop.	
Attached information	None					
Precautions/Remarks	None					

Event name	Servo Main Circuit Power OFF			Event code	74210000 hex	
Meaning	The main circuit power of the Servo Drive turned OFF while the Servo was ON.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	Whenever Servo is ON
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The Servo for the axis turns OFF.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFAultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The main circuit power of the Servo Drive was interrupted while the Servo was ON.		Turn ON the main circuit power of the Servo Drive for the axis where the error occurred, reset the error, and then turn ON the Servo.		Turn OFF the Servo, then turn OFF the main circuit power of the Servo Drive.	
Attached information	None					
Precautions/Remarks	None					

Event name	Interrupt Feeding Interrupt Signal Missing			Event code	74230000 hex	
Meaning	An interrupt input was not received during execution of an MC_MoveFeed (Interrupt Feeding) instruction.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The relevant axis decelerates to a stop.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFAultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The latch enabled range specification is invalid.		If an invalid latch enabled range is specified to the instruction, correct it.		Specify a correct latch enabled range based on the relationship between the motion and sensor position.	
	There is a problem with the wiring of the interrupt signal.		Correct any problems with the wiring for the interrupt signal for the instruction.		Make sure that the wiring of the interrupt signal is correct.	
	The sensor that outputs the interrupt signal has failed.		If neither of the two causes listed above are applicable, the sensor that outputs the interrupt signal has failed. Replace the sensor that outputs the interrupt signal for the instruction where this error occurred.		None	
Attached information	None					
Precautions/Remarks	None					

Event name	Homing Opposite Direction Limit Input Detected			Event code	74240000 hex	
Meaning	The limit signal in the direction opposite to the homing direction was detected during a homing operation.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The axis stops with the stop method for the homing execution status.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFAultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The Operation Selection at Negative Limit Input or Operation Selection at Positive Limit Input parameter is set to <i>No reverse turn</i> .		To prevent errors at the limit inputs, set the Operation Selection at Negative Limit Input and Operation Selection at Positive Limit Input parameters to <i>Reverse turn</i> .		Check to see if any of the conditions that are given as causes exist in advance.	
	The location of the homing input signal sensors, homing settings, and homing start position cause a limit input to be reached.		Correct the location of the input signal sensors, homing settings, and homing start position so that a limit input is not reached.			
	The input signal sensor wiring is incorrect or the sensor is faulty.		Correct the wiring of the input signal sensor or replace the sensor.			
Attached information	None					
Precautions/Remarks	None					

Event name	Homing Direction Limit Input Detected			Event code	74250000 hex	
Meaning	The limit signal in the homing direction was detected during a homing operation.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The axis stops with the stop method for the homing execution status.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The Operation Selection at Negative Limit Input or Operation Selection at Positive Limit Input parameter is set to <i>No reverse turn</i> .		To prevent errors at the limit inputs, set the Operation Selection at Negative Limit Input and Operation Selection at Positive Limit Input parameters to <i>Reverse turn</i> .		Check to see if any of the conditions that are given as causes exist in advance.	
	The location of the homing input signal sensors, homing settings, and homing start position cause a limit input to be reached.		Correct the location of the input signal sensors, homing settings, and homing start position so that a limit input is not reached.			
	The input signal sensor wiring is incorrect or the sensor is faulty.		Correct the wiring of the input signal sensor or replace the sensor.			
None		None				
Attached information	None					
Precautions/Remarks	None					

Event name	Homing Limit Inputs Detected in Both Directions			Event code	74260000 hex	
Meaning	The limit signals in both directions were detected during a homing operation.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The axis stops with the stop method for the homing execution status.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The wiring of the limit signal is incorrect.		Correct the wiring of the limit signal.		Check to see if any of the conditions that are given as causes exist in advance.	
	The limit sensor is installed in the wrong location.		Correct the installation locations of the limit sensors so that they do not turn ON at the same time.			
	The contact logic of the limit signal is not correct.		Correct the contact logic (N.C./N.O.) of the limit signal.			
	The limit sensor failed.		Replace the limit sensor.			
None		None				
Attached information	None					
Precautions/Remarks	None					

Event name	Home Proximity/Homing Opposite Direction Limit Input Detected		Event code	74270000 hex		
Meaning	The home proximity input and the limit signal in the direction opposite to the homing direction were detected during a homing operation.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The axis stops with the stop method for the homing execution status.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFAultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The wiring of the home proximity signal or limit signal is incorrect.		Correct the wiring of the home proximity signal or limit signal.		Check to see if any of the conditions that are given as causes exist in advance.	
	The home proximity sensor or limit sensor is installed in the wrong location.		Correct the installation location of the home proximity sensor or limit sensor so that they do not turn ON at the same time.			
	The contact logic of the home proximity signal or limit signal is not correct.		Correct the contact logic (N.C./N.O.) of the home proximity sensor or limit sensor.			
	The home proximity sensor or limit sensor failed.		Replace the home proximity sensor or limit sensor.			
Attached information	None					
Precautions/Remarks	None					

Event name	Home Proximity/Homing Direction Limit Input Detected		Event code	74280000 hex		
Meaning	The home proximity input and the limit signal in the homing direction were detected at the same time during a homing operation.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The axis stops with the stop method for the homing execution status.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFAultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The wiring of the home proximity signal or limit signal is incorrect.		Correct the wiring of the home proximity signal or limit signal.		Check to see if any of the conditions that are given as causes exist in advance.	
	The home proximity sensor or limit sensor is installed in the wrong location.		Correct the installation location of the home proximity sensor or limit sensor so that they do not turn ON at the same time.			
	The contact logic of the home proximity signal or limit signal is not correct.		Correct the contact logic (N.C./N.O.) of the home proximity sensor or limit sensor.			
	The home proximity sensor or limit sensor failed.		Replace the home proximity sensor or limit sensor.			
None		None				
Attached information	None					
Precautions/Remarks	None					

Event name	Home Input/Homing Opposite Direction Limit Input Detected		Event code	74290000 hex		
Meaning	The home input and the limit signal in the direction opposite to the homing direction were detected at the same time during a homing operation.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The axis stops with the stop method for the homing execution status.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFAultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The wiring of the home input signal or limit signal is incorrect.		Correct the wiring of the home input signal or limit signal.		Check to see if any of the conditions that are given as causes exist in advance.	
	The home input sensor or limit sensor is installed in the wrong location.		Correct the installation location of the home input sensor or limit sensor so that they do not turn ON at the same time.			
	The contact logic of the home input signal or limit signal is not correct.		Correct the contact logic (N.C./N.O.) of the home input signal or limit sensor.			
	The home input signal output device or limit sensor failed.		Replace the home input signal output device or limit sensor.			
None		None				
Attached information	None					
Precautions/Remarks	None					

Event name	Home Input/Homing Direction Limit Input Detected		Event code	742A0000 hex		
Meaning	The home input and the limit signal in the homing direction were detected at the same time during a homing operation.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The axis stops with the stop method for the homing execution status.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The wiring of the home input signal or limit signal is incorrect.		Correct the wiring of the home input signal or limit signal.		Check to see if any of the conditions that are given as causes exist in advance.	
	The home input sensor or limit sensor is installed in the wrong location.		Correct the installation location of the home input sensor or limit sensor so that they do not turn ON at the same time.			
	The contact logic of the home input signal or limit signal is not correct.		Correct the contact logic (N.C./N.O.) of the home input signal or limit sensor.			
	The home input signal output device or limit sensor failed.		Replace the home input signal output device or limit sensor.			
Attached information	None					
Precautions/Remarks	None					

Event name	Invalid Home Input Mask Distance		Event code	742B0000 hex		
Meaning	The setting of the home input mask distance is not suitable for the MC_Home instruction.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The axis stops with the stop method for the homing execution status.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The set value of the home input mask distance when the operating mode of the MC_Home instruction is set to <i>Proximity Reverse Turn/Home Input Mask Distance</i> is insufficient to decelerate from the homing velocity to the homing approach velocity.		Check the home input mask distance, homing velocity, and homing approach velocity. Change the settings so that they provide sufficient travel distance to decelerate based on the operating specifications of the MC_Home instruction.		Check the operating specifications for the MC_Home instruction, then set the home input mask distance, homing velocity, and homing approach velocity so that they provide sufficient travel distance to decelerate.	
Attached information	None					
Precautions/Remarks	None					

Event name	No Home Input			Event code	742C0000 hex	
Meaning	There was no home signal input during the homing operation. Or, a limit signal was detected before there was a home input.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The axis stops with the stop method for the homing execution status.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFAultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	<ul style="list-style-type: none"> There was no home signal input during the homing operation. A limit signal was detected before there was a home input. 		Check the home input settings and wiring and correct them so that the home signal is input during homing based on the operation specifications of the MC_Home instruction. Also, set the system so that the home signal is detected before the limit signals.		Set the system so that the home signal is input during the homing operation. Make sure that the home signal is detected before a limit signal. Also check to make sure there are no wiring problems with the home input.	
Attached information	None					
Precautions/Remarks	None					

Event name	No Home Proximity Input			Event code	742D0000 hex	
Meaning	There was no home proximity signal input during the homing operation.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The axis stops with the stop method for the homing execution status.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFAultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	There was no home proximity signal input during the homing operation when a home proximity input signal was specified.		Check the home proximity input settings and wiring and correct them so that the home proximity signal is input during homing based on the operation specifications of the MC_Home instruction.		Set the system so that the home proximity signal is input during the homing operation. Also check to make sure there are no wiring problems with the home proximity input.	
Attached information	None					
Precautions/Remarks	None					

Event name	Slave Error Detected			Event code	742F0000 hex	
Meaning	An alarm was detected for the EtherCAT slave that is allocated to an axis.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The Servo for the axis turns OFF.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	An error was detected for the EtherCAT slave that is allocated to the axis.		Check the error at the slave and check the slave error code reported in Slave Error Code Report (94220000 hex) and perform the required corrections.		None	
Attached information	None					
Precautions/Remarks	None					

Event name	Axes Group Composition Axis Error			Event code	74300000 hex	
Meaning	An error occurred for an axis in an axes group.					
Source	Motion Control Function Module		Source details	Axes group	Detection timing	Continuously
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	If an immediate stop is performed for one of the composition axes, operation will follow the setting of the Axes Group Stop Method Selection. Otherwise, an interpolated path stop is performed.		
System-defined variables	Variable		Data type		Name	
	_MC_GRP[*].MFaultLvl.Active		BOOL		Axes Group Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	An error occurred for an axis in an axes group that was in motion.		Check the error code of the axes in the axes group and remove the cause of the error.		None	
Attached information	None					
Precautions/Remarks	When an axis error occurs, any axes group that contains that axis will not operate.					

Event name	MC Common Error Occurrence			Event code	74330000 hex	
Meaning	An MC common error occurred.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	Operation is not possible for relevant axis.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	Partial fault level MC common error occurred.		Check the MC common error that occurred and remove the cause of the error.		None	
Attached information	None					
Precautions/Remarks	When a partial fault level MC common error occurs, the axis and axis group do not operate.					

Event name	Latch Position Overflow			Event code	74340000 hex	
Meaning	An overflow occurred for the latched position for the MC_TouchProbe (Enable External Latch) instruction.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The relevant axis decelerates to a stop. The Enable External Latch instruction cannot retrieve the latch position.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	An overflow occurred for the latched position for the MC_TouchProbe (Enable External Latch) instruction.		Correct the program so that the axis position does not overflow.		Write the program so that the axis position does not overflow.	
Attached information	None					
Precautions/Remarks	None					

Event name	Latch Position Underflow			Event code	74350000 hex	
Meaning	An underflow occurred for the latched position for the MC_TouchProbe (Enable External Latch) instruction.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The axis decelerates to a stop. The Enable External Latch instruction cannot retrieve the latch position.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	An underflow occurred for the latched position for the MC_TouchProbe (Enable External Latch) instruction.		Correct the program so that the axis position does not underflow.		Write the program so that the axis position does not underflow.	
Attached information	None					
Precautions/Remarks	None					

Event name	Master Sync Direction Error			Event code	74360000 hex	
Meaning	The master axis continued to move in the direction opposite to the sync direction.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The axis decelerates to a stop.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The master axis continued to move in the direction opposite to the sync direction of the master and slave axes, resulting in an overflow.		Correct the program so that the movement direction and travel distance of the master axis are in the sync direction after the start of synchronization.		Write the program so that the movement direction and travel distance of the master axis is the sync direction after the start of synchronization.	
Attached information	None					
Precautions/Remarks	None					

Event name	Slave Disconnection during Servo ON			Event code	74370000 hex	
Meaning	An EtherCAT slave that is allocated to an axis was disconnected while the servo was ON.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	Whenever Servo is ON
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The Servo for the axis turns OFF.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	An EtherCAT slave that is allocated to an axis was disconnected or replaced while the Servo was ON.		Reconnect the EtherCAT slave that is allocated to the axis to the network.		Turn OFF the Servo before you disconnect or replace a slave.	
Attached information	None					
Precautions/Remarks	None					

Event name	Feed Distance Overflow			Event code	74380000 hex	
Meaning	The target position after the interrupt input was received for the MC_MoveFeed (Interrupt Feeding) instruction overflowed or underflowed.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The axis decelerates to a stop.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The target position after the interrupt input was received for the MC_MoveFeed (Interrupt Feeding) instruction exceeded the range of signed 40-bit data when converted to pulses.		Correct the input value for the command position in the program. The target value after the interrupt input is received must not exceed the valid range for the number of pulses when it is converted to pulses.		Write the program correctly. The input value for the command position must not cause the target value after the interrupt input is received to exceed the valid range. The valid range is signed 40-bit data for the number of pulses when the target value is converted to pulses.	
Attached information	None					
Precautions/Remarks	None					

Event name	Error in Changing Servo Drive Control Mode			Event code	74390000 hex	
Meaning	Changing the Control Mode was not completed within the specified time.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The Servo for the axis turns OFF.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	

Cause and correction	Assumed cause	Correction	Prevention
	When the MC_SyncMoveVelocity instruction was stopped, the actual current velocity was not reduced to 10% or less of the maximum velocity within 10 seconds for three consecutive periods after a command velocity of 0 was output.	Adjust the commands and load so that an error does not occur.	Adjust the commands and load so that an error does not occur.
	For an OMRON G5-series Servo Drive, the actual current velocity was not reduced to 10% or less of the maximum velocity within 10 seconds for three consecutive periods when the MC_TorqueControl instruction was stopped.		
	Changing the Control Mode of the Servo Drive between CSP, CSV, and CST was not completed within one second after the command was executed.	Check to see if there is an error in the Servo Drive and to see if settings are correct. Correct any problems that are found.	Make sure that there are no errors in the Servo Drives and make sure that the settings are correct.
Attached information	None		
Precautions/Remarks	None		

Event name	Master Axis Position Read Error		Event code	743A0000 hex		
Meaning	The synchronized instruction was not executed because an error occurred in the position of the master axis of the synchronized instruction.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	At or during instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	Operation is not possible for relevant slave axis. Relevant slave axis decelerates to a stop if it is in motion.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	EtherCAT process data communications are not established for the master axis of the synchronized instruction.		If the <i>_EC_PDSlavTbl</i> (Process Data Communicating Slave Table) system-defined variable for the EtherCAT master of the master axis is FALSE, investigate the error in the master axis and remove the cause.		If you execute synchronized instructions after you turn ON the power supply, download data, or reset slave communications error, make sure that the <i>_EC_PDSlavTbl</i> (Process Data Communicating Slave Table) system-defined variable for the EtherCAT master is TRUE for the node of the master axis before you execute the synchronized instruction.	
	The slave of the master axis for the synchronized instruction was disconnected.		Check the slave of the master axis and reconnect it if it was disconnected.		Make sure that the slave of the master axis is not disconnected during execution of a synchronized instruction.	
	An Absolute Encoder Current Position Calculation Failed error (6458000 hex) was detected for the master axis of a synchronized instruction.		See if an Absolute Encoder Current Position Calculation Failed error (64580000 hex) occurred for the master axis and make suitable corrections to restore operation.		Do not use an axis with an Absolute Encoder Current Position Calculation Failed error (64580000 hex) as the master axis in a synchronized instruction.	
Attached information	None					
Precautions/Remarks	None					

Event name	Auxiliary Axis Position Read Error			Event code	743B0000 hex	
Meaning	The synchronized instruction was not executed because an error occurred in the position of the auxiliary axis of the synchronized instruction.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	At or during instruction execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	Operation is not possible for relevant slave axis. Relevant slave axis decelerates to a stop if it is in motion.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFAultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	EtherCAT process data communications are not established for the auxiliary axis of the synchronized instruction.		If the <code>_EC_PDslavTbl</code> (Process Data Communicating Slave Table) system-defined variable for the EtherCAT master of the auxiliary axis is FALSE, investigate the error in the auxiliary axis and remove the cause.		If you execute synchronized instructions after you turn ON the power supply, download data, or reset slave communications error, make sure that the <code>_EC_PDslavTbl</code> (Process Data Communicating Slave Table) system-defined variable for the EtherCAT master is TRUE for the node of the auxiliary axis before you execute the synchronized instruction.	
	The slave of the auxiliary axis for the synchronized instruction was disconnected.		Check the slave of the auxiliary axis and reconnect it if it was disconnected.		Make sure that the slave of the auxiliary axis is not disconnected during execution of a synchronized instruction.	
	An Absolute Encoder Current Position Calculation Failed error (6458000 hex) was detected for the auxiliary axis of a synchronized instruction.		See if an Absolute Encoder Current Position Calculation Failed error (64580000 hex) occurred for the auxiliary axis and make suitable corrections to restore operation.		Do not use an axis with a Absolute Encoder Current Position Calculation Failed error (64580000 hex) as the auxiliary axis in a synchronized instruction.	
Attached information	None					
Precautions/Remarks	None					

Event name	EtherCAT Slave Communications Error			Event code	84400000 hex	
Meaning	A communications error occurred for the EtherCAT slave that is allocated to an axis.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The Servo for the axis turns OFF.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFAultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	A communications error occurred for the EtherCAT slave that is allocated to an axis.		Check the event log for the EtherCAT error that occurred. Remove the cause of the error and clear the relevant error.		None	
Attached information	None					
Precautions/Remarks	Even if this error is reset, the error in the EtherCAT Master Function Module is not reset. This error can be reset without resetting the error in the EtherCAT Master Module, but the axis will still be disabled.					

Event name	Following Error Warning			Event code	644C0000 hex	
Meaning	The following error exceeded the Following Error Warning Value.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Observation	Recovery	---	Log category	System
Effects	User program	Continues.	Operation	Not affected.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].Obsr.Active		BOOL		Axis Observation Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	Performance of positioning operation is poor and the actual motion is slower than the command.		Remove the cause of poor following performance in the positioning operation. Or increase the Following Error Warning Value within the range that will not create problems.		Remove the cause of poor following performance in the positioning operation much as possible.	
Attached information	None					
Precautions/Remarks	None					

Event name	Velocity Warning			Event code	644D0000 hex	
Meaning	The command velocity exceeded the velocity warning value.					
Source	Motion Control Function Module		Source details	Axis/axes group	Detection timing	During instruction execution
Error attributes	Level	Observation	Recovery	---	Log category	System
Effects	User program	Continues.	Operation	Not affected.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].Obsr.Active		BOOL		Axis Observation Occurrence	
	_MC_GRP[*].Obsr.Active		BOOL		Axes Group Observation Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The command velocity exceeded the velocity warning value.		Find the reason the velocity warning value was exceeded and make suitable corrections. Or increase the Velocity Warning Value within the range that will not create problems.		(The goal is to enable detecting when the velocity warning value is exceeded. Preventative measures are not required.)	
Attached information	None					
Precautions/Remarks	None					

Event name	Acceleration Warning			Event code	644E0000 hex	
Meaning	The command acceleration exceeded the acceleration warning value.					
Source	Motion Control Function Module		Source details	Axis/axes group	Detection timing	During instruction execution
Error attributes	Level	Observation	Recovery	---	Log category	System
Effects	User program	Continues.	Operation	Not affected.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].Obsr.Active		BOOL		Axis Observation Occurrence	
	_MC_GRP[*].Obsr.Active		BOOL		Axes Group Observation Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The command acceleration rate exceeded the acceleration warning value.		Find the reason the acceleration warning value was exceeded and make suitable corrections. Or increase the Acceleration Warning Value within the range that will not create problems.		(The goal is to enable detecting when the acceleration warning value is exceeded. Preventative measures are not required.)	
Attached information	None					
Precautions/Remarks	None					

Event name	Deceleration Warning			Event code	644F0000 hex	
Meaning	The command deceleration exceeded the deceleration warning value.					
Source	Motion Control Function Module		Source details	Axis/axes group	Detection timing	During instruction execution
Error attributes	Level	Observation	Recovery	---	Log category	System
Effects	User program	Continues.	Operation	Not affected.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].Obsr.Active		BOOL		Axis Observation Occurrence	
	_MC_GRP[*].Obsr.Active		BOOL		Axes Group Observation Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The command deceleration rate exceeded the deceleration warning value.		Find the reason the deceleration warning value was exceeded and make suitable corrections. Or increase the Deceleration Warning Value within the range that will not create problems.		(The goal is to enable detecting when the deceleration warning value is exceeded. Preventative measures are not required.)	
Attached information	None					
Precautions/Remarks	None					

Event name	Positive Torque Warning			Event code	64500000 hex	
Meaning	The torque command value exceeded the positive torque warning value.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Observation	Recovery	---	Log category	System
Effects	User program	Continues.	Operation	Not affected.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].Obsr.Active		BOOL		Axis Observation Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The torque command value exceeded the positive torque warning value.		Find the reason the torque warning value was exceeded and make suitable corrections. Or increase the Positive Torque Warning Value within the range that will not create problems.		(The goal is to enable detecting when the torque warning value is exceeded. Preventative measures are not required.)	
Attached information	None					
Precautions/Remarks	None					

Event name	Negative Torque Warning			Event code	64510000 hex	
Meaning	The torque command value exceeded the negative torque warning value.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruction execution
Error attributes	Level	Observation	Recovery	---	Log category	System
Effects	User program	Continues.	Operation	Not affected.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].Obsr.Active		BOOL		Axis Observation Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The torque command value exceeded the negative torque warning value.		Find the reason the torque warning value was exceeded and make suitable corrections. Or increase the Negative Torque Warning Value within the range that will not create problems.		(The goal is to enable detecting when the torque warning value is exceeded. Preventative measures are not required.)	
Attached information	None					
Precautions/Remarks	None					

Event name	Command Position Overflow			Event code	64520000 hex	
Meaning	The number of pulses for the command position overflowed.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously
Error attributes	Level	Observation	Recovery	---	Log category	System
Effects	User program	Continues.	Operation	The position is not updated, but motion continues.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].Obsr.Active		BOOL		Axis Observation Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	In Linear Mode, the command position when converted to pulses exceeded the upper limit of signed 40-bit data.		Correct the program so that the input value for the command position does not exceed the range for the number of pulses for the instruction. Or, change the electronic gear ratio settings. To recover from the overflow, change the current position or perform the homing operation.		Check the gear ratio setting and the target position setting value, and make sure that the converted number of pulses does not exceed the range of signed 40-bit data.	
Attached information	None					
Precautions/Remarks	None					

Event name	Command Position Underflow			Event code	64530000 hex	
Meaning	The number of pulses for the command position exceeded the valid range. (It underflowed.)					
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously
Error attributes	Level	Observation	Recovery	---	Log category	System
Effects	User program	Continues.	Operation	The position is not updated, but motion continues.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].Obsr.Active		BOOL		Axis Observation Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	In Linear Mode, the command position when converted to pulses exceeded the lower limit of signed 40-bit data.		Correct the program so that the input value for the command position does not exceed the pulse number limit for the instruction. Or, change the electronic gear ratio settings. To recover from the underflow, change the current position or perform the homing operation.		Check the gear ratio setting and the target position setting value, and make sure that the converted number of pulses does not exceed the range of signed 40-bit data.	
Attached information	None					
Precautions/Remarks	None					

Event name	Actual Position Overflow			Event code	64540000 hex	
Meaning	The number of pulses for the actual position overflowed.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously
Error attributes	Level	Observation	Recovery	---	Log category	System
Effects	User program	Continues.	Operation	The position is not updated, but motion continues.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].Obsr.Active		BOOL		Axis Observation Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The actual position when converted to pulses exceeded the upper limit of signed 40-bit data.		Correct the program so that the target position is well within the pulse number limit so that the actual position does not exceed the pulse number limit for the instruction. Or, change the electronic gear ratio settings. To recover from the overflow, change the current position or perform the homing operation.		Check the gear ratio setting and the target position setting value, and make sure that the converted number of pulses does not exceed the range of signed 40-bit data. Allow some leeway.	
Attached information	None					
Precautions/Remarks	None					

Event name	Actual Position Underflow			Event code	64550000 hex	
Meaning	The number of pulses for the actual position underflowed.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously
Error attributes	Level	Observation	Recovery	---	Log category	System
Effects	User program	Continues.	Operation	The position is not updated, but motion continues.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].Obsr.Active		BOOL		Axis Observation Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	The actual position when converted to pulses exceeded the lower limit of signed 40-bit data.		Correct the program so that the target position is well within the pulse number limit so that the actual position does not exceed the pulse number limit for the instruction. Or, change the electronic gear ratio settings. To recover from the underflow, change the current position or perform the homing operation.		Check the gear ratio setting and the target position setting value, and make sure that the converted number of pulses does not exceed the range of signed 40-bit data. Allow some leeway.	
Attached information	None					
Precautions/Remarks	None					

Event name	Slave Observation Detected			Event code	74320000 hex	
Meaning	A warning has been detected for an EtherCAT slave.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously
Error attributes	Level	Observation	Recovery	---	Log category	System
Effects	User program	Continues.	Operation	Not affected.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].Obsr.Active		BOOL		Axis Observation Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	A warning was detected for the Ether-CAT slave that is allocated to the axis.		Check the warning code for the Ether-CAT slave and remove the cause of the warning.		None	
Attached information	Attached information 1: Drive warning code					
Precautions/Remarks	None					

Event name	Cannot Execute Save Cam Table Instruction			Event code	743C0000 hex	
Meaning	You cannot save a cam table to a file when non-volatile memory is being accessed by another operation.					
Source	Motion Control Function Module		Source details	MC Common	Detection timing	At instruction execution
Error attributes	Level	Observation	Recovery	---	Log category	System
Effects	User program	Continues.	Operation	Not affected.		
System-defined variables	Variable		Data type		Name	
	_MC_COM.Obsr.Active		BOOL		MC Common Observation Active	
Cause and correction	Assumed cause		Correction		Prevention	
	An attempt was made to execute the MC_SaveCamTable instruction when another operation was accessing the non-volatile memory (e.g., transfer or data trace operation from the Sysmac Studio).		Execute the MC_SaveCamTable instruction again.		None	
Attached information	None					
Precautions/Remarks	None					

Event name	Notice of Insufficient Travel Distance to Achieve Blending Transit Velocity		Event code	94200000 hex		
Meaning	There is not sufficient travel distance to accelerate or decelerate to the transit velocity during blending operation.					
Source	Motion Control Function Module		Source details	Axis/axes group	Detection timing	At multi-execution of instructions
Error attributes	Level	Observation	Recovery	---	Log category	System
Effects	User program	Continues.	Operation	Not affected.		
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].Obsr.Active		BOOL		Axis Observation Occurrence	
	_MC_GRP[*].Obsr.Active		BOOL		Axes Group Observation Occurrence	
Cause and correction	Assumed cause		Correction		Prevention	
	When the Acceleration/Deceleration Over parameter was set to <i>Use rapid acceleration/deceleration (Blending is changed to Buffered)</i> , the results of profile creation caused the acceleration/deceleration rate to be exceeded when blending was specified, so buffered was used.		Set the Acceleration/Deceleration Over parameter to a value other than <i>Use rapid acceleration/deceleration (Blending is changed to Buffered)</i> if you do not want to change to Buffered operation.		Set the Acceleration/Deceleration Over parameter to a value other than <i>Use rapid acceleration/deceleration (Blending is changed to Buffered)</i> if you do not want to change to Buffered operation.	
	Blending was specified, but the target position was already reached, so it was changed to Buffered because the profile could not be created.		If unanticipated operation occurs from the switch to <i>Buffered</i> operation, correct the program so that the causes given at the left do not occur.		If unanticipated operation would occur from the switch to <i>Buffered</i> operation, write the program so that the causes given at the left do not occur.	
	<i>Blending</i> was specified for an interpolation instruction, but based on the results of profile creation, this was changed to <i>Buffered</i> because the execution time of the instruction before the transition was four control periods or less.					
Attached information	None					
Precautions/Remarks	None					

Event name	Error Clear from MC Test Run Tab Page		Event code	94210000 hex		
Meaning	An error was cleared from the MC Test Run Pane of the Sysmac Studio.					
Source	Motion Control Function Module		Source details	MC common	Detection timing	When MC Test Run error is reset
Error attributes	Level	Information	Recovery	---	Log category	System
Effects	User program	Continues.	Operation	Not affected.		
System-defined variables	Variable		Data type		Name	
	None		---		---	
Cause and correction	Assumed cause		Correction		Prevention	
	An error was cleared from the MC Test Run Pane of the Sysmac Studio.		---		---	
Attached information	Attached information 1: Execution results (0000_0000 hex: All errors reset, 0000_0001 hex: Resetting all errors failed)					
Precautions/Remarks	None					

Event name	Slave Error Code Report			Event code	94220000 hex	
Meaning	The error code was reported by the slave when a Slave Error Detected error occurred.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	After Slave Error Detected error (742F0000 hex)
Error attributes	Level	Information	Recovery	---	Log category	System
Effects	User program	Continues.	Operation	Not affected.		
System-defined variables	Variable		Data type		Name	
	None		---		---	
Cause and correction	Assumed cause		Correction		Prevention	
	The error code was reported by the slave when a Slave Error Detected error (742F0000 hex) occurred.		This error accompanies a Slave Error Detected error (742F0000 hex). Check the slave error code in the attached information and make the required corrections.		None	
Attached information	Attached information 1: Slave error code					
Precautions/Remarks	None					

11-2-3 Error Causes and Remedies

This section describes remedial actions to take when problems occur the first time you use the MC Function Module or after starting operation.

Preliminary Check Items

If an error occurs, check the items below to investigate the problem.

Category	Item to check
Installation conditions	Is there dust in the ambient environment?
	Are there conductive foreign matters (metal, carbon, etc.) in the ambient environment that might enter the Controller?
	Is the ambient temperature higher than the ambient operating temperature in the specifications?
	Is the ambient area humid (due to moisture in the air, use of water, etc.)?
	Does the ambient air contain corrosive gases (acid, salt, sulfur, etc.)?
	Are there sources of noise around the Controller (welders, inverters, etc.)?
Wiring	Are power supply lines wired in the same duct as the signal lines?
	Is the Controller grounded properly?
	Is there a noise filter in the power supply?
Changes	Was any extension work (welding work) done lately?
	Was any power supply facility added lately?
	Was the system (including its program) modified in any way (including additions)?
Accidents	Was there a lightning strike nearby?
	Was there a ground-fault accident or was the earth leakage breaker tripped?
	Was there a power outage?

Problems and Countermeasures

This section describes troubleshooting when the MC Function Module is used in combination with an OMRON G5-series Servo Drive. If an unexpected operation is performed, data such as parameter settings or cam data may not have been transferred properly to the CPU Unit from the Sysmac Studio. Furthermore, variables may not be working properly between the user program and the MC Function Module. Use the data tracing function of Sysmac Studio to check if variables are exchanged at the correct timings.

Problem	Cause	Item to check	Countermeasure
Motor does not lock.	The MC Function Module does not output operation commands to the Servo Drive.	Make sure that you execute the MC_Power instruction.	Correct the program.
	Servo Drive setting error	Check the Servo Drive settings.	Set the Servo Drives correctly.
Motor does not run.	The drive prohibit input of the Servo Drive is enabled.	Use the Servo Drive software to check the drive prohibit input.	Cancel the drive prohibit input of the Servo Drive. Change the setting so that you do not use the drive prohibit input of the Servo Drive.
	Servo Drive error	Check for a Servo Drive error.	If there is an error, follow troubleshooting procedures for it.
	Mechanical axis is locked.	Check for contact with mechanical limits and check to see if mechanical parts are caught on something.	Manually release the locked mechanical axis.
	CPU Unit failure	---	Replace the CPU Unit.

Problem	Cause	Item to check	Countermeasure
Homing cannot be performed.	Error	Check the nature of the error.	If there is an error, follow troubleshooting procedures for it.
	Incorrect wiring of the home proximity input.	Check the axis input information in the Axis Variables to see if the home proximity input sensor turns ON/OFF.	Wire all connections correctly.
	Incorrect wiring of the home input.	Check the wiring of the home input.	Wire all connections correctly.
	The rotation direction and limit input direction are inconsistent.	If the axis moves to the mechanical limit without reversing at the limit, check the axis input information in the Axis Variables to see if the limit input turns ON and OFF.	Wire the limit inputs correctly.
	Incorrect wiring of the limit input	Check the wiring of the limit inputs.	Wire all connections correctly.
	<i>InPosWaiting</i> does not change to FALSE	Check to see if the Servo Drive gain is too low. Check to see if the in-position range is too narrow.	Increase the Servo Drive gain. Increase the in-position range.
	Homing approach velocity is too high.	Check the homing approach velocity.	Lower the homing approach velocity of the MC Function Module.
	Axis parameters are not set correctly.	Check the axis parameters in the Sysmac Studio.	After setting the axis parameters correctly, download them to the MC Function Module.
	CPU Unit failure	---	Replace the CPU Unit.
The position of home defined with homing changes occasionally.	Loose mechanical parts, such as couplings	Use a marker pen to mark the motor shafts, couplings, and other mechanical connections to check for shifting.	Securely tighten the connections that shifted.
	Insufficient leeway for Z phase Insufficient leeway for home input signal	If the value is close to the setting per Servomotor rotation (number of pulses per encoder rotation) or near zero, the home may be shifted by one motor rotation due to slight changes in the timing of reading the sensor input.	Remove the motor coupling and shift the position by around one-quarter of a turn so that the Z phase pulse occurs at around one half of a Servomotor rotation (number of pulses per encoder rotation), and then perform homing again.

Problem	Cause	Item to check	Countermeasure
Unstable motor rotation	Incorrect wiring of Servomotor power line/encoder line, missing phase, etc.	Check the wiring of the motor power line and encoder line.	Wire all connections correctly.
	Load torque variation due to gear meshing or not tightening the coupling eccentric screw connecting the motor axis with the mechanical system	Check the machine. Turn the coupling under a no-load condition (with the mechanical part after the coupling removed).	Review and adjust the machine.
	Insufficient gain adjustment	---	Perform auto-tuning of the Servomotor. Manually adjust the Servomotor gain.
	Incorrect Servomotor selection (adjustment not possible)	Select another motor (check the torque and inertia ratio).	Change to an optimal motor.
	Damaged Servomotor bearings	Turn OFF the Servo Drive power supply, and also turn ON the brake power supply and release the brake if the motor comes with a brake. Then manually turn the motor output shaft with the motor power line disconnected (because the dynamic brake may be applied).	Replace the Servomotor.
	Broken Servomotor winding	Use a tester to check the resistance between phases U, V, and W of the motor power line. If the balance is off, there is a problem.	Replace the Servomotor.
Rotation direction is reversed.	The Servo Drive is set to the opposite rotation direction.	Jog the machine. If the rotation direction of the Servo Drive is opposite the jogging direction, the rotation direction of the Servo Drive is reversed. Also check for reversed feedback signals (phases A and B) and reverse rotation setting of the parameter.	Set the rotation direction of the Servo Drive correctly.
	(During homing) The axis parameters that set the polarity of the home proximity sensor and the polarity of the home proximity input do not match.	Check the axis parameters and sensor polarity again.	Set the correct axis parameters.
	(During homing) Incorrect wiring of the home proximity input	Check the axis input information in the Axis Variables to see if the home proximity input sensor turns ON/OFF.	Wire the home proximity input correctly.

Problem	Cause	Item to check	Countermeasure
Operation cannot be started, positioning is not completed, or positioning takes too much time to complete.	The in-position range of the Servo Drive is too narrow, and thus the current position does not enter the in-position range. (The current operation does not complete until the current position enters the in-position range, so you cannot start the next motion.)	---	Increase the in-position range.
	Servo Drive gain is low.	---	Adjust the Servo Drive gain.
	The axis does not remain in the in-position range due to an external force.	Check the axis input information for the Axis Variables to see if the difference between the command current position and the actual current position is within the in-position range.	If you stop the axis so that a position inside the in-position range is not achieved, such as holding control, you can use the following error reset output to forcibly achieve the in-position range.
Abnormal noise	Mechanical vibration	Check the moving parts of the machine for intrusion of foreign matter, damage, deformation, and loosening.	Correct the problem.
	Insufficient adjustment of the Servo Drive gain (high gain)	---	Perform auto-tuning. Manually lower the gain.
	Incorrect Servomotor selection (adjustment not possible).	Select another motor (check the torque and inertia ratio).	Change to an optimal motor.
	Misalignment of the coupling that connects the motor shaft and machine	---	Adjust the motor and machine installation.
Motor shaft shakes.	Insufficient adjustment of the gain (low gain)	---	Perform auto-tuning. Manually increase the gain.
	Gain cannot be adjusted due to low machine rigidity.	In particular, this condition occurs on vertical axes, SCARA robots, palletizers, and other systems whose axes are subject to bending or tensional loads.	Increase the machine rigidity. Readjust the gain.
	Mechanical configuration prone to stick slip (highly sticky static friction)	---	Perform auto-tuning. Manually adjust the gain.
	Incorrect Servomotor selection (adjustment not possible)	Select an appropriate motor (check the torque and inertia ratio).	Change to an optimal motor.
	Failure	---	Replace the Servo Drive. Replace the Servomotor.

Problem	Cause	Item to check	Countermeasure
Position shift	The home position was already shifted before positioning.	Refer to <i>The position of home defined with homing changes occasionally.</i>	Refer to <i>The position of home defined with homing changes occasionally.</i>
	Malfunction due to noise from a welder, inverter, etc.	Check if a welder, inverter, or other similar device is located nearby.	Isolate the Controller from any nearby welders, inverters, etc.
	Mechanical shift	Check if dimensional shifts accumulated. (Mark the mechanical connections to check for shifting.)	Securely tighten the mechanical tightening points.
An MC Test Run is not possible from the Sysmac Studio.	An MC Test Run is being executed from another installation of the Sysmac Studio	Check to see if there is another installation of the Sysmac Studio connected to the same CPU Unit.	End all MC Test Run operation for other installations of the Sysmac Studio.

App

Appendices

This section describes settings and connection methods for OMRON G5-series Servo Drive objects.

A-1	Connecting the Servo Drive	A-2
A-1-1	Wiring the Servo Drive	A-2
A-1-2	Servo Drive Settings	A-2
A-2	Connecting to Encoder Input Terminals	A-11
A-2-1	Wiring to Encoder Input Terminals	A-11
A-2-2	Settings for Encoder Input Terminals	A-11
A-3	Terminology	A-15
A-3-1	NJ-series Controller	A-15
A-3-2	Motion Control	A-16
A-3-3	EtherCAT Communications	A-17

A-1 Connecting the Servo Drive

This appendix describes connections to an OMRON G5-series Servo Drive with Built-in EtherCAT Communications.

A-1-1 Wiring the Servo Drive

Servo Drives are connected using EtherCAT communications. Refer to the *NJ-series CPU Unit Built-in EtherCAT Port User's Manual* (Cat. No. W505) for information on the connection methods.

A-1-2 Servo Drive Settings

This section outlines the Servo Drive settings that are used when connected to OMRON G5-series Servo Drives with Built-in EtherCAT Communications (i.e., the applicable Servo Drives for the MC Function Module). Refer to the *G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications User's Manual* (Cat. No. I576) for details on the Servo Drives.

Recommended Servo Drives

All of the functions of the MC Function Module can be used for Servo Drives with the unit versions that are given in the following table.

Manufacturer	Compatible models	Applicable unit versions
OMRON	R88D-KN □□□ -ECT	Unit version 2.1 or later



Additional Information

- You can also use unit versions of the OMRON G5-series Servo Drives with Built-in EtherCAT Communications other than the recommended unit versions.
- The R88D-KN□□□-ECT-R (unit version 1.0) Servo Drives support only position control (Cyclic Synchronous Position Control Mode). You can use them for applications that do not require velocity control (Cyclic Synchronous Velocity Control Mode) or torque control (Cyclic Synchronous Torque Control Mode).
Refer to the *G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications User's Manual* (Cat. No. I573) for details on functions.
- When you use an OMRON G5-series Servo Drive with unit version 2.0 or earlier, do not set the node address switches to 00. If you set them to 00, a network configuration error occurs.
- Refer to the *G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications User's Manual* (Cat. No. I576) for details on the differences between the unit versions of the OMRON G5-series Servo Drives.

Assigning External Input Signals

The MC Function Module uses the following input signals of the Servo Drives.

- Immediate stop input
- Positive limit input
- Negative limit input
- Home proximity input
- External latch trigger signals (latch input 1 and latch input 2)

● Assigning Positive Limit Inputs, Negative Limit Inputs, and Home Proximity Input

The default settings of the input signals of a G5-series Servo Drive are listed in the following table.

Signal name	Input signal
Immediate stop input	Servo Drive general-purpose input 1 (IN1: pin 5 on connector CN1, NC)
Positive limit input	Servo Drive general-purpose input 2 (IN2: pin 7 on connector CN1, NC) ^{*1}
Negative limit input	Servo Drive general-purpose input 3 (IN3: pin 8 on connector CN1, NC) ^{*2}
Home proximity input	General-purpose input 4 (IN4: pin 9 on connector CN1, NO)

*1 The signal name for the Servo Drive is the positive drive prohibit input.

*2 The signal name for the Servo Drive is the negative drive prohibit input.

● Trigger Signal Assignments for External Latches

The input signals in the following table are assigned to external latch trigger signals by default for the G5-series Servo Drive.

Settings for the <i>TriggerInput</i> (Trigger Input Condition) input variable of the MC_TouchProbe instruction			External latch trigger signal
Mode	InputDrive	LatchID	
0:mcDrive	0:mcEncoderMark	---	Encoder Z phase
	1:mcEXT	1:mcLatch1	Servo Drive general-purpose input 7 (IN7: pin 12 on connector CN1, NO) ^{*1}
		2:mcLatch2	Servo Drive general-purpose input 6 (IN6: pin 11 on connector CN1, NO) ^{*2}
1:mcController	---	---	Variable specified by <i>TriggerVariable</i>

*1 The signal name for the Servo Drive is the external latch input 1.

*2 The signal name for the Servo Drive is the external latch input 2.

Backlash Compensation

The MC Function Module does not perform backlash compensation.

If you require backlash compensation, use the compensation function of the Servo Drive.

The objects that must be set on the Servo Drive are listed in the following table.

Index	Name	Description
3704 hex	Backlash Compensation Selection	This object is used to select whether to enable or disable backlash compensation during position control, and to set the compensation direction. The default value is to disable compensation.
3705 hex	Backlash Compensation Amount	Set the backlash compensation amount during position control.
3706 hex	Backlash Compensation Time Constant	Set the backlash compensation time constant during position control.

Refer to the *G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications User's Manual* (Cat. No. I576) for details on backlash compensation.


PDO Mapping

This section describes mapping PDOs to control servo axes from the MC Function Module.

To use motion control functions, you must map the objects that are required for those functions to PDOs.

The PDO map is a list of required objects that is prepared in advance.

You select the PDOs to use in the Edit PDO Map Settings Dialog Box of the EtherCAT Edit Tab Page in the Sysmac Studio.



The following PDOs are mapped by default in the Sysmac Studio.

RxPDO (1704 hex)	Controlword (6040 hex), Target Position (607A hex), Target Velocity (60FF hex), Target Torque (6071 hex), Modes of Operation (6060 hex), Touch Probe Function (60B8 hex), Max Profile Velocity (607F hex), Positive Torque Limit Value (60E0 hex), and Negative Torque Limit Value (60E1 hex)
TxPDO (1B02 hex)	Error Code(603F hex), Status Word (6041 hex), Position Actual Value (6064 hex), Torque Actual Value (6077 hex), Modes of Operation Display (6061 hex), Touch Probe Status (60B9 hex), Touch Probe Pos1 Pos Value (60BA hex), Touch Probe Pos2 Pos Value (60BC hex), and Digital Inputs (60FD hex)




Additional Information

If you use the recommended Servo Drives (OMRON R88D-KN□□□-ECT, version 2.1 or higher), then it is not necessary to change the default PDO map on the Sysmac Studio.

Relationships between MC Function Module and Process Data

The functions of the MC Function Module are related to the information in the process data objects. Depending on the EtherCAT slave configuration and functions that are used by the MC Function Module, you sometimes must change the relationships between the MC Function Module and the PDOs.

To access the settings, click the **Detailed Settings** Button on the Axis Basic Settings Tab Page in the Sysmac Studio.



Additional Information

If you use the recommended Servo Drives (OMRON R88D-KN□□□-ECT, version 2.1 or higher), then it is not necessary to change the default relationships between MC Function Module functions and the PDOs on the Sysmac Studio.

● Output Settings (Controller to Servo Drive)

The input settings apply to the command data that is sent from the MC Function Module to the Servo Drive. The default settings in the Sysmac Studio are listed in the following table. (Required objects are marked with a star.)

Function name	Process data	Description
★ Control word	6040 hex-00.0 (Controlword)	This data is used to control the status of the Servo Drive. Set 6040 hex: Controlword.
★ Target position	607A hex-00.0 (Target position)	The target position for position control. Set 607A hex: Target position.
Target velocity	60FF hex-00.0 (Target velocity)	The target velocity for velocity control. This object is necessary to output to the Servo Drive in Cyclic Synchronous Velocity Control Mode by the MC_SyncMoveVelocity (Cyclic Synchronous Velocity Control) and other instructions. Normally set 60FF hex: Target velocity.

Function name	Process data	Description
Target torque	6071 hex-00.0 (Target torque)	The target torque for torque control. This object is necessary to output to the Servo Drive in Cyclic Synchronous Torque Control Mode by the MC_TorqueControl (Torque Control) and other instructions. Normally set <i>6071 hex: Target torque.</i>
Maximum profile velocity	607F hex-00.0 (Max profile velocity)	The velocity limit value for torque control. This object is necessary for velocity control in Cyclic Synchronous Torque Control Mode by the MC_TorqueControl (Torque Control) and other instructions. Normally set <i>607F hex: Max profile velocity.</i>
Modes of operation	6060 hex-00.0 (Modes of operation)	This data is required to change the control mode. This object is necessary to change to a control mode other than Cyclic Synchronous Position Control Mode for the MC_SyncMoveVelocity (Cyclic Synchronous Velocity Control), MC_TorqueControl, and other instructions. Normally set <i>606C hex: Modes of operation.</i>
Positive torque limit value	60E0 hex-00.0 (Positive torque limit value)	This is the torque limit value in the positive direction. This object is necessary to control the output torque of the Servo Drive by the MC_SetTorqueLimit and other instructions. Normally set <i>60E0 hex: Positive torque limit value.</i>
Negative torque limit value	60E1 hex-00.0 (Negative torque limit value)	This is the torque limit value in the negative direction. This object is necessary to control the output torque of the Servo Drive by the MC_SetTorqueLimit and other instructions. Normally set <i>60E1 hex: Negative torque limit value.</i>
Touch probe function	60B8 hex-00.0 (Touch probe function)	This data is used to control the touch probe function. It is required for the touch probe function for the MC_Home, MC_MoveFeed (Interrupt Feeding), MC_TouchProbe (Enable External Latch), MC_MoveLink (Synchronous Positioning), and other instructions. Normally set <i>60B8 hex: Touch probe function.</i>



Precautions for Correct Use

- Some functions may not be supported if you connect unit versions of the OMRON G5-series Servo Drives with Built-in EtherCAT Communications other than the recommended unit versions. Refer to the manual for the connected servo drive for details.
- If you change the settings, make sure that the desired operations are performed for the MC Function Module and process data settings.

● **Input Settings (Servo Drive to Controller)**

This is the status data from the Servo Drive to the MC Function Module. The default settings in the Sysmac Studio are listed in the following table. (Required objects are marked with a star.)

Function name	Process data	Description
★ Status word	6041 hex-00.0 (Statusword)	The status of the Servo Drive. Set <i>6041 hex: Statusword.</i>
★ Position actual value	6064 hex-00.0 (Position actual value)	Shows the actual position. Set <i>6064 hex: Position actual value.</i>
Velocity actual value	Not set.*1	Shows the actual velocity. Normally set <i>606C hex: Velocity actual value.</i>
Torque actual value	6077 hex (Torque actual value)	Shows the actual torque. This object is necessary to output to the Servo Drive in Cyclic Synchronous Torque Control Mode by the MC_TorqueControl (Torque Control) and other instructions. Normally set <i>6077 hex: Torque actual value.</i>
Modes of operation display	6061 hex-00.0 (Modes of operation display)	Shows the operation mode. This object is necessary to change to a control mode other than Cyclic Synchronous Position Control Mode for the MC_SyncMoveVelocity (Cyclic Synchronous Velocity Control), MC_TorqueControl, and other instructions. Normally set <i>6061 hex: Modes of operation display.</i>
Touch probe status	60B9 hex-00.0 (Touch probe status)	Shows the status of the touch probe function. This object is required for the touch probe function for the MC_Home, MC_MoveFeed (Interrupt Feeding), MC_TouchProbe (Enable External Latch), MC_MoveLink (Synchronous Positioning), and other instructions. Normally set <i>60B9 hex: Touch probe status.</i>
Touch probe position 1 position value	60BA hex-00.0 (Touch probe pos1 pos value)	The latched position for touch probe 1. This object is required for the touch probe function for the MC_Home, MC_MoveFeed (Interrupt Feeding), MC_TouchProbe (Enable External Latch), MC_MoveLink (Synchronous Positioning), and other instructions. Normally set <i>60BA hex: Touch probe pos1 pos value.</i>

Function name	Process data	Description
Touch probe position 2 position value	60BC hex-00.0 (Touch probe pos2 pos value)	The latched position for touch probe 2. This object is required for the touch probe function for the MC_Home, MC_MoveFeed (Interrupt Feeding), MC_TouchProbe (Enable External Latch), MC_MoveLink (Synchronous Positioning), and other instructions. Normally set <i>60BC hex: Touchprobe pos2 pos value.</i>
Error code	603F hex-00.0 (Error code)	The error code in the Servo Drive. Normally set <i>603F hex: Error code.</i>
Reference position for csp	Not set.*2	The reference position for changing the csp mode. This object can be used with OMRON G5-series Servo Drives with unit version 2.1 or later. Set <i>4020 hex: Reference Position for csp when required.*3</i>

*1 If required, map the selected process data to a PDO before setting it. The standard setting is 606Ch-00.0 (Velocity actual value).

*2 This data is accessed by the MC_SyncMoveVelocity (Cyclic Synchronous Velocity Control) instruction. If it is required, set *4020 hex-00.0* (Reference position for csp). However, an error occurs in the Servo Drive if it is mapped to a PDO when the process data communications cycle for EtherCAT communications is 250 μs or 500 μs or when the electronic gear ratio at the Servo Drive (6091 hex) is not 1:1.
For details, refer to the *NJ-series Motion Control Instructions Reference Manual* (Cat. No. W508).

*3 Refer to the *G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications User's Manual* (Cat. No. I576) if you use 4020 hex (Reference position for csp) and check the process data communications cycles that can be set for EtherCAT communications.



Precautions for Correct Use

- Some functions may not be supported if you connect unit versions of the OMRON G5-series Servo Drives with Built-in EtherCAT Communications other than the recommended unit versions. Refer to the manual for the connected servo drive for details.
- If you change the settings, make sure that the desired operations are performed for the MC Function Module and process data settings.

● Digital Input Settings

The MC Function Module uses the following input signals of the Servo Drive.

Function name	Process data	Description
Positive limit switch (positive drive prohibit input)	60FD hex-00.1 (Digital inputs)	This signal is used for the positive limit input. Normally set <i>Bit 1: Positive limit switch of 60FD hex-00: Digital inputs.</i>
Negative limit switch (negative drive prohibit input)	60FD hex-00.0 (Digital inputs)	This signal is used for the negative limit input. Normally set <i>Bit 0: Negative limit switch of 60FD hex-00: Digital inputs.</i>
Immediate stop input	60FD hex-00.25 (Digital inputs)	This signal is used for the immediate stop input. Set <i>Bit 25: Immediate Stop Input of 60FD hex-00: Digital inputs</i> for an OMRON G5-series Servo Drive.
Encoder Phase Z Detection (encoder Z-phase detection)	60FD hex-00.10 (Digital inputs)	Shows the status of detecting the Z-phase input. Set <i>Bit 10: Encoder Phase Z Detection of 60FD hex-00: Digital inputs</i> for an OMRON G5-series Servo Drive.

Function name	Process data	Description
Home switch (home proximity input)	60FD hex-00.2 (Digital inputs)	This signal is used for the home proximity input. Normally set <i>Bit 2: Home switch of 60FD hex-00: Digital inputs.</i>
External Latch Input 1	60FD hex-00.17 (Digital inputs)	Shows the status of the signal that is used for external latch input 1. Set <i>Bit 17: External Latch Input 1 of 60FD hex-00: Digital inputs</i> for an OMRON G5-series Servo Drive.
External Latch Input 2	60FD hex-00.18 (Digital inputs)	Shows the status of the signal that is used for external latch input 2. Set <i>Bit 18: External Latch Input 2 of 60FD hex-00: Digital inputs</i> for an OMRON G5-series Servo Drive.



Precautions for Correct Use

- Some functions may not be supported if you connect unit versions of the G5-series Servo Drives with Built-in EtherCAT Communications other than the recommended unit versions. Refer to the manual for the connected servo drive for details.
- If you change the settings, make sure that the desired operations are performed for the MC Function Module and process data settings.

Object Settings

The Servo Drive settings required to use the control functions of the MC Function Module are listed in the following table.

Consult the manual for your Servo Drive and set all related objects for the Servo Drive functions that you are going to use.

Index	Subindex	Name	Recommended setting	Description
3015 hex	00 hex	Operation Switch for Using Absolute Encoder	0002 hex	Use absolute values and ignore multi-rotation counter overflow.
3317 hex	00 hex	Speed Limit Selection	0001 hex	The velocity limit method used during torque control is either 607F: Max profile velocity or 3321h: Velocity limit value setting, whichever value is smaller.
3324 hex	00 hex	External Feedback Pulse Dividing Numerator	00000000 hex	Set the encoder resolution per motor rotation [pulses]. Set to 0 for automatic setting.
3401 hex	00 hex	Input Signal Selection 2	00818181 hex	Positive Drive Prohibit Input (NC)
3402 hex	00 hex	Input Signal Selection 3	00828282 hex	Negative Drive Prohibit Input (NC)
3403 hex	00 hex	Input Signal Selection 4	00222222 hex	Home proximity input (NO)
3404 hex	00 hex	Input Signal Selection 5	002B2B2B hex	External Latch Signal 3 (NO)
3405 hex	00 hex	Input Signal Selection 6	00212121 hex	External Latch Signal 2 (NO)
3406 hex	00 hex	Input Signal Selection 7	00202020 hex	External Latch Signal 1 (NO)

Index	Subindex	Name	Recommended setting	Description
3504 hex	00 hex	Drive Prohibit Input Selection	0001 hex	The drive prohibit input is disabled at the Servo. This is performed by the MC Function Module instead.
3508 hex	00 hex	Undervoltage Error Selection	0001 hex	Operation is stopped for an insufficient main power voltage.
3521 hex	00 hex	Torque Limit Selection	0006 hex	There are two limit values, one for positive and one for negative. Switch between them by using PCL and NCL.
3703 hex	00 hex	Torque Limit Output Setting	0001h hex	Output turns ON for the torque limit value excluding the torque command value.
3801 hex	00 hex	Software Limit Function	0003 hex	Disable the software limits in both directions.
3758 hex	00 hex	Latch Trigger Selection	0100 hex	Touch probe1 = External latch signal 1 Touch probe2 = External latch signal 2
3759 hex	00 hex	Warning Hold Selection	0000 hex	The warnings are automatically cleared when the cause of the warning is eliminated.
607C hex	00 hex	Encoder Home Offset	00000000 hex	An offset value of 0 is used by the Servo Drive.
6091 hex	01 hex	Electronic Gear Ratio Numerator	00000001 hex	The gear ratio on the Servo Drive is 1:1. A similar function is set in the MC Function Module.
	02 hex	Electronic Gear Ratio Denominator	00000001 hex	
60E0 hex	00 hex	Positive Torque Limit	1388 hex	Default setting = 500.0%
60E1 hex	00 hex	Negative Torque Limit	1388 hex	Default setting = 500.0%

A-2 Connecting to Encoder Input Terminals

This appendix describes connections to an OMRON GX-series EtherCAT Slave Encoder Input Terminals.

A-2-1 Wiring to Encoder Input Terminals

Encoder Input Terminals are connected using EtherCAT communications. Refer to the *NJ-series CPU Unit Built-in EtherCAT Port User's Manual* (Cat. No. W505) for information on the connection methods.

A-2-2 Settings for Encoder Input Terminals

This section outlines the Encoder Input Terminal settings that are used when connected to OMRON GX-series GX-EC0211/EC0241 Encoder Input Terminals (i.e., the applicable Encoder Input Terminals for the MC Function Module). Refer to the *GX-series EtherCAT Slave User's Manual* (Cat. No. W488) for detailed information on the Encoder Input Terminals.

Recommended Encoder Input Terminals

All of the functions of an encoder axis of the MC Function Module can be used for Encoder Input Terminals with the unit versions that are given in the following table.

Manufacturer	Compatible models	Applicable unit versions
OMRON	GX-EC0211	Unit version 1.1 or later
OMRON	GX-EC0241	Unit version 1.1 or later



Additional Information

- Only the OMRON GX-EC0211/EC0241 can be used for encoder axes of EtherCAT slaves.
- Unit version 1.0 of the GX-EC0211/EC0241 can also be used for encoder axes, but they do not support the Sysmac device functions. When you use unit version 1.0, do not set the node address switches to 00. If you set them to 00, a network configuration error occurs. Refer to the *GX-series EtherCAT Slave User's Manual* (Cat. No. W488) for detailed information on functions

External Input Signals

When all of the functions of an encoder axis are used for an Encoder Input Terminal, the following input signals are used at the Encoder Input Terminal.

- Counter A phase
- Counter B phase
- Counter Z phase
- Latch Inputs (A/B)


There are two counter channels, and there are two external latches for each channel. Wire the input signals that are required for your application.

Refer to the *GX-series EtherCAT Slave User's Manual* (Cat. No. W488) for input signal wiring methods.

Relationships between MC Function Module and Process Data

The functions of the MC Function Module are related to the information in the process data objects. Depending on the EtherCAT slave configuration and functions that are used by the MC Function Module, you sometimes must change the relationships between the MC Function Module and the PDOs.

To access the settings, click the **Detailed Settings** Button on the Axis Basic Settings Tab Page in the Sysmac Studio.



Additional Information

If you use the recommended Encoder Input Terminals (GX-EC0211/EC0241, version 1.1 or higher), then it is not necessary to change the default relationships between the functions and process data on the Sysmac Studio.

● Output Settings (Controller to Servo Drive)

The input settings apply to the command data that is sent from the MC Function Module to the Encoder Input Terminal. The default settings in the Sysmac Studio are listed in the following table. (Required objects are marked with a star.)

Function name	Process data		Description
	Channel 1	Channel 2	
★ Software Switch of Encoder's Input Slave	4020 hex-01.0 (Instruction Bits)	4020 hex-02.0 (Instruction Bits)	Set the instruction bits. Set the objects given at the left for each channel.

Precautions for Correct Use

- If you change the settings, make sure that the desired operations are performed for the MC Function Module and process data settings.

● **Input Settings (Servo Drive to Controller)**

This is the status data from the Encoder Input Terminal to the MC Function Module. The default settings in the Sysmac Studio are listed in the following table. (Required objects are marked with a star.)

Function name	Process data		Description
	Channel 1	Channel 2	
★ Position actual value	4010 hex-01.0 (Position Value)	4010 hex-02.0 (Position Value)	Store the current values from the counters. Set the objects given at the left for each channel.
Touch probe position 1 position value	4012 hex-01.0 (Latch Value A)	4012 hex-02.0 (Latch Value A)	This is the latched position for latch 1. Store the values of latch positions A. You must map these objects to use the touch probe function, i.e., to use the MC_TouchProbe (Enable External Latch) instruction. Set the objects given at the left for each channel.
Touch probe position 2 position value	4013 hex-01.0 (Latch Value B)	4013 hex-02.0 (Latch Value B)	This is the latched position for latch 2. Store the values of latch positions B. You must map these objects to use the touch probe function, i.e., to use the MC_TouchProbe (Enable External Latch) instruction. Set the objects given at the left for each channel.
Status of Encoder's Input Slave	4030 hex-01.0 (Status Bits)	4030 hex-02.0 (Status Bits)	Store the status bits. You must map these objects to use the touch probe function, i.e., to use the MC_TouchProbe (Enable External Latch) instruction. Set the objects given at the left for each channel.



Precautions for Correct Use

- If you change the settings, make sure that the desired operations are performed for the MC Function Module and process data settings.

● **Digital Input Settings**

Settings are not required to use an encoder axis.

Object Settings in the Encoder Input Terminals

There are no objects that you must set at the Encoder Input Terminal.

A-3 Terminology

This appendix provides definitions of terms related to motion control.

A-3-1 NJ-series Controller

Term	Description
main memory	The memory inside the CPU Unit that is used by the CPU Unit to execute the OS and user program.
periodic task	Tasks for which user program execution and I/O refreshing are performed each period.
primary periodic task	The task with the highest priority.
period of tasks	The interval at which the primary periodic task or a periodic task is executed.
I/O Refresh	Cyclic data exchange with external devices that is performed with predetermined memory addresses.
program	One of three POU's. The others are functions and function blocks. Programs are assigned to tasks to execute them.
user program	All of the programs in one project.
Inline ST	ST programming that is included within a ladder diagram program.
system-defined variables	A variable for which all attributes are defined by the system and cannot be changed by the user.
global variable	Reading and writing global variables are possible from all POU's (programs, functions, and function blocks).
local variable	A variable that can be accessed only from the POU in which it is defined. Local variables include internal variables, input variables, output variables, in-out variables, and external variables.
download	To transfer data from the Sysmac Studio to the Controller, e.g., with the synchronization operation of the Sysmac Studio.
upload	To transfer data from the Controller to the Sysmac Studio, e.g., with the synchronization operation of the Sysmac Studio.
major fault level Control error	An error for which all control operations from the NJ-series Controller are not possible. The CPU Unit stops user program execution immediately and turns OFF the loads for all slaves and Units (including remote I/O).
partial fault level Controller error	An error for which all control operations for one of the function modules in the NJ-series Controller are stopped. The NJ-series CPU Unit continues operation even after a partial fault level Controller error occurs.
minor fault level Controller error	An error for which some of the control operations for one of the function modules in the NJ-series Controller are stopped. The NJ-series CPU Unit continues operation even after a minor fault level Controller error occurs.
observation	One of the event levels for Controller information and user-defined information. Observations represent minor errors that do not affect operation. They are recorded in an event log to inform the use.


A-3-2 Motion Control

Term	Description
Motion Control Function Module	A software component that executes motion control. It performs motion control based on commands from the motion control instructions that are executed in the user program. (Abbreviation: MC Function Module)
motion control instruction	An instruction that is defined as a function block to execute a motion control function. The MC Function Module supports instructions that are based on function blocks for PLCopen motion control as well as instructions developed specifically for the MC Function Module.
single-axis position control	Controlling the position of one axis.
single-axis velocity control	Controlling the velocity of one axis. For single-axis velocity control, the MC Function Module sometimes outputs velocity commands to the Servo Drive and sometimes outputs position commands to the Servo Drive.
single-axis torque control	Controlling the torque of one axis.
single-axis synchronized control	Synchronizing the control of one slave axis with one master axis. There are two types of single-axis synchronized control: gear operation, in which the axes are synchronized with a gear ratio, and cam operation, in which the axes are synchronized according to the relationship between phases and displacements in a cam table.
single-axis manual operation	Controlling an axis with manual operation, such as jogging.
auxiliary functions for single-axis control	Functions that aid in controlling an axis, such as override factor settings and resetting errors.
multi-axes coordinated control	Controlling the motion of more than one axis, such as linear interpolation and circular interpolation. You specify an axes group to specify the axes to coordinate.
auxiliary functions for multi-axes coordinated control	Functions that aid in controlling an axes group, such as override factor settings and resetting errors.
motion control parameters	Parameters that define the operation of the MC Function Module. The motion control parameters include the MC common parameters, axis parameters, and axes group parameters.
axis parameters	Parameters that apply to a single axis.
axes group parameters	Parameters that apply to an axes group.
system-defined variables for motion control	System-defined variables that provide status information for the MC Function Module. The system-defined variables for motion control include the MC Common Variable, Axis Variables, and Axes Group Variables.
MC common variables	A system-defined variable that is defined as a structure and provides status information for the overall operation of the MC Function Module.
axis variables	System-defined variables that are defined as structures and provide status information and some of the axis parameters for individual axes.
axes group variables	System-defined variables that are defined as structures and provide status information and some of the axes group parameters for individual axes groups.
homing	The process of defining home. Homing is also called home positioning, home searching, calibration, and datum.
home	The zero position of the mechanical system. Home is determined by the home input signal during the homing operation.
zero position	The position that is based on home and is treated as the zero position in the user program. This is the same position as home if the home position is not changed.

Term	Description
following error	The difference between the command current position and actual current position. There is a following error only in position control mode. (Other modes do not have a command current position.) The following error is also called the following error counter value and the remaining pulses.
following error reset	Setting the following error to zero.
cam profile curve	A curve that shows the relationship between phases and displacements in a cam operation. The cam profile curve is created on the Sysmac Studio.
cam data	Data made up of phases (master axis) and displacements (slave axis) for cam operation.
cam data variable	A structure array variable for cam data. It contains phases and displacements and is defined as a structure array.
cam table	A data table that contains cam data. Use the Sysmac Studio to download the cam profile curves that you created with the Cam Editor to the CPU Unit to save them as cam tables in the non-volatile memory in the CPU Unit.
override	A function that allows the operator to temporarily change programmed values during operation.
jerk	The rate of change in the acceleration or deceleration rate. If you specify the jerk, the velocity graph will form an S-curve for acceleration and deceleration. Jerk is also called jolt, surge, and lurch.

A-3-3 EtherCAT Communications

Term	Description
CAN application protocol over EtherCAT(CoE)	A CAN application protocol service implemented on EtherCAT.
CAN in Automation(CiA)	CiA is the international users' and manufacturers' group that develops and supports higher-layer protocols.
EtherCAT Technology Group	The ETG is a global organization in which OEM, End Users and Technology Providers join forces to support and promote the further technology development.
Object)	An abstract representation of a particular component within a device, which consists of data, parameters, and methods.
Object Dictionary	A data structure addressed by Index and Subindex that contains description of data type objects, communications objects and application objects.
Process Data	Collection of application objects designated to be transferred cyclically or acyclically for the purpose of measurement and control.
Process Data Object	A process data (I/O data) object that exchanges data at regular periods with CoE.
Service Data Object	CoE asynchronous mailbox communications where all objects in the object dictionary can be read and written.
Receive PDO	A process data object received by an EtherCAT slave.
Transmit PDO	A process data object sent from an EtherCAT slave.
Device Profile	A collection of device dependent information and functionality providing consistency between similar devices of the same device type.



Index



Index

A

- aborting 9-42, 9-57
- absolute encoder
 - Absolute Encoder Origin Position Offset 8-13
 - applicable Servomotors 8-13
 - homing 8-12
 - Rotary Mode 8-14
 - setup 8-14
- absolute positioning 9-4
- acceleration and deceleration 9-29
- acceleration and deceleration rates
 - unit 9-29
- acceleration rate
 - changing 9-38
- Acceleration Warning Value 5-11
- Acceleration/Deceleration Over 5-11
- Actual Current Position 6-21
- Actual Current Torque 6-21
- Actual Current Velocity 6-21
- actual position 6-14, 9-26
- actual velocity 9-28
- Actual Velocity Filter Time Constant 5-12
- assumed causes 11-10
- axes 3-2
 - specifying in user program 3-2
- Axes Group Basic Settings 5-21, 6-27
- Axes Group Command Values 6-26
- Axes Group Control Status 6-25
- Axes Group Disabled 6-25
- Axes Group Error Status 11-4
- Axes Group Errors 11-6
- axes group errors
 - resetting 9-47
- Axes Group Minor Fault 6-26
- Axes Group Minor Fault Code 6-26
- Axes Group Minor Fault Occurrence 6-26
- Axes Group Number 6-27
- Axes Group Observation 6-26
- Axes Group Observation Code 6-26
- Axes Group Observation Occurrence 6-26
- Axes Group Operation Settings 5-22
- axes group parameters 3-18, 5-20
 - list 5-20
- axes group states 6-6
 - Deceleration Stopping 6-7
 - Error Deceleration Stopping 6-6, 6-7
 - Group Standby 6-7
 - Moving 6-7
- Axes Group Status 6-25
- Axes Group Stop Method 5-23
- Axes Group Use 5-21, 6-27
- Axes Group Variables 3-17, 6-25
 - introduction 3-19
 - names 3-19
- axes groups 3-17
 - enabling and disabling 9-47
 - introduction 3-17
 - specifying in user program 3-17, 3-21
- Axis Basic Settings 5-5, 6-22
- Axis Command Values 6-21
- Axis Current Value 6-21
- Axis Disabled 6-19
- Axis Error 11-6
- Axis Error Status 11-4
- axis following error monitoring 9-70
- Axis Minor Fault 6-22
- Axis Minor Fault Occurrence 6-22
- Axis Number 5-5, 6-22
- Axis Observation 6-22
- Axis Observation Code 6-22
- Axis Observation Occurrence 6-22
- axis parameters 3-2, 5-4
 - introduction 3-3
 - list 5-4
- Axis Ready-to-execute 6-19
- axis states 6-4
 - Axis Disabled 6-5
 - Continuous Motion 6-5
 - Coordinated Motion 6-5
 - Deceleration Stopping 6-5
 - Discrete Motion 6-5
 - Error Deceleration Stopping 6-5
 - Homing 6-5
 - Stopped 6-5
 - Synchronized Motion 6-5
- Axis Status 6-19
- axis types 5-6
- Axis Use 5-5, 6-22
- Axis Variables 3-2, 6-19
 - names 3-5
 - relationship to axis types 6-23

B

- basic data types 6-16
- blending 9-43, 9-58
- Buffer Mode 9-41
- buffered 9-42, 9-58

C

- cam block 9-14
- cam block end point 9-14
- cam block start point 9-14
- cam curve 9-14
- cam data 9-14
 - loading and saving 9-18
- cam data index 9-14
- cam data variables 6-28, 9-14

cam end point 9-14
 cam operation 9-13, 9-14
 cam profile curves 6-28, 9-14
 names 6-31
 cam start point 9-14
 cam table 9-14
 Cam Table Busy 6-18
 cam table start position 9-15
 cam tables 6-28, 9-15
 data type 9-17
 names 6-31
 saving 9-18
 specifications 9-16
 specifying in user program 6-31
 switching 9-17
 updating properties 9-18
 CAN application protocol over EtherCAT (CoE) 2-11
 circular interpolation 9-49
 combining axes 9-21
 Command Current Acceleration/Deceleration 6-21
 Command Current Jerk 6-21
 Command Current Position 6-21
 Command Current Torque 6-21
 Command Current Velocity 6-21
 Command Direction 6-20
 Command Interpolation Acceleration/ Deceleration ... 6-26
 Command Interpolation Velocity 6-26
 command position 6-14, 9-26
 Command Pulse Count Per Motor Rotation 5-8, 6-22
 command velocity 9-28
 Command Velocity Saturation 6-20
 Composition 5-21, 6-27
 Composition Axes 5-21
 Composition Axis for Axis A0 6-27
 Composition Axis for Axis A1 6-27
 Composition Axis for Axis A2 6-27
 Composition Axis for Axis A3 6-27
 connecting acceleration 9-15
 connecting velocity 9-15
 Continuous Motion 6-19
 Coordinated Motion 6-19
 Correction Allowance Ratio 5-23
 Count Mode 5-13
 current position
 changing 9-65
 Cyclic Synchronous Position (CSP) Control Mode 6-20
 Cyclic Synchronous Torque (CST) Control Mode 6-20
 Cyclic Synchronous Velocity (CSV) Control Mode 6-20
 cyclic synchronous velocity control 9-24

D

data types 6-16
 deceleration rate
 changing 9-38
 deceleration stop of command value 9-8
 Deceleration Stopping 6-19, 6-25
 Deceleration Warning Value 5-12
 defined home

losing 8-2
 derivative data types 6-17
 Discrete Motion 6-19
 displacement 9-14
 Drive Error Input 6-20
 Drive Error Reset Monitoring Time 5-12
 Drive Internal Limiting 6-20
 Drive Status 6-20
 Drive Warning Input 6-20

E

electronic gear ratio (unit conversion formula) 5-10
 encoder axis 3-2, 5-6
 Encoder Type 5-13, 5-15
 enumerated data types 6-17
 error confirmation 11-3
 Error Deceleration Stopping 6-19, 6-25
 error status variables 11-4
 EtherCAT 1-2
 EtherCAT communications and motion control 2-11
 EtherCAT Master Function Module 2-2
 event codes 11-10
 event levels 11-6
 event names 11-10
 events 11-2, 11-10
 External Latch Input 1 6-20
 External Latch Input 2 6-20

F

finite length axis 5-13
 following error counter reset 9-70
 following error monitoring 9-69
 Following Error Over Value 5-13
 Following Error Warning Value 5-13
 function blocks for PLCopen motion control 6-3
 function specifications 1-7

G

gear operation 9-11
 Get Motion Control Error Status instruction 11-4
 GetMCErr (Get Motion Control Error Status) 11-4

H

high-speed homing 8-15
 home 8-2
 Home Defined 6-20
 Home Input 6-20
 Home Input Detection Direction 5-16, 8-8
 Home Input Mask Distance 5-16, 8-8
 Home Input Signal 5-16, 8-9
 Home Offset 5-16, 8-9
 Home Proximity Input 6-20
 Homing 6-19
 homing 8-2
 Homing Acceleration 5-16, 8-9

Homing Approach Velocity 5-16, 8-9
 Homing Compensation Value 5-17, 8-8
 Homing Compensation Velocity 5-17, 8-9
 Homing Deceleration 5-16, 8-9
 Homing Holding Time 5-16, 8-8
 Homing Jerk 5-16, 8-9
 Homing Method 5-16, 8-6
 homing parameters 8-5
 Homing Settings 5-16
 Homing Start Direction 5-16, 8-7
 Homing Velocity 5-16, 8-9

I

Idle 6-25
 Immediate Stop Input 6-20
 Immediate Stop Input Stop Method 5-12
 immediate stop of command value 9-8
 immediate stop of command value and error reset 9-9
 immediate stop of command value and servo OFF 9-9
 In Home Position 6-20
 indicators 11-3
 infinite length axis 5-13
 information 11-6
 in-position check 9-71
 In-position Check Time 5-12
 In-position Range 5-12
 In-position Waiting 6-20, 6-25
 input devices and output devices 5-6
 Interpolation Acceleration Warning Value 5-23
 Interpolation Acceleration/Deceleration Over 5-22
 Interpolation Deceleration Warning Value 5-23
 Interpolation Velocity Warning Value 5-22
 interrupt feeding 9-5
 invalid cam data 9-14

J

jerk 1-2, 9-31
 jerk unit 9-31
 jogging 7-5

K

Kinematics Transformation Settings 6-27

L

latching 9-66
 Limit Input Stop Method 5-12
 Limit Settings 5-13
 linear interpolation 9-48
 Linear Mode 5-14

M

Main Power 6-20
 major fault 11-6
 manual operation 7-2

master axis 9-14
 master axis phase shift 9-22
 master sync start position 9-15
 Maximum Acceleration 5-11
 Maximum Deceleration 5-11
 Maximum Interpolation Acceleration 5-22
 Maximum Interpolation Deceleration 5-22
 Maximum Interpolation Velocity 5-22
 Maximum Jog Velocity 5-11
 Maximum Negative Torque Limit 5-13
 maximum number of cam data 9-14
 Maximum Positive Torque Limit 5-13
 Maximum Velocity 5-11
 MC Common Error Status 11-4
 MC Common Errors 11-6
 MC Common Minor Fault 6-18
 MC Common Minor Fault Code 6-18, 6-22
 MC Common Minor Fault Occurrence 6-18
 MC Common Observation 6-18
 MC Common Observation Code 6-18
 MC Common Observation Occurrence 6-18
 MC Common Partial Fault 6-18
 MC Common Partial Fault Code 6-18
 MC Common Partial Fault Occurrence 6-18
 MC Common Status 6-18
 MC Common Variable 6-18
 MC Error Status 11-4
 MC Run 6-18
 MC Test Run 4-2, 6-18
 MC Test Run functions 4-2
 _MC_AX[0-63].Act.Pos (Actual Current Position) 6-21
 _MC_AX[0-63].Act.Trq (Actual Current Torque) 6-21
 _MC_AX[0-63].Act.Vel (Actual Current Velocity) 6-21
 _MC_AX[0-63].Cfg.AxEnable (Axis Use) 6-22
 _MC_AX[0-63].Cfg.AxNo (Axis Number) 6-22
 _MC_AX[0-63].Cfg.AxType (Axis Type) 6-22
 _MC_AX[0-63].Cfg.NodeAddress (Node Address) 6-22
 _MC_AX[0-63].Cmd.AccDec (Command Current Acceleration/Deceleration) 6-21
 _MC_AX[0-63].Cmd.Jerk (Command Current Jerk) 6-21
 _MC_AX[0-63].Cmd.Pos (Command Current Position) 6-21
 _MC_AX[0-63].Cmd.Trq (Command Current Torque) 6-21
 _MC_AX[0-63].Cmd.Vel (Command Current Velocity) 6-21
 _MC_AX[0-63].Details.Homed (Home Defined) 6-20
 _MC_AX[0-63].Details.Idle (Standstill) 6-20
 _MC_AX[0-63].Details.InHome (In Home Position) 6-20
 _MC_AX[0-63].Details.InPosWaiting (In-position Waiting) 6-20
 _MC_AX[0-63].Details.VelLimit (Command Velocity Saturation) 6-20
 _MC_AX[0-63].Dir.Nega (Negative Direction) 6-20
 _MC_AX[0-63].Dir.Posi (Positive Direction) 6-20
 _MC_AX[0-63].DrvStatus.CSP (Cyclic Synchronous Position (CSP) Control Mode) 6-20
 _MC_AX[0-63].DrvStatus.CST (Cyclic Synchronous Torque (CST) Control Mode) 6-20
 _MC_AX[0-63].DrvStatus.CSV (Cyclic Synchronous Velocity (CSV) Control Mode) 6-20

_MC_AX[0-63].DrvStatus.DrvAlarm (Drive Error Input)	6-20	_MC_COM.PFaultLvl.Active (MC Common Partial Fault Occurrence)	6-18
_MC_AX[0-63].DrvStatus.DrvWarning (Drive Warning Input)	6-20	_MC_COM.PFaultLvl.Code (MC Common Partial Fault Code)	6-18
_MC_AX[0-63].DrvStatus.Home (Home Input)	6-20	_MC_COM.Status.CamTableBusy (Cam Table Busy)	6-18
_MC_AX[0-63].DrvStatus.HomeSw (Home Proximity Input)	6-20	_MC_COM.Status.RunMode (MC Run)	6-18
_MC_AX[0-63].DrvStatus.ILA (Drive Internal Limiting)	6-20	_MC_COM.Status.TestMode (MC Test Run)	6-18
_MC_AX[0-63].DrvStatus.lmdStop (Immediate Stop Input)	6-20	_MC_ComErrSta (MC Common Error Status)	11-4
_MC_AX[0-63].DrvStatus.Latch1 (External Latch Input 1)	6-20	_MC_ErrSta (Axis Error Status)	11-4
_MC_AX[0-63].DrvStatus.Latch2 (External Latch Input 2)	6-20	_MC_GRP[0-31] (Axes Group Variable)	6-25
_MC_AX[0-63].DrvStatus.MainPower (Main Power) ...	6-20	_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) ...	6-27
_MC_AX[0-63].DrvStatus.N_OT (Negative Limit Input)	6-20	_MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) ...	6-27
_MC_AX[0-63].DrvStatus.P_OT (Positive Limit Input)	6-20	_MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration)	6-26
_MC_AX[0-63].DrvStatus.Ready (Servo Ready)	6-20	_MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity)	6-26
_MC_AX[0-63].DrvStatus.ServoOn (Servo ON)	6-20	_MC_GRP[0-31].Details.Idle (Idle)	6-25
_MC_AX[0-63].MFaultLvl.Active (Axis Minor Fault Occurrence)	6-22	_MC_GRP[0-31].Details.InPosWaiting (In-Position Waiting)	6-25
_MC_AX[0-63].MFaultLvl.Code (MC Common Minor Fault Code)	6-22	_MC_GRP[0-31].Kinematics.Axis[0] (Composition Axis for Axis A0)	6-27
_MC_AX[0-63].Obsr.Active (Axis Observation Occurrence)	6-22	_MC_GRP[0-31].Kinematics.Axis[1] (Composition Axis for Axis A1)	6-27
_MC_AX[0-63].Obsr.Code (Axis Observation Code) ..	6-22	_MC_GRP[0-31].Kinematics.Axis[2] (Composition Axis for Axis A2)	6-27
_MC_AX[0-63].Scale.Den (Work Travel Distance Per Motor Rotation)	6-22	_MC_GRP[0-31].Kinematics.Axis[3] (Composition Axis for Axis A3)	6-27
_MC_AX[0-63].Scale.Num (Command Pulse Count Per Motor Rotation)	6-22	_MC_GRP[0-31].Kinematics.GrpType (Composition) ..	6-27
_MC_AX[0-63].Scale.Units (Unit of Display)	6-22	_MC_GRP[0-31].MFaultLvl.Active (Axes Group Minor Fault Occurrence)	6-26
_MC_AX[0-63].Status.Continuous (Continuous Motion)	6-19	_MC_GRP[0-31].MFaultLvl.Code (Axes Group Minor Fault Code)	6-26
_MC_AX[0-63].Status.Coordinated (Coordinated Motion)	6-19	_MC_GRP[0-31].Obsr.Active (Axes Group Observation Occurrence)	6-26
_MC_AX[0-63].Status.Disabled (Axis Disabled)	6-19	_MC_GRP[0-31].Obsr.Code (Axes Group Observation Code)	6-26
_MC_AX[0-63].Status.Discrete (Discrete Motion)	6-19	_MC_GRP[0-31].Status.Disabled (Axes Group Disabled)	6-25
_MC_AX[0-63].Status.ErrorStop (Error Deceleration Stopping)	6-19	_MC_GRP[0-31].Status.ErrorStop (Error Deceleration Stopping)	6-25
_MC_AX[0-63].Status.Homing (Homing)	6-19	_MC_GRP[0-31].Status.Moving (Moving)	6-25
_MC_AX[0-63].Status.Ready (Axis Ready-to-execute)	6-19	_MC_GRP[0-31].Status.Ready (Ready to Execute) ...	6-25
_MC_AX[0-63].Status.Standstill (Stopped)	6-19	_MC_GRP[0-31].Status.Standby (Stopped)	6-25
_MC_AX[0-63].Status.Stopping (Deceleration Stopping)	6-19	_MC_GRP[0-31].Status.Stopping (Deceleration Stopping)	6-25
_MC_AX[0-63].Status.Synchronized (Synchronized Motion)	6-19	_MC_GRP_ErrSta (Axes Group Error Status)	11-4
_MC_AX_ErrSta (MC Error Status)	11-4	minor fault	11-6
_MC_COM (MC Common Variable)	6-18	Modulo Maximum Position Setting Value	5-13, 5-15
_MC_COM.MFaultLvl.Active (MC Common Minor Fault Occurrence)	6-18	Modulo Minimum Position Setting Value	5-13, 5-15
_MC_COM.MFaultLvl.Code (MC Common Minor Fault Code)	6-18	Motion Control Function Module	2-2
_MC_COM.Obsr.Active (MC Common Observation Occurrence)	6-18	motion control instructions	6-3
_MC_COM.Obsr.Code (MC Common Observation Code)	6-18	Enable variable	6-10
		exclusiveness of outputs	6-8
		Execute variable	6-10
		execution and status	6-8
		input parameters	6-8
		multi-execution	9-41, 9-56
		operation of output variable Busy	6-9
		operation of output variable CommandAborted	6-9

operation of output variable Done	6-9
output status	6-8
output variable Active	6-9
re-executing	9-35, 9-56
timing chart for multi-execution	6-13
timing chart for re-execution	6-12
timing charts for enable-type instructions	6-12
timing charts for execute-type instructions	6-10
motion control period	2-13
motion control programs	6-2
writing	6-32
Moving	6-25
multi-axes coordinated control	9-46
multi-execution of instructions	9-41, 9-56

N

Negative Direction	6-20
Negative Limit Input	6-20
Negative Software Limit	5-13
Negative Torque Warning Value	5-12
Node Address	6-22
node addresses	5-7
null cam data	9-15
number of valid cam data	9-14

O

object dictionary	2-11
observation	11-6
operation direction	
specifying	9-32
current direction	9-32
negative direction	9-32
no direction specified	9-32
positive direction	9-32
shortest way	9-32
Operation Selection at Negative Limit Input	5-16, 8-6
Operation Selection at Positive Limit Input	5-16, 8-6
Operation Selection at Reversing	5-11
Operation Settings	5-11
original cam data	9-14
Other Operation Settings	5-12
overrides	9-9, 9-51

P

partial fault	11-6
performance specifications	1-6
periodic tasks	2-4
phase	9-14
phase pitch	9-15
PLC Function Module	2-2
PLCopen	1-2
Position Count Settings	5-13
positioning gear operation	9-12
positions	6-14, 9-26
types	9-26
Positive Direction	6-20

Positive Limit Input	6-20
Positive Software Limit	5-13
Positive Torque Warning Value	5-12
primary period	2-5, 2-13
primary periodic task	2-4
process data communications cycle	2-13
process data objects (PDOs)	2-11
program-modified cam data	9-14

R

Ready to Execute	6-25
re-executing instructions	9-35
re-execution of instructions	9-56
relative positioning	9-4
Rotary Mode	5-14

S

S-curve	9-31
service data objects (SDOs)	2-11
servo axis	3-2, 5-6
Servo Drive Settings	5-15
Servo ON	6-20, 7-3
Servo Ready	6-20
single-axis control	
common functions	9-26
position control	9-3
synchronized control	9-11
torque control	9-25
velocity control	9-23
slave axis	9-14
Software Limits	5-13
software limits	9-68
sources	11-6
Standstill	6-20
start mode	9-15
stop priorities	9-9
Stopped	6-19, 6-25
Stopping	9-6
stopping	
due to errors or other problems	9-7, 9-50
immediate stop input	9-6
limit inputs	9-6
MC_GroupImmediateStop instruction	9-50
MC_GroupStop instruction	9-50
MC_ImmediateStop instruction	9-7
MC_Stop instruction	9-7
Servo Drive input signals	9-6
stop method	9-8
stopping under multi-axes coordinated control	9-50
structure data types	6-17
superimpose corners	9-60
Synchronized Motion	6-19
synchronous positioning	9-19
system configuration	1-3
system-defined variables	6-15, 11-4
motion control	6-15, 11-5
attributes	6-17

tables 6-18

T

target position
 changing 9-35
 excessive deceleration patterns 9-36
 triangular control patterns 9-36
 when a reverse turn occurs for the new
 command value 9-36

target velocity
 changing 9-38

task period 2-5

tasks 2-4

torque command
 changing 9-39

torque limit 9-66

transition disabled 9-60

Transition Modes 9-60

travel distance
 changing 9-38

trial operation 4-2

Troubleshooter 11-4

troubleshooting 11-4

U

Unit Conversion Settings 5-8, 6-22

Unit of Display 5-8, 6-22

V

valid cam data 9-14

velocities
 types 9-28
 velocity control 9-23
 velocity unit 9-28
 Velocity Warning Value 5-11

virtual encoder axis 3-2, 5-6

virtual servo axis 3-2, 5-6

W

Work Travel Distance Per Motor Rotation 5-8, 6-22

Z

Zero Position Range 5-12

zones 9-67

OMRON Corporation Industrial Automation Company

Tokyo, JAPAN

Contact: www.ia.omron.com

Regional Headquarters

OMRON EUROPE B.V.

Wegalaan 67-69-2132 JD Hoofddorp
The Netherlands

Tel: (31)2356-81-300/Fax: (31)2356-81-388

OMRON ELECTRONICS LLC

One Commerce Drive Schaumburg,
IL 60173-5302 U.S.A.

Tel: (1) 847-843-7900/Fax: (1) 847-843-7787

OMRON ASIA PACIFIC PTE. LTD.

No. 438A Alexandra Road # 05-05/08 (Lobby 2),
Alexandra Technopark,
Singapore 119967

Tel: (65) 6835-3011/Fax: (65) 6835-2711

OMRON (CHINA) CO., LTD.

Room 2211, Bank of China Tower,
200 Yin Cheng Zhong Road,
PuDong New Area, Shanghai, 200120, China

Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200

Authorized Distributor:

© OMRON Corporation 2011 All Rights Reserved.
In the interest of product improvement,
specifications are subject to change without notice.

Cat. No. W507-E1-01

0711